


# Service Manual



ORDER NO.  
RRV1280

COMPACT DISC RECORDER

# PDR-99 PDR-05

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

| Type | Model  |        | Power Requirement | Remarks |
|------|--------|--------|-------------------|---------|
|      | PDR-99 | PDR-05 |                   |         |
| KU   | ○      | ○      | AC120V            |         |
| ME8  | -      | ○      | AC220 - 230V      |         |

## CONTENTS

|   |     |
|---|-----|
| 1. SAFETY INFORMATION .....                       | 2   |
| 2. PACKING AND PARTS LIST .....                   | 4   |
| 3. EXPLODED VIEWS AND PARTS LIST .....            | 5   |
| 4. DISASSEMBLY .....                              | 12  |
| 5. SCHEMATIC AND PCB CONNECTION<br>DIAGRAMS ..... | 13  |
| 6. PCB PARTS LIST .....                           | 39  |
| 7. ADJUSTMENTS .....                              | 46  |
| 8. TROUBLESHOOTING .....                          | 73  |
| 9. IC INFORMATION .....                           | 75  |
| 10. FL INFORMATION .....                          | 103 |
| 11. CIRCUIT DESCRIPTION .....                     | 104 |
| 12. BLOCK DIAGRAMS .....                          | 119 |
| 13. PANEL FACILITIES .....                        | 123 |
| 14. SPECIFICATIONS .....                          | 124 |

## 1. SAFETY INFORMATION

This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual. Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.



### WARNING

Lead in solder used in this product is listed by the California Health and Welfare agency as a known reproductive toxicant which may cause birth defects or other reproductive harm (California Health & Safety Code, Section 25249.5).

When servicing or handling circuit boards and other components which contain lead in solder, avoid unprotected skin contact with the solder. Also, when soldering do not inhale any smoke or fumes produced.



### NOTICE

(FOR CANADIAN MODEL ONLY)

Fuse symbols  (fast operating fuse) and/or  (slow operating fuse) on PCB indicate that replacement parts must be of identical designation.

### REMARQUE

(POUR MODÈLE CANADIEN SEULEMENT)

Les symboles de fusible  (fusible de type rapide) et/ou  (fusible de type lent) sur CCI indiquent que les pièces de remplacement doivent avoir la même désignation.


(FOR USA MODEL ONLY)

### 1. SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

#### LEAKAGE CURRENT CHECK

Measure leakage current to a known earth ground (water pipe, conduit, etc.) by connecting a leakage current tester such as Simpson Model 229-2 or equivalent between the earth ground and all exposed metal parts of the appliance (input/output terminals, screwheads, metal overlays, control shaft, etc.). Plug the AC line cord of the appliance directly into a 120V AC 60Hz outlet and turn the AC power switch on. Any current measured must not exceed 0.5mA.



AC Leakage Test

ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE APPLIANCE TO THE CUSTOMER.

### 2. PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in the appliance have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a  $\Delta$  on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which does not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

(FOR EUROPEAN MODEL ONLY)

**VARO!**  
AVATTAESSA JA SUOJALUKITUS  
OHITETTAESSA OLET ALTTIINA  
NAKYMÄTTÖMÄLLE LASERSATEILYLLE.  
ÄLÄ KATSO SÄTEESEEN.

**ADVERSEL:**  
USYNLIG LASERSTRÅLING VED ÅBNING  
NÅR SIKKERHEDSAFBRYDERE ER UDE AF  
FUNKTION. UNDGÅ UDSÆTTELSE FOR  
STRÅLING.

**VARNING!**  
OSYNLIG LASERSTRÅLNING NÅR DENNA  
DEL ÄR ÖPPNAD OCH SPÄRREN  
ÄR URKOPPLAD. BETRÄKTA EJ STRÅLEN.



LASER  
Kuva 1  
Lasersäteilyn  
varoituserkki

**WARNING!**  
DEVICE INCLUDES LASER DIODE WHICH  
EMITS INVISIBLE INFRARED RADIATION  
WHICH IS DANGEROUS TO EYES. THERE IS  
A WARNING SIGN ACCORDING TO PICTURE  
1 INSIDE THE DEVICE CLOSE TO THE LASER  
DIODE.



LASER  
Picture 1  
Warning sign for  
laser radiation

**IMPORTANT**  
THIS PIONEER APPARATUS CONTAINS  
LASER OF CLASS 1.  
SERVICING OPERATION OF THE APPARATUS  
SHOULD BE DONE BY A SPECIALLY  
INSTRUCTED PERSON.


**LASER DIODE CHARACTERISTICS**  
MAXIMUM OUTPUT POWER: 5 mw  
WAVELENGTH: 780-785 nm

**LABEL CHECK (PDR-05/ME8 type)**

**CLASS 1  
LASER PRODUCT**  
VRW-328



**VARO!**  
Avatessa ja suojalukitus ohitettaessa olet alttiina näkymättömälle lasersäteilylle. Älä katso säteeseen.  
**VARNING!**  
Osynlig laserstrålning när denna del är öppnad och spärren är urkopplad. Beträkta ej strålen.  
PRM233



**ADVARSEL**  
USYNLIG LASERSTRÅLING VED ÅBNING NÅR SIKKERHEDSAFBRYDERE ER UDE AF FUNKTION. UNDGÅ UDSÆTTELSE FOR STRÅLING.  
**VORSICHT!**  
UNSICHTBARE LASERSTRÄHLUNG TRITZ AUS, WENN DECKEL (ODER KLAPPEL) GEÖFFNET IST! NICHT DEM STRÄHL AUSSETZEN!  
VRW1094

**Additional Laser Caution**

- Laser Interlock Mechanism**  
The position of the switch (S101) for detecting clamp state is detected by the system microprocessor, and the design prevents laser diode oscillation when the switch (S101) is not clamp state [X OPEN signal is OFF (high) and X CLAMP signal is ON (low)].  
Thus, the interlock will no longer function if the switch (S101) is deliberately set to clamp state [X OPEN signal is OFF (high) and X CLAMP signal is ON (low)].  
The interlock also does not function in the test mode \*.  
Laser diode oscillation will continue, if pin 39 of PA4022A (IC101) on the HEAD board assy mounted on the single mechanism assy is connected to GND.
- When the cover is opened with the servo mechanism block removed and turned over, close viewing of the objective lens with the naked eye will cause exposure to a Class 1 laser beam.

\* : Refer to page 49 .

## 2. PACKING AND PARTS LIST

### NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The  $\Delta$  mark found on some component parts indicates the importance of the safety factor of the parts. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.


### ■ CONTRAST OF PDR-99/KU, PDR-05/KU AND PDR-05/ME8

PDR-99/KU, PDR-05/KU and PDR-05/ME8 have the same construction except for the following:

| Mark | No. | Symbol & Description                                   | Part No.  |           |            | Remarks |
|------|-----|--|-----------|-----------|------------|---------|
|      |     |  | PDR-99/KU | PDR-05/KU | PDR-05/ME8 |         |
|      | 2   | Cord with mini plug (for SR cord)                      | PDE1247   | PDE1247   | Not Used   |         |
|      | 3   | Operating instructions (English)                       | PRB1235   | PRB1224   | Not used   |         |
|      | 3   | Operating instructions (English/French/German/Italian) | Not Used  | Not Used  | PRE1216    |         |
|      | 3   | Operating instructions (Dutch/Swedish/Spanish/Danish)  | Not Used  | Not Used  | PRF1069    |         |
|      | 4   | CD-R disc caution card                                 | PRM1046   | PRM1046   | PRM1045    |         |
|      | 9   | Mirror mat   | DHL1006   | Z23-007   | Z23-007    |         |
|      | 10  | Styrol protector F                                     | PHA1301   | PHA1243   | PHA1243    |         |
|      | 11  | Styrol protector R                                     | PHA1302   | PHA1245   | PHA1245    |         |
|      | 12  | Packing case   | PHG2157   | PHG2119   | PHG2118    |         |

### ■ PARTS LIST FOR PDR-99/KU

| Mark | No. | Description                             | Parts No. |
|------|-----|---|-----------|
|      | 1   | Cord with plug                          | PDE1109   |
|      | 2   | Cord with mini Plug (for SR cord)       | PDE1247   |
|      | 3   | Operating instructions (English)        | PRB1235   |
|      | 4   | CD-R disc caution card                  | PRM1046   |
|      | 5   | Wireless remote control unit (CU-PD075) | PWW1103   |
| NSP  | 6   | Battery cover                           | PZN1010   |
|      | 7   | Battery (R03, AAA)                      | VEM-022   |
|      | 8   | Polyethylene bag                        | Z21-038   |
|      | 9   | Mirror mat                              | DHL1006   |
|      | 10  | Styrol protector F                      | PHA1301   |
|      | 11  | Styrol protector R                      | PHA1302   |
|      | 12  | Packing case                            | PHG2157   |





### 3. EXPLODED VIEWS AND PARTS LIST

#### NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The  $\Delta$  mark found on some component parts indicates the importance of the safety factor of the parts. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "☉" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

#### 3.1 EXTERIOR

##### ■ CONTRAST OF PDR-99/KU, PDR-05/KU AND PDR-05/ME8

PDR-99/KU, PDR-05/KU and PDR-05/ME8 have the same construction except for the following:

| Mark     | No. | Symbol & Description                     | Part No.  |              |              | Remarks |
|----------|-----|--|-----------|--------------|--------------|---------|
|          |     |  | PDR-99/KU | PDR-05/KU    | PDR-05/ME8   |         |
|          | 2   | Servo Ucom board assy                    | PWZ3027   | PWZ3029      | PWZ3028      |         |
|          | 3   | Audio digital board assy                 | PWZ3033   | PWZ3031      | PWZ3032      |         |
|          | 8   | Power A board assy                       | PWZ3049   | PWZ3047      | PWZ3048      |         |
|          | 9   | Power B board assy                       | PWZ3053   | PWZ3051      | PWZ3052      |         |
| $\Delta$ | 10  | Strain relief                            | CM-22C    | CM-22C       | CM-22B       |         |
| $\Delta$ | 13  | AC power cord                            | PDG1015   | PDG1015      | PDG1003      |         |
|          | 14  | Ferrite core                             | PTH1018   | PTH1018      | PTH1021      |         |
| $\Delta$ | 15  | Power transformer (Servo, AC120V)        | PTT1308   | PTT1308      | Not Used     |         |
| $\Delta$ | 15  | Power transformer (Servo, AC220V – 230V) | Not Used  | Not Used     | PTT1315      |         |
| $\Delta$ | 16  | Power transformer (Audio, AC120V)        | PTT1309   | PTT1309      | Not Used     |         |
| $\Delta$ | 16  | Power transformer (Audio, AC220V – 230V) | Not Used  | Not Used     | PTT1316      |         |
| $\Delta$ | 17  | Fuse (FU 11, 1A)                         | REK1075   | REK1075      | Not Used     |         |
| $\Delta$ | 17  | Fuse (FU 11, T500mA)                     | Not Used  | Not Used     | AEK1051      |         |
|          | 26  | Rear base R99                            | PNA2247   | Not Used     | Not Used     |         |
|          | 26  | Rear base                                | Not Used  | PNA2201      | PNA2200      |         |
|          | 39  | FL sheet                                 | PAM1673   | PAM1673      | PAM1669      |         |
|          | 40  | Front panel 99 (AL)                      | PAN1335   | Not Used     | Not Used     |         |
|          | 40  | Front panel                              | Not Used  | PAN1334      | PAN1337      |         |
|          | 41  | Name plate 99 (AL)                       | PAN1325   | Not Used     | Not Used     |         |
|          | 41  | Name plate                               | Not Used  | PAN1308      | PAN1332      |         |
|          | 42  | Display panel 99 (AL)                    | PAN1326   | Not Used     | Not Used     |         |
|          | 42  | Display panel                            | Not Used  | PAN1309      | PAN1309      |         |
|          | 43  | Side mole (L)                            | PAN1327   | Not Used     | Not Used     |         |
|          | 44  | Side mole (R)                            | PAN1328   | Not Used     | Not Used     |         |
|          | 45  | Step screw                               | PBA1103   | Not Used     | Not Used     |         |
|          | 46  | Plate spring                             | PBK1061   | Not Used     | Not Used     |         |
|          | 49  | Side wood (L)                            | PMM1041   | Not Used     | Not Used     |         |
|          | 50  | Side wood (R)                            | PMM1042   | Not Used     | Not Used     |         |
|          | 51  | Wood collar                              | PNW1238   | Not Used     | Not Used     |         |
|          | 57  | Control panel 99 (AL)                    | PNW2630   | Not Used     | Not Used     |         |
|          | 57  | Control panel                            | Not Used  | PNW2571      | PNW2571      |         |
|          | 59  | 65 label                                 | ORW1069   | ORW1069      | Not Used     |         |
|          | 62  | Bonnet                                   | PYY1189   | PYY1188      | PYY1188      |         |
|          | 72  | Caution label (HE)                       | Not Used  | Not Used     | PRW1233      |         |
| NSP      | 73  | Caution label (F)                        | Not Used  | Not Used     | VRW-328      |         |
|          | 74  | Caution label (G)                        | Not Used  | Not Used     | VRW-329      |         |
|          | 75  | Caution label                            | Not Used  | Not Used     | VRW1094      |         |
|          | 76  | Screw                                    | Not Used  | FBT40P080FZK | FBT40P080FZK |         |
|          | 79  | Earth plate                              | Not Used  | Not Used     | PBK1090      |         |
|          | 81  | Sheet                                    | PNM1293   | Not Used     | Not Used     |         |

## ■ PARTS LIST FOR PDR-99/KU

| Mark | No. | Description                       | Parts No. | Mark | No. | Description           | Parts No.    |
|------|-----|-----------------------------------|-----------|------|-----|-----------------------|--------------|
|      | 1   | HEAD BOARD ASSY                   | PWZ3022   |      | 56  | Tray holder           | PNW2592      |
|      | 2   | SERVO UCOM BOARD ASSY             | PWZ3027   |      | 57  | Control panel 99 (AL) | PNW2630      |
|      | 3   | AUDIO DIGITAL BOARD ASSY          | PWZ3033   |      | 58  | Name plate (AL)       | VAM1032      |
| NSP  | 4   | REC VR BOARD ASSY                 | PWZ3034   |      | 59  | 65 label              | ORW1069      |
| NSP  | 5   | H.P BOARD ASSY                    | PWZ3038   |      | 60  | Caution label         | PRW1244      |
| NSP  | 6   | MECHANISM BOARD ASSY              | PWZ3062   |      | 61  | Indicator lens        | PEA1206      |
|      | 7   | FUNCTION BOARD ASSY               | PWZ3042   |      | 62  | Bonnet                | PYY1189      |
|      | 8   | POWER A BOARD ASSY                | PWZ3049   |      | 63  | Screw                 | BBT30P080FCC |
|      | 9   | POWER B BOARD ASSY                | PWZ3053   |      | 64  | Ferrite core          | PTH1009      |
| △    | 10  | Strain relief                     | CM-22C    |      | 65  | Screw                 | BBZ30P080FCC |
|      | 11  | 39P F.F.C/30V                     | PDD1163   |      | 66  | Screw                 | IBZ30P060FCC |
|      | 12  | Connector assy (5P)               | PDE1272   |      | 67  | Screw                 | IBZ30P080FCC |
| △    | 13  | AC power cord                     | PDG1015   |      | 68  | Screw                 | IBZ30P150FCC |
|      | 14  | Ferrite core                      | PTH1018   |      | 69  | Screw                 | PPZ30P150FMC |
| △    | 15  | Power transformer (Servo, AC120V) | PTT1308   |      | 70  | Rivet (plastic)       | RBM-003      |
| △    | 16  | Power transformer (Audio, AC120V) | PTT1309   |      | 71  | Binder                | ZCA-SKB90BK  |
| △    | 17  | Fuse (FU11, 1A)                   | REK1075   |      | 72  | .....                 |              |
|      | 18  | Screw                             | ABA1207   |      | 73  | .....                 |              |
|      | 19  | Cord clasper                      | RNH-184   |      | 74  | .....                 |              |
| NSP  | 20  | Cushion (3.5)                     | PEB1110   |      | 75  | .....                 |              |
| NSP  | 21  | Spacer A                          | PEB1228   |      | 76  | .....                 |              |
|      | 22  | Rubber spacer A                   | PEB1280   | NSP  | 77  | Cord clasper          | DNF1128      |
|      | 23  | Rubber spacer B                   | PEB1281   |      | 78  | Binder holder         | PNW1021      |
| NSP  | 24  | Under base                        | PNA2195   |      | 79  | .....                 |              |
|      | 25  | Audio angle                       | PNA2197   | NSP  | 80  | Cap                   | VEC1810      |
|      | 26  | Rear base 99                      | PNA2247   |      | 81  | Sheet                 | PNM1293      |
|      | 27  | Stopper                           | PNM1285   |      |     |                       |              |
|      | 28  | Insulator                         | PNW2020   |      |     |                       |              |
| NSP  | 29  | PCB holder                        | PNW2100   |      |     |                       |              |
|      | 30  | PCB holder                        | PNW2562   |      |     |                       |              |
| NSP  | 31  | PCB spacer                        | PNY-404   |      |     |                       |              |
| NSP  | 32  | Loading mechanism assy TT         | PXA1568   |      |     |                       |              |
|      | 33  | Headphone knob                    | PAC1600   |      |     |                       |              |
|      | 34  | Operate button                    | PAC1744   |      |     |                       |              |
|      | 35  | REC button                        | PAC1804   |      |     |                       |              |
|      | 36  | Power button                      | PAC1805   |      |     |                       |              |
|      | 37  | VR knob                           | PAC1806   |      |     |                       |              |
|      | 38  | Display window                    | PAM1668   |      |     |                       |              |
|      | 39  | FL sheet                          | PAM1673   |      |     |                       |              |
|      | 40  | Front panel 99 (AL)               | PAN1335   |      |     |                       |              |
|      | 41  | Name plate 99 (AL)                | PAN1325   |      |     |                       |              |
|      | 42  | Display panel 99 (AL)             | PAN1326   |      |     |                       |              |
|      | 43  | Side mole (L)                     | PAN1327   |      |     |                       |              |
|      | 44  | Side mole (R)                     | PAN1328   |      |     |                       |              |
|      | 45  | Step screw                        | PBA1103   |      |     |                       |              |
|      | 46  | .....                             |           |      |     |                       |              |
|      | 47  | Earth spring B                    | PBK1138   |      |     |                       |              |
|      | 48  | Earth spring C                    | PBK1143   |      |     |                       |              |
|      | 49  | Side wood (L)                     | PMM1041   |      |     |                       |              |
|      | 50  | Side wood (R)                     | PMM1042   |      |     |                       |              |
|      | 51  | Wood collar                       | PNW1238   |      |     |                       |              |
|      | 52  | LED lens                          | PNW2019   |      |     |                       |              |
|      | 53  | REC ring                          | PNW2558   |      |     |                       |              |
|      | 54  | REC lens                          | PNW2559   |      |     |                       |              |
|      | 55  | Holder                            | PNW2591   |      |     |                       |              |

NOTE: Screws adjacent to ▼ mark on the product are used for disassembly

A

A

B

B

C

C

D

D

Note) The parts with \* marking is an attached parts of No. 4.

Note : The stopper consist of the big ring part and the small ring part.  
If you stick the stopper to the leg, stick the big ring part to the front leg, and the small ring part to the rear leg.

(For the front leg)

(For the rear leg)

3.2 LOADING MECHANISM ASSY TT

A

A

B


B

C

C

D

D




# Parts List

| Mark | No. | Description              | Parts No.    | Mark | No. | Description              | Parts No.    |
|------|-----|--------------------------|--------------|------|-----|--------------------------|--------------|
|      | 1   | Lever switch (S601)      | DSK1003      |      | 51  | Pinion gear              | PNW2515      |
|      | 2   | Float screw              | PBA1027      | NSP  | 52  | Spindle D.C motor (0.3W) | PXM1033      |
|      | 3   | Rubber belt              | PEB1186      | NSP  | 53  | SERVO MECHANISM ASSY     | PXA1560      |
|      | 4   | Motor pulley             | PNW1634      |      | 54  | Stop ring                | YE20S        |
|      | 5   | Drive gear               | PNW1996      |      | 55  | Shaft holder             | PNB1382      |
|      | 6   | Timing lever             | PNW2168      |      | 56  | HEAD BOARD ASSY          | PWZ3022      |
|      | 7   | Gear pulley              | PNW1998      |      | 57  | Screw                    | BPZ26P060FMC |
|      | 8   | SW head                  | PNW1999      |      | 58  | Screw                    | IBZ30P080FCC |
|      | 9   | Float base               | PNW2563      | NSP  | 59  | MECHANISM BOARD ASSY     | PWZ3062      |
|      | 10  | Left cam                 | PNW2001      |      | 60  | Caution label            | PRW1244      |
|      | 11  | Right cam                | PNW2002      |      | 61  | Connector assy 5P        | PDE1243      |
|      | 12  | Float spring             | PBH1120      |      | 62  | Clamp spring             | PBK1139      |
|      | 13  | Lock spring              | PBH1121      |      | 63  | Spacer                   | PBF1014      |
|      | 14  | Float rubber             | PEB1014      |      | 64  | Screw                    | IPZ30P080FCC |
|      | 15  | Table rubber sheet       | PEB1181      |      |     |                          |              |
|      | 16  | Tray                     | PNW2003      |      |     |                          |              |
|      | 17  | Table guide              | PNW2004      |      |     |                          |              |
|      | 18  | Lock plate               | PNW2005      |      |     |                          |              |
|      | 19  | D.C. motor               | PXM1010      |      |     |                          |              |
|      | 20  | (0.75W, LOADING)         |              |      |     |                          |              |
|      | 20  | Float rubber             | PEB1031      |      |     |                          |              |
|      | 21  | Cord clasper             | RNH-184      |      |     |                          |              |
|      | 22  | Screw                    | BMZ26P040FMC |      |     |                          |              |
|      | 23  | Screw                    | IPZ26P060FCU |      |     |                          |              |
|      | 24  | Screw                    | IPZ20P080FMC |      |     |                          |              |
|      | 25  | Turn table assy          | PEA1165      |      |     |                          |              |
|      | 26  | Screw                    | IPZ30P080FCU |      |     |                          |              |
| NSP  | 27  | Loading base             | PNW1995      |      |     |                          |              |
| NSP  | 28  | Table shaft holder       | PXA1383      |      |     |                          |              |
|      | 29  | Turn table (AL)          | PNR1035      |      |     |                          |              |
|      | 30  | Guide shaft              | DLA1530      |      |     |                          |              |
|      | 31  | Earth spring             | PBH1196      |      |     |                          |              |
| NSP  | 32  | Earth lead unit/300V     | PDF1088      |      |     |                          |              |
|      | 33  | TAN base                 | PNB1514      |      |     |                          |              |
|      | 34  | Stopper ring             | PNM1246      |      |     |                          |              |
|      | 35  | Gear 2                   | PNW2513      |      |     |                          |              |
|      | 36  | Gear 3                   | PNW2514      |      |     |                          |              |
|      | 37  | TAN plate TT             | PNW2518      |      |     |                          |              |
|      | 38  | Mechanism chassis        | PNW2520      |      |     |                          |              |
|      | 39  | Gear 1                   | PNW2521      |      |     |                          |              |
|      | 40  | Disc table TT assy       | PEA1323      |      |     |                          |              |
|      | 41  | Carriage moter assy      | PEA1324      |      |     |                          |              |
|      | 42  | D.C motor assy (Spindle) | PEA1325      |      |     |                          |              |
|      | 43  | Pickup assy              | PEA1326      |      |     |                          |              |
|      | 44  | Screw                    | BBZ26P040FMC |      |     |                          |              |
|      | 45  | Screw                    | BBZ26P080FMC |      |     |                          |              |
|      | 46  | Screw                    | BMZ20P040FMC |      |     |                          |              |
|      | 47  | Screw                    | JFZ20P030FNI |      |     |                          |              |
|      | 48  | Washer                   | WT12D032D025 |      |     |                          |              |
| NSP  | 49  | Mirror mat               | PNM1247      |      |     |                          |              |
| NSP  | 50  | Disc table TT            | PNW2516      |      |     |                          |              |

## • How to install the disc table

- 1 Use nippers or other tool to cut the two sections marked (A) in figure 1. Then remove the spacer.
- 2 While supporting the spindle motor shaft with the stopper, put the spacer on top of the mechanism chassis and stick the disc table TT on top (takes about 9Kg pressure). Take off the spacer.



## 4. DISASSEMBLY

### 4.1 REMOVE THE TRAY PANEL

Hold the tray panel with your hands as shown in Fig. 1, and grasp the tray with your thumbs and then lift the tray panel up while pulling it toward you with the other fingers. (Fig. 2)




Fig. 1




Fig. 2

### 4.2 INSTALL THE TRAY PANEL

Align the tray panel with the grooves located at both edges of the tray. And then press it down till it stops. (Fig. 3)




Fig. 3

### 4.3 REMOVE AND SET UP THE HEAD BOARD ASSY

- ① Remove the bonnet (side wood).
- ② Remove the tray panel. (Refer to 4.1)
- ③ Remove the five screws of the front panel.




Fig. 4

- ④ Pull out the right side of the front panel to the front and remove the four screws of the board.




Fig. 5

- ⑤ Remove the fixtures of the wires connected to the board (cord holder, PCB binder).
- ⑥ Place the HEAD BOARD ASSY upright against the slit of the float base.





Fig. 6

# 5. SCHEMATIC AND PCB CONNECTION DIAGRAMS


## 5.1 OVERALL WIRING DIAGRAM



SCH-1

OVERALL WIRING  
DIAGRAM

SCH-1



NOTE FOR SCHEMATIC DIAGRAMS

Type 4A

- When ordering service parts, be sure to refer to "PARTS LIST of EXPLODED VIEWS" or "PCB PARTS LIST".
- Since these are basic circuits, some parts of them or the values of some components may be changed for improvement.
- RESISTORS:**  
Unit: k: k $\Omega$ , M: M $\Omega$ , or  $\Omega$  unless otherwise noted.  
Rated power: 1/4W, 1/6W, 1/8W, 1/10W unless otherwise noted.  
Tolerance: (F):  $\pm 1\%$ , (G):  $\pm 2\%$ , (K):  $\pm 10\%$ , (M):  $\pm 20\%$  or  $\pm 5\%$  unless otherwise noted.
- CAPACITORS:**  
Unit: p: pF or  $\mu$ F unless otherwise noted.  
Ratings: capacitor ( $\mu$ F)/ voltage (V) unless otherwise noted.  
Rated voltage: 50V except for electrolytic capacitors.
- COILS:**  
Unit: m: mH or  $\mu$ H unless otherwise noted.
- VOLTAGE AND CURRENT:**  
□ or - V :  
DC voltage (V) in PLAY mode unless otherwise noted.  
Value in ( ) is DC voltage (V) in STOP mode.  
mA or - mA :  
DC current in PLAY mode unless otherwise noted.
- OTHERS:**  
• or • : Adjusting point.  
• : Measurement point.  
• The  $\Delta$  mark found on some component parts indicates the importance of the safety factor of the parts. Therefore, when replacing, be sure to use parts of identical designation.
- SCH-□ ON THE SCHEMATIC DIAGRAM:**  
• SCH-□ indicates the drawing number of the schematic diagram. (SCH stands for schematic diagram.)

9. SWITCHES (Underline indicates switch position):


- FUNCTION BOARD ASSY**
- S701 : AUTO/MANUAL
  - S702 : WRITE [MANUAL]
  - S703 : DISPLAY OFF
  - S704 : POWER STANDBY/ON
  - S705 : INPUT SELECTOR
  - S706 : DIGITAL SYNCHRO
  - S707 : FINALIZE
  - S708 : OPEN/CLOSE ( $\Delta$ )
  - S709 : PAUSE (II)
  - S710 : PLAY ( $\blacktriangleright$ )
  - S711 : STOP ( $\blacksquare$ )
  - S712 : MANUAL/TRACK SEARCH REV ( $\blacktriangleleft$ )
  - S713 : MANUAL/TRACK SEARCH FWD ( $\blacktriangleright$ )
  - S714 : SKIP SET
  - S715 : SKIP CLEAR
  - S716 : SKIP ON/OFF
  - S717 : REC
  - S718 : REC MUTE
- SERVO UCOM BOARD ASSY**
- S201 : DIGITAL OUT ON/OFF

OVERALL WIRING  
DIAGRAM

SCH-1



## 5.2 HEAD BOARD AND PICKUP ASSY





## SCH-2

# **Voltages (V) of HEAD BOARD Assy**

**IC101 (PA4022A) [V]**

| Pin No. | MODE |       |      | Pin No. | MODE |      |      |
|---------|------|-------|------|---------|------|------|------|
|         | STOP | PLAY  | REC  |         | STOP | PLAY | REC  |
| 1       | 0.01 | —     | —0.1 | 35      | 0.6  | 0.6  | 0.8  |
| 2       | 0.02 | —0.12 | —0.4 | 36      | 0.6  | 0.8  | 0.8  |
| 3       | 0    | —0.16 | 0.0  | 37      | 1.2  | 1.2  | 1.5  |
| 4       | —4.9 | —4.9  | —4.9 | 38      | 0.1  | 0.1  | 3.1  |
| 5       | 0.0  | 0.0   | 0.0  | 39      | 5.0  | 0.0  | 0.0  |
| 6       | 0.0  | 0.0   | 0.0  | 40      | 0.0  | 0.0  | 0.0  |
| 7       | 0.0  | 0.0   | 0.0  | 41      | 0.0  | 0.0  | 0.0  |
| 8       | 0.0  | 0.0   | 0.0  | 42      | 0.0  | 0.0  | 0.0  |
| 9       | 0.0  | 0.0   | 0.0  | 43      | 0.0  | 0.0  | 0.1  |
| 10      | 0.0  | 0.0   | 0.0  | 44      | 0.0  | —0.1 | —0.1 |
| 11      | 0.0  | 0.0   | 0.0  | 45      | —4.9 | —4.9 | —4.9 |
| 12      | 0.0  | 0.0   | 0.0  | 46      | 0.0  | —0.1 | —0.1 |
| 13      | 0.0  | 0.0   | 0.0  | 47      | 0.0  | 0.0  | 0.0  |
| 14      | 0.0  | 0.0   | 0.0  | 48      | 0.0  | 0.0  | 0.0  |
| 15      | 0.0  | 0.0   | 0.0  | 49      | 0.0  | 0.0  | 0.0  |
| 16      | 0.0  | 0.0   | —    | 50      | 0.0  | 0.0  | 0.0  |
| 17      | 0.0  | 0.0   | 0.0  | 51      | 0.0  | 0.0  | 0.0  |
| 18      | 0.0  | 0.0   | 0.0  | 52      | 0.0  | —0.1 | 0.0  |
| 19      | 0.0  | 0.0   | 0.0  | 53      | 0.0  | —0.1 | —0.1 |
| 20      | 0.0  | 0.0   | 0.0  | 54      | 0.0  | 0.2  | 0.2  |
| 21      | 0.0  | 0.0   | 0.0  | 55      | 0.0  | 0.0  | 0.0  |
| 22      | 0.0  | 0.0   | 0.0  | 56      | 0.0  | 0.0  | 0.0  |
| 23      | 1.4  | 1.4   | 1.4  | 57      | 0.1  | 0.1  | 0.1  |
| 24      | 1.4  | 1.4   | 1.4  | 58      | —4.0 | —4.0 | —4.0 |
| 25      | 0.0  | 0.0   | 0.9  | 59      | —2.9 | —2.7 | —2.7 |
| 26      | 0.0  | 0.2   | 0.2  | 60      | 0.0  | 0.0  | 0.0  |
| 27      | 0.0  | 0.0   | 1.2  | 61      | 0.0  | 0.0  | 0.0  |
| 28      | 0.0  | 0.0   | 0.0  | 62      | 0.0  | 0.0  | 0.0  |
| 29      | 5.0  | 5.0   | 5.0  | 63      | 5.0  | 5.0  | 5.0  |
| 30      | 4.2  | 1.2   | 1.2  | 64      | —0.1 | 0.3  | 0.3  |
| 31      | —3.4 | —1.7  | —1.7 | 65      | 0.0  | —0.1 | 0.0  |
| 32      | 0.0  | 0.0   | 0.0  | 66      | —0.3 | 1.4  | 1.2  |
| 33      | —1.0 | 0.0   | 0.0  | 67      | 0.0  | 0.0  | 0.0  |
| 34      | 4.3  | 3.6   | 3.6  | 68      | —0.1 | 0.0  | 0.0  |

**IC102 (BA4560F) [V]**

| Pin No. | MODE |      |            |
|---------|------|------|------------|
|         | STOP | PLAY | REC        |
| 1       | 0    | 0.2  | 1.5        |
| 2       | 1.4  | 1.4  | 1.5        |
| 3       | 1.4  | 1.4  | 1.4        |
| 4       | —5.0 | —5.0 | —5.0       |
| 5       | 0    | 0    | 0          |
| 6       | 0    | 0    | 0          |
| 7       | 0    | 0    | 0.1 to 0.6 |
| 8       | 5    | 5    | 5          |

**IC202 (LA6517) [V]**

| Pin No. | MODE  |      |      |
|---------|-------|------|------|
|         | STOP  | PLAY | REC  |
| 1       | 0     | 0    | 0    |
| 2       | 9.4   | —    | —    |
| 3       | —0.4  | —0.4 | —0.4 |
| 4       | —10.0 | —    | —    |
| 5       | —0.4  | —0.4 | —0.4 |
| 6       | —0.4  | —0.4 | —0.4 |
| 7       | 0     | 0.0  | 0.0  |
| 8       | 0     | 0.0  | 0.0  |

**Q101 (2SC2412K) [V]**

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| E       | 0.6  | 0.6  | 0.8 |
| C       | —    | —    | —   |
| B       | 1.2  | 1.2  | 1.4 |

**Q106 (2SA1037K) [V]**

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| E       | 5.0  | 5.0  | 4.8 |
| C       | —    | —    | —   |
| B       | —    | —    | —   |

**Q102 (2SB1189) [V]**

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| E       | 5.0  | 5.0  | 4.5 |
| C       | 1.5  | 1.5  | 1.8 |
| B       | 4.3  | 3.8  | 3.8 |

**Q107 (2SA1461) [V]**

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| E       | —    | —    | —   |
| C       | 1.5  | 1.5  | 1.8 |
| B       | 3.0  | 3.0  | 3.0 |

**Q103 (2SA1037K) [V]**

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| E       | 5.0  | 5.0  | 4.8 |
| C       | 1.0  | 1.0  | 2.2 |
| B       | —    | —    | —   |

**Q109 (DTC114TS) [V]**

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| E       | 0.0  | —    | —   |
| C       | 0.0  | 1.1  | 1.2 |
| B       | 5.0  | 0.0  | 0.0 |

**Q104 (2SA1037K) [V]**


| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| E       | 5.0  | 5.0  | 4.8 |
| C       | 1.0  | 1.0  | 2.2 |
| B       | —    | —    | —   |

**Q111 (DTA114TK) [V]**

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| E       | 5.0  | —    | —   |
| C       | 0.0  | 0.0  | 4.4 |
| B       | 5.0  | 0.0  | 0.0 |

**Q105 (2SA1037K) [V]**


| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| E       | 5.0  | 5.0  | 4.8 |
| C       | 1.0  | 1.0  | 2.2 |
| B       | —    | —    | —   |



- The parts mounted on this PCB include necessary parts for several destinations. For further information for respective destinations, be sure to check with the schematic diagram.

## **Waveforms at HEAD BOARD ASSY**

- Measuring condition : DC input unless otherwise noted.



## **NOTE FOR PCB DIAGRAMS:**


- Part numbers in PCB diagrams match those in the schematic diagrams.
- A comparison between the main parts of PCB and schematic diagrams is shown below.

| Symbol in PCB Diagrams | Symbol in Schematic Diagrams | Part Name                |
|------------------------|------------------------------|--------------------------|
|                        |                              | Transistor               |
|                        |                              | Transistor with resistor |
|                        |                              | Field effect transistor  |
|                        |                              | Resistor array           |
|                        |                              | 3-terminal regulator     |

- This diagram is viewed from the top.
- This PCB is double sided.

S-809

TO  
AUDIO  
BOARD  
DIGITAL  
CN303




A-1305-A

05020  
TOSCI

Y22A 01

- This diagram is viewed from the gray colored foil side.
- This PCB is double sided.



is viewed from the gray colored foil side.  
double sided.





# 5.3 SERVO UCOM BOARD ASSY


## Voltages (V) of SERV

IC201 (CXA1372Q) [V]

| Pin No. | MODE | Pin No. |
|---------|------|---------|
| 1       | STOP | 25      |
| 2       | PLAY | 26      |
| 3       | REC  | 27      |
| 4       | 0.0  | 28      |
| 5       | -0.4 | 29      |
| 6       | 0.0  | 30      |
| 7       | 0.3  | 31      |
| 8       | 0.0  | 32      |
| 9       | 0.0  | 33      |
| 10      | 5.0  | 34      |
| 11      | 0.0  | 35      |
| 12      | 0.0  | 36      |
| 13      | 0.0  | 37      |
| 14      | 0.0  | 38      |
| 15      | 0.0  | 39      |
| 16      | -4.0 | 40      |
| 17      | 1.3  | 41      |
| 18      | 0.0  | 42      |
| 19      | -4.9 | 43      |
| 20      | 5.0  | 44      |
| 21      | 5.0  | 45      |
| 22      | 4.8  | 46      |
| 23      | 5.0  | 47      |
| 24      | 0.7  | 48      |

### Waveforms at SERVO UCOM BOARD ASSY

Measuring condition : DC input unless otherwise noted.




- This diagram is viewed from the pink colored foil side.
- This PCB is double sided.

#### Note:

- \* 1: Ask PIONNER subsidiaries/distributors if these parts are to be replaced or repaired.

PC



- The parts mounted on this PCB include all necessary parts for several destinations. For further information for respective destinations, be sure to check with the schematic diagram.

2) [V]

IC205 (PA9004A) [V]IC206 (CXD2500BO) [VI]IC207 (RD 1006A) (1/2)IC208 (LM2940DCT-5.0) [V]IC311 (PST529C) [V]IC204 (HD74HC4053EE) (M)IC351 (PD4591A) [V]IC352 (LC3517BML-15) (V)IC252 (UB34UG5705B) B/AIC950 (BD470-1) 115IC354 (TC7S00E) [VI]IC355 (TC7S04F) [V]IC357 (TC74HC367AF) [M]1C360 (Y193) C46AF) (1/1)ICE008 (BA 15005) B.1.Q14 (DTA124EK) (V)Q5026 (DTA18450) 5/3Q201 (DTA124ES) [M]Q202 (2SC2412K) [VT]Q203 (2SA1037K) [V]IC359 (TC7S04F) [V]

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| 1       | 0.0  | 0.0  | 0.1 |
| 2       | 0.2  | 0.3  | 0.3 |
| 3       | 0.0  | 0.0  | 0.0 |
| 4       | 4.7  | 4.7  | 4.7 |
| 5       | 5.0  | 5.0  | 5.0 |



PCB-2

PNP 1392-A

5026  
207

ASSY


B

C

D


F

F



SCH-3






SERVO UCOM BOARD ASSY

SCH-3




## 5.4 AUDIO DIGITAL BOARD, REC VR BOARD AND H.P BOARD ASSY



SCH-4

AUDIO DIGITAL BOARD ASSY,  
REC VR BOARD ASSY,  
H.P BOARD ASSY



AUDIO DIGITAL BOARD ASSY,  
REC VR BOARD ASSY,  
H.P. BOARD ASSY

**SCH-4**

# 1 Voltages (V) of AUDIO DIGITAL BOARD Assy

| IC301 (PDC019A) [V] |      |      |            | IC302 (CD74HC4046AM) [V] |      |      |     |
|---------------------|------|------|------------|--------------------------|------|------|-----|
| Pin No.             | MODE |      |            | Pin No.                  | MODE |      |     |
|                     | STOP | PLAY | REC        |                          | STOP | PLAY | REC |
| 1                   | 0.0  | 0.0  | 0.0        | 50                       | 4.9  | 4.9  | 4.9 |
| 2                   | 0.0  | 0.0  | 0.0        | 51                       | 0.0  | 0.0  | 0.0 |
| 3                   | 0.0  | 0.0  | 0.0        | 52                       | 5.0  | 5.0  | 3.9 |
| 4                   | 0.0  | 0.0  | 0.0        | 53                       | 5.0  | 5.0  | 4.1 |
| 5                   | 2.4  | 2.4  | 2.4        | 54                       | 0.0  | 0.0  | 2.3 |
| 6                   | 2.4  | 2.4  | 2.4        | 55                       | 0.0  | 0.0  | 2.3 |
| 7                   | 5.0  | 5.0  | 5.0        | 56                       | 0.0  | 0.0  | 2.4 |
| 8                   | 1.8  | 1.8  | 1.8        | 57                       | 0.0  | 0.0  | 2.5 |
| 9                   | 0.0  | 0.0  | 0.0        | 58                       | 0.0  | 0.0  | 2.5 |
| 10                  | 2.5  | 2.5  | 2.5        | 59                       | 0.0  | 0.0  | 2.5 |
| 11                  | 2.5  | 2.5  | 2.5        | 60                       | 0.0  | 0.0  | 2.4 |
| 12                  | 0.0  | 0.0  | 0.0        | 61                       | 5.0  | 5.0  | 5.0 |
| 13                  | 5.0  | 5.0  | 5.0        | 62                       | 0.0  | 0.0  | 0.0 |
| 14                  | 2.0  | 2.3  | 2.4        | 63                       | 0.0  | 0.0  | 1.4 |
| 15                  | 0.0  | 0.0  | 0.0        | 64                       | 0.0  | 0.0  | 1.3 |
| 16                  | 0.0  | 0.0  | 0.0        | 65                       | 0.0  | 0.0  | 2.4 |
| 17                  | 0.0  | 0.0  | 0.0        | 66                       | 5.0  | 5.0  | 2.0 |
| 18                  | 0.0  | 5.0  | 5.0        | 67                       | 5.0  | 5.0  | 4.1 |
| 19                  | 0.0  | 5.0  | 5.0        | 68                       | 0.0  | 0.0  | 0.8 |
| 20                  | 5.0  | 5.0  | 5.0        | 69                       | 0.0  | 0.0  | 0.8 |
| 21                  | 0.0  | 0.0  | 0.0        | 70                       | 0.0  | 0.0  | 0.0 |
| 22                  | 0.0  | 0.0  | 0.0        | 71                       | 0.0  | 0.0  | 0.7 |
| 23                  | 0.0  | 0.0  | 0.0        | 72                       | 0.0  | 0.0  | 0.0 |
| 24                  | 0.0  | 0.0  | 0.0        | 73                       | 0.0  | 0.0  | 0.0 |
| 25                  | 0.0  | 0.0  | 0.1        | 74                       | 0.0  | 0.0  | 0.0 |
| 26                  | 2.4  | 2.4  | 5.0        | 75                       | 5.0  | 5.0  | 5.0 |
| 27                  | 2.4  | 2.4  | 0.0 to 3.4 | 76                       | 2.6  | 0.0  | 2.5 |
| 28                  | 2.4  | 2.4  | 0.0 to 2.4 | 77                       | 2.7  | 5.0  | 2.7 |
|                     |      |      | 0.0 to 2.4 | 78                       | 2.4  | 0.0  | 2.4 |
| 29                  | 5.0  | 5.0  | 5.0        | 80                       | 0.0  | 5.0  | 0.0 |
| 30                  | 0.0  | 1.6  | 0.0        | 81                       | 0.0  | 0.0  | 0.0 |
| 31                  | 2.0  | 2.0  | 2.2        | 82                       | 0.0  | 0.0  | 0.0 |
| 32                  | 2.5  | 0.0  | 2.5        | 83                       | 5.0  | 0.0  | 5.0 |
| 33                  | 0.0  | 0.0  | 0.6        | 84                       | 0.0  | 0.0  | 4.9 |
| 34                  | 0.0  | 0.6  | 0.6        | 85                       | 0.0  | 0.0  | 3.1 |
| 35                  | 2.0  | 2.0  | 2.0        | 86                       | 0.0  | 0.0  | 0.6 |
| 36                  | 0.0  | 2.5  | 2.5        | 87                       | 0.0  | 0.0  | 0.7 |
| 37                  | 0.0  | 5.0  | 0.0        | 88                       | 0.0  | 0.0  | 1.9 |
| 38                  | 2.2  | 2.2  | 2.2        | 89                       | 5.0  | 5.0  | 5.0 |
| 39                  | 2.7  | 2.7  | 2.6        | 90                       | 0.0  | 0.0  | 0.0 |
| 40                  | 0.0  | 0.0  | 0.0        | 91                       | 1.4  | 5.0  | 1.3 |
| 41                  | 5.0  | 5.0  | 5.0        | 92                       | 5.0  | 5.0  | 5.0 |
| 42                  | 2.0  | 2.0  | 2.2        | 93                       | 5.0  | 4.9  | 4.9 |
| 43                  | 2.0  | 2.2  | 2.2        | 94                       | 0.2  | 0.0  | 0.3 |
| 44                  | 0.0  | 2.4  | 0.0        | 95                       | 0.0  | 0.0  | 0.0 |
| 45                  | 2.0  | 2.0  | 2.0        | 96                       | 0.0  | 0.0  | 0.0 |
| 46                  | 2.5  | 2.5  | 2.5        | 97                       | 4.8  | 4.8  | 4.8 |
| 47                  | 2.4  | 2.4  | 2.4        | 98                       | 4.9  | 4.8  | 4.8 |
| 48                  | 2.0  | 2.0  | 2.1        | 99                       | 0.6  | 2.3  | 2.3 |
| 49                  | 0.0  | 0.0  | 0.0        | 100                      | 5.0  | 5.0  | 5.0 |

| IC304 (MB81C4256A) [V] |      |      |      |
|------------------------|------|------|------|
| Pin No.                | MODE | STOP | PLAY |
| 1                      | 0.0  | 0.0  | 1.4  |
| 2                      | 0.0  | 0.0  | 1.4  |
| 3                      | 5.0  | 5.0  | 4.1  |
| 4                      | 5.0  | 5.0  | 2.0  |
| 5                      | 0.0  | 0.0  | 2.5  |
| 6                      |      |      |      |
| 7                      |      |      |      |
| 8                      |      |      |      |
| 9                      | 0.0  | 0.0  | 1.3  |
| 10                     | 0.0  | 0.0  | 1.4  |
| 11                     | 0.0  | 0.0  | 2.5  |
| 12                     | 0.0  | 0.0  | 2.5  |
| 13                     | 5.0  | 5.0  | 5.0  |
| 14                     | 0.0  | 0.0  | 2.5  |
| 15                     | 0.0  | 0.0  | 2.5  |
| 16                     | 0.0  | 0.0  | 2.5  |
| 17                     | 0.0  | 0.0  | 2.5  |
| 18                     | 0.0  | 0.0  | 2.5  |
| 19                     |      |      |      |
| 20                     |      |      |      |
| 21                     | 5.0  | 5.0  | 4.1  |
| 22                     | 5.0  | 5.0  | 3.9  |
| 23                     | 0.0  | 0.0  | 0.9  |
| 24                     | 0.0  | 0.0  | 0.8  |
| 25                     | 0.0  | 0.0  | 0.8  |
| 26                     | 0.0  | 0.0  | 0.0  |

| IC306 (PDC020A) [V] |      |      |      |
|---------------------|------|------|------|
| Pin No.             | MODE | STOP | PLAY |
| 1                   | 0.0  | 0.0  | 0.0  |
| 2                   | 4.9  | 4.9  | 4.9  |
| 3                   | 2.2  | 2.2  | 2.3  |
| 4                   | 0.0  | 0.0  | 0.0  |
| 5                   | 0.0  | 0.0  | 0.0  |
| 6                   | 0.0  | 0.0  | 0.0  |
| 7                   | 5.0  | 5.0  | 5.0  |
| 8                   | 0.0  | 0.0  | 0.0  |
| 9                   | 0.0  | 0.0  | 0.0  |
| 10                  | 0.0  | 0.0  | 0.0  |
| 11                  | 0.0  | 0.0  | 0.0  |
| 12                  | 5.0  | 5.0  | 5.0  |
| 13                  | 4.9  | 4.8  | 4.8  |
| 14                  | 0.6  | 1.8  | 2.3  |
| 15                  | 5.0  | 5.0  | 5.0  |
| 16                  | 0.0  | 5.0  | 0.0  |
| 17                  | 5.0  | 5.0  | 5.0  |
| 18                  | 0.0  | 0.0  | 0.0  |
| 19                  | 5.0  | 5.0  | 5.0  |
| 20                  | 0.0  | 0.0  | 0.0  |
| 21                  | 0.0  | 0.0  | 0.0  |
| 22                  | 0.0  | 0.0  | 0.0  |
| 23                  | 0.0  | 0.0  | 0.0  |
| 24                  | 0.0  | 0.0  | 0.0  |

| IC307 (TC74HC04AF) [V] |      |      |      |
|------------------------|------|------|------|
| Pin No.                | MODE | STOP | PLAY |
| 1                      | 2.5  | 2.5  | 2.5  |
| 2                      | 2.5  | 2.5  | 2.5  |
| 3                      | 2.5  | 2.6  | 2.6  |
| 4                      | 3.1  | 3.1  | 3.1  |
| 5                      | 2.2  | 2.0  | 2.0  |
| 6                      | 2.6  | 2.6  | 2.6  |
| 7                      | 0.0  | 0.0  | 0.0  |
| 8                      | 2.4  | 2.4  | 2.4  |
| 9                      | 2.6  | 2.6  | 2.6  |
| 10                     | 2.4  | 2.4  | 2.4  |
| 11                     | 2.6  | 2.6  | 2.6  |
| 12                     | 2.4  | 2.4  | 2.4  |
| 13                     | 2.6  | 2.6  | 2.6  |
| 14                     | 5.0  | 5.0  | 5.0  |

| IC308 (TC74HC04AF) [V] |      |      |      |
|------------------------|------|------|------|
| Pin No.                | MODE | STOP | PLAY |
| 1                      | 2.2  | 2.2  | 2.3  |
| 2                      | 2.1  | 2.1  | 2.1  |
| 3                      | 0.0  | 0.0  | 0.0  |
| 4                      | 4.3  | 4.3  | 4.3  |
| 5                      | 2.0  | 2.2  | 2.3  |
| 6                      | 2.0  | 2.1  | 2.1  |
| 7                      | 0.0  | 0.0  | 0.0  |
| 8                      | 2.2  | 2.2  | 2.3  |
| 9                      | 2.1  | 2.2  | 2.2  |
| 10                     | 2.0  | —    | —    |
| 11                     | 1.9  | —    | —    |
| 12                     | 1.4  | —    | —    |
| 13                     | 2.0  | 2.2  | 2.2  |
| 14                     | 4.2  | 4.3  | 4.3  |

| IC309 (TC74HC00AF) [V] |      |      |      |
|------------------------|------|------|------|
| Pin No.                | MODE | STOP | PLAY |
| 1                      | 2.0  | 2.2  | 2.2  |
| 2                      | 4.8  | 5.0  | 5.0  |
| 3                      | 1.5  | 2.0  | 2.0  |
| 4                      | 0.9  | 1.8  | 2.1  |
| 5                      | 4.2  | 4.3  | 4.3  |
| 6                      | 2.2  | 2.3  | 2.3  |
| 7                      | 0.0  | 0.0  | 0.0  |
| 8                      | 4.2  | 4.3  | 4.3  |
| 9                      | 0.0  | 0.0  | 0.0  |
| 10                     | 0.0  | 0.0  | 0.0  |
| 11                     | 0.0  | 0.0  | 0.0  |
| 12                     | 4.8  | 5.0  | 4.9  |
| 13                     | 4.8  | 5.0  | 4.9  |
| 14                     | 4.2  | 4.3  | 4.3  |

| IC310 (TC74HC00AF) [V] |      |      |      |
|------------------------|------|------|------|
| Pin No.                | MODE | STOP | PLAY |
| 1                      | 5.0  | 5.0  | 3.0  |
| 2                      | 5.0  | 5.0  | 4.8  |
| 3                      | 0.0  | 0.0  | 2.0  |
| 4                      | 0.0  | 0.0  | 2.0  |
| 5                      | 0.0  | 0.0  | 0.0  |
| 6                      | 5.0  | 5.0  | 5.0  |
| 7                      | 0.0  | 0.0  | 0.0  |
| 8                      | 5.0  | 5.0  | 4.6  |
| 9                      | 0.0  | 0.0  | 0.6  |
| 10                     | 0.0  | 0.0  | 1.9  |
| 11                     | 5.0  | 5.0  | 3.0  |
| 12                     | 0.0  | 0.0  | 2.0  |
| 13                     | 5.0  | 5.0  | 5.0  |
| 14                     | 5.0  | 5.0  | 5.0  |

| IC312 (TC7S14F) [V] |      |      |      |
|---------------------|------|------|------|
| Pin No.             | MODE | STOP | PLAY |
| 1                   | 0.0  | 0.0  | 0.0  |
| 2                   | 3.1  | 3.1  | 3.1  |
| 3                   | 0.0  | 0.0  | 0.0  |
| 4                   | 0.0  | 0.0  | 0.0  |
| 5                   | 5.0  | 5.0  | 5.0  |


| IC401 (PD7009A) [V] |      |      |      |
|---------------------|------|------|------|
| Pin No.             | MODE | STOP | PLAY |
| 1                   | 0.0  | 1.6  | 2.4  |
| 2                   | 2.1  | 2.1  | 2.2  |
| 3                   | 4.9  | 5.0  | 5.0  |
| 4                   | 4.8  | 4.9  | 4.9  |
| 5                   | 4.8  | 4.9  | 4.9  |
| 6                   | 2.0  | 2.1  | 2.2  |
| 7                   | 2.8  | 2.8  | 2.8  |
| 8                   | 0.0  | 0.0  | 0.0  |
| 9                   | 2.1  | 2.1  | 2.2  |
| 10                  | 4.8  | 4.9  | 4.9  |
| 11                  | 4.8  | 4.9  | 4.9  |
| 12                  | 4.8  | 4.9  | 4.9  |
| 13                  | 4.8  | 4.9  | 4.9  |
| 14                  | 4.9  | 4.9  | 4.9  |
| 15                  | 4.9  | 5.0  | 5.0  |
| 16                  | 0.0  | 0.0  | 0.0  |
| 17                  | 4.8  | 4.9  | 4.9  |
| 18                  | 0.0  | 0.0  | 0.0  |
| 19                  | 0.0  | 0.0  | 0.0  |
| 20                  | 4.8  | 4.9  | 4.9  |
| 21                  | 0.0  | 0.0  | 0.0  |
| 22                  | 4.9  | 5.0  | 5.0  |
| 23                  | 0.0  | 2.1  | 2.1  |
| 24                  | 0.0  | 2.1  | 2.1  |
| 25                  | 2.5  | 2.5  | 2.5  |
| 26                  | 2.0  | 2.0  | 2.0  |
| 27                  | 4.8  | 4.9  | 4.9  |
| 28                  | 2.5  | 2.5  | 2.5  |

| IC402 (PD2028BS) [V] |      |      |      |
|----------------------|------|------|------|
| Pin No.              | MODE | STOP | PLAY |
| 1                    | 0.0  | 0.0  | 0.0  |
| 2                    | 2.4  | 2.4  | 2.4  |
| 3                    | 2.2  | 2.2  | 2.2  |
| 4                    | 0.0  | 0.0  | 0.0  |
| 5                    | 5.0  | 5.0  | 5.0  |
| 6                    | 5.0  | 5.0  | 5.0  |
| 7                    | 2.3  | 2.3  | 2.3  |
| 8                    | 2.3  | 2.3  | 2.3  |
| 9                    | 0.0  | 0.0  | 0.0  |
| 10                   | 5.0  | 5.0  | 5.0  |
| 11                   | 0.0  | 0.0  | 0.0  |
| 12                   | 2.2  | 2.2  | 2.2  |
| 13                   | 2.4  | 2.4  | 2.4  |
| 14                   | 0.0  | 0.0  | 0.0  |
| 15                   | 5.0  | 5.0  | 5.0  |
| 16                   | 5.0  | 5.0  | 5.0  |
| 17                   | 4.9  | 4.9  | 4.9  |
| 18                   | 5.0  | 5.0  | 5.0  |
| 19                   | 2.5  | 2.5  | 2.5  |
| 20                   | 2.1  | 2.1  | 2.1  |
| 21                   | 0.0  | 2.1  | 0.8  |
| 22                   | 0.0  | 2.1  | 0.8  |
| 23                   | 0.0  | 0.0  | 0.0  |
| 24                   | 0.0  | 0.0  | 0.0  |
| 25                   | 5.0  | 5.0  | 5.0  |
| 26                   | 2.4  | 2.4  | 2.5  |
| 27                   | 0.0  | 0.0  | 0.0  |
| 28                   | 5.0  | 5.0  | 5.0  |

| IC403 (PD2028BS) [V] |      |      |      |
|----------------------|------|------|------|
| Pin No.              | MODE | STOP | PLAY |
| 1                    | 0.0  | 0.0  | 0.0  |
| 2                    | 2.4  | 2.4  | 2.4  |
| 3                    | 2.2  | 2.2  | 2.2  |
| 4                    | 0.0  | 0.0  | 0.0  |
| 5                    | 5.0  | 5.0  | 5.0  |
| 6                    | 5.0  | 5.0  | 5.0  |
| 7                    | 2.3  | 2.3  | 2.3  |
| 8                    | 2.3  | 2.3  | 2.3  |
| 9                    | 0.0  | 0.0  | 0.0  |
| 10                   | 5.0  | 5.0  | 5.0  |
| 11                   | 0.0  | 0.0  | 0.0  |
| 12                   | 2.2  | 2.2  | 2.2  |
| 13                   | 2.4  | 2.4  | 2.4  |
| 14                   | 0.0  | 0.0  | 0.0  |
| 15                   | 5.0  | 5.0  | 5.0  |
| 16                   | 5.0  | 5.0  | 5.0  |
| 17                   | 4.9  | 4.9  | 4.9  |
| 18                   | 5.0  | 5.0  | 5.0  |
| 19                   | 2.5  | 2.5  | 2.5  |
| 20                   | 2.1  | 2.1  | 2.1  |
| 21                   | 0.0  | 2.1  | 0.8  |
| 22                   | 0.0  | 2.1  | 0.8  |
| 23                   | 0.0  | 0.0  | 0.0  |
| 24                   | 0.0  | 0.0  | 0.0  |
| 25                   | 5.0  | 5.0  | 5.0  |
| 26                   | 2.4  | 2.4  | 2.5  |
| 27                   | 0.0  | 0.0  | 0.0  |
| 28                   | 5.0  | 5.0  | 5.0  |

- This diagram is viewed from the pink colored foil side.
- This PCB is double sided.

- Waveforms at AUDIO DIGITAL BOARD ASSY
- Measuring condition : DC input unless otherwise noted.





IC403 (PD2028BS) [V]

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| 1       | 0.0  | 0.0  | 0.0 |
| 2       | 2.4  | 2.4  | 2.4 |
| 3       | 2.2  | 2.2  | 2.2 |
| 4       | 0.0  | 0.0  | 0.0 |
| 5       | 5.0  | 5.0  | 5.0 |
| 6       | 5.0  | 5.0  | 5.0 |
| 7       | 2.3  | 2.3  | 2.2 |
| 8       | 2.3  | 2.3  | 2.2 |
| 9       | 0.0  | 0.0  | 0.0 |
| 10      | 5.0  | 5.0  | 5.0 |
| 11      | 0.0  | 0.0  | 0.0 |
| 12      | 2.2  | 2.2  | 2.2 |
| 13      | 2.4  | 2.4  | 2.4 |
| 14      | 0.0  | 0.0  | 0.0 |
| 15      | 5.0  | 5.0  | 5.0 |
| 16      | 5.0  | 5.0  | 5.0 |
| 17      | 4.9  | 4.9  | 4.9 |
| 18      | 5.0  | 0.0  | 0.0 |
| 19      | 2.5  | 2.5  | 2.5 |
| 20      | 2.1  | 2.1  | 2.1 |
| 21      | 0.0  | 2.1  | 0.8 |
| 22      | 0.0  | 2.1  | 0.8 |
| 23      | 0.0  | 0.0  | 0.0 |
| 24      | 0.0  | 0.0  | 0.0 |
| 25      | 5.0  | 0.0  | 0.0 |
| 26      | 2.4  | 2.4  | 2.5 |
| 27      | 0.0  | 0.0  | 0.0 |
| 28      | 5.0  | 5.0  | 5.0 |

IC404 (NJM5532MD) [V]

| Pin No. | MODE  |       |       |
|---------|-------|-------|-------|
|         | STOP  | PLAY  | REC   |
| 1       | 0.0   | 0.0   | 0.0   |
| 2       | 1.2   | 1.2   | 1.2   |
| 3       | 1.2   | 1.2   | 1.2   |
| 4       | -12.1 | -12.1 | -12.1 |
| 5       | 0.0   | 0.0   | 0.0   |
| 6       | 0.0   | 0.0   | 0.0   |
| 7       | 0.0   | 0.0   | 0.0   |
| 8       | 11.9  | 11.9  | 11.9  |

IC405 (NJM5532MD) [V]

| Pin No. | MODE  |       |       |
|---------|-------|-------|-------|
|         | STOP  | PLAY  | REC   |
| 1       | 0.0   | 0.0   | 0.0   |
| 2       | 1.2   | 1.2   | 1.2   |
| 3       | 1.2   | 1.2   | 1.2   |
| 4       | -12.1 | -12.1 | -12.1 |
| 5       | 0.0   | 0.0   | 0.0   |
| 6       | 0.0   | 0.0   | 0.0   |
| 7       | 0.0   | 0.0   | 0.0   |
| 8       | 11.9  | 11.9  | 11.9  |

IC406 (M5218AFP) [V]

| Pin No. | MODE  |       |       |
|---------|-------|-------|-------|
|         | STOP  | PLAY  | REC   |
| 1       | -12.1 | -12.1 | -12.1 |
| 2       | 0.0   | 0.0   | 0.0   |
| 3       | 0.0   | 0.0   | 0.0   |
| 4       | -12.1 | -12.1 | -12.1 |
| 5       | 0.0   | 0.0   | 0.0   |
| 6       | 0.0   | 0.0   | 0.0   |
| 7       | 0.0   | 0.0   | 0.0   |
| 8       | 11.9  | 11.9  | 11.9  |

IC801 (AK5340-VS) [V]

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| 1       | 2.5  | 2.5  | 2.5 |
| 2       | 2.5  | 2.5  | 2.5 |
| 3       | 5.0  | 5.0  | 2.4 |
| 4       | 5.0  | 5.0  | 0.0 |
| 5       | 0.0  | 0.0  | 0.0 |
| 6       | 0.0  | 0.0  | 0.0 |
| 7       | 0.0  | 0.0  | 0.0 |
| 8       | 0.0  | 0.0  | 0.0 |
| 9       | 0.0  | 0.0  | 0.0 |
| 10      | 5.0  | 5.0  | 0.0 |
| 11      | 0.0  | 0.0  | 0.0 |
| 12      | 5.0  | 5.0  | 5.0 |
| 13      | 0.0  | 0.0  | 0.0 |
| 14      | 2.5  | 2.5  | 2.5 |
| 15      | 2.0  | 2.0  | 2.2 |
| 16      | 0.0  | 0.0  | 2.5 |
| 17      | 5.0  | 5.0  | 5.0 |
| 18      | 5.0  | 5.0  | 5.0 |
| 19      | 0.0  | 0.0  | 0.0 |
| 20      | 2.1  | 2.1  | 2.1 |
| 21      | 0.0  | 0.0  | 0.0 |
| 22      | 0.0  | 0.0  | 0.0 |
| 23      | 0.0  | 0.0  | 0.0 |
| 24      | 5.0  | 5.0  | 5.0 |
| 25      | 0.0  | 0.0  | 0.0 |
| 26      | 5.0  | 5.0  | 2.4 |
| 27      | 2.5  | 2.5  | 2.5 |
| 28      | 2.5  | 2.5  | 2.5 |

IC803 (NJM4580D) [V]

| Pin No. | MODE  |       |       |
|---------|-------|-------|-------|
|         | STOP  | PLAY  | REC   |
| 1       | 0.0   | 0.0   | 0.0   |
| 2       | 0.0   | 0.0   | 0.0   |
| 3       | 0.0   | 0.0   | 0.0   |
| 4       | -12.0 | -12.0 | -12.0 |
| 5       | 0.0   | 0.0   | 0.0   |
| 6       | 0.0   | 0.0   | 0.0   |
| 7       | 0.0   | 0.0   | 0.0   |
| 8       | 11.8  | 11.8  | 11.8  |

IC804 (NJM4580D) [V]

| Pin No. | MODE  |       |       |
|---------|-------|-------|-------|
|         | STOP  | PLAY  | REC   |
| 1       | 0.0   | 0.0   | 0.0   |
| 2       | 0.0   | 0.0   | 0.0   |
| 3       | 0.0   | 0.0   | 0.0   |
| 4       | -12.0 | -12.0 | -12.0 |
| 5       | 0.0   | 0.0   | 0.0   |
| 6       | 0.0   | 0.0   | 0.0   |
| 7       | 0.0   | 0.0   | 0.0   |
| 8       | 11.8  | 11.8  | 11.8  |

Q301 (DTA114TS) [V]

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| E       | 5.0  | 5.0  | 5.0 |
| C       | 0.5  | 0.4  | 0.4 |
| B       | 5.0  | 5.0  | 5.0 |

Q302 (DTC124EK) [V]

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| E       | 0.0  | 0.0  | 0.0 |
| C       | 5.0  | 5.0  | 5.0 |
| B       | 0.0  | 0.0  | 0.0 |

Q303 (DTA114TS) [V]

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| E       | 5.0  | 5.0  | 5.0 |
| C       | 0.9  | 0.8  | 0.8 |
| B       | 5.0  | 5.0  | 5.0 |

Q304 (DTC114EK) [V]

| Pin No. | MODE |      |     |
|---------|------|------|-----|
|         | STOP | PLAY | REC |
| E       | 0.0  | 0.0  | 0.0 |
| C       | 2.0  | —    | —   |
| B       | 0.2  | -0.1 | 0.0 |

Q401 (DTC124ES) [V]

| Pin No. | MODE  |       |       |
|---------|-------|-------|-------|
|         | STOP  | PLAY  | REC   |
| E       | -12.1 | -12.1 | -12.1 |
| C       | 1.4   | -12.1 | -12.1 |
| B       | -12.1 | 2.0   | 2.0   |

Q402 (DTA124ES) [V]

| Pin No. | MODE  |      |     |
|---------|-------|------|-----|
|         | STOP  | PLAY | REC |
| E       | 5.0   | 5.0  | 5.0 |
| C       | -12.1 | 5.0  | 5.0 |
| B       | 5.0   | 3.6  | 3.6 |

Q403 (DTA124ES) [V]

| Pin No. | MODE  |      |     |
|---------|-------|------|-----|
|         | STOP  | PLAY | REC |
| E       | 5.0   | 5.0  | 5.0 |
| C       | -12.1 | 5.0  | 5.0 |
| B       | 5.0   | 0.2  | 0.2 |

Q404 (DTA124ES) [V]

| Pin No. | MODE  |      |     |
|---------|-------|------|-----|
|         | STOP  | PLAY | REC |
| E       | 5.0   | 5.0  | 5.0 |
| C       | -12.1 | 5.0  | 5.0 |
| B       | 5.0   | 0.2  | 0.2 |

Q405 (DTC124ES) [V]

| Pin No. | MODE  |       |       |
|---------|-------|-------|-------|
|         | STOP  | PLAY  | REC   |
| E       | -12.1 | -12.1 | -12.1 |
| C       | 1.1   | -12.1 | -12.1 |
| B       | -12.1 | 3.7   | 3.7   |

Q406 (DTC124ES) [V]

| Pin No. | MODE  |       |       |
|---------|-------|-------|-------|
|         | STOP  | PLAY  | REC   |
| E       | -12.1 | -12.1 | -12.1 |
| C       | 1.1   | -12.1 | -12.1 |
| B       | -12.1 | 3.7   | 3.7   |

Q408 (2SD2114K) [V]


| Pin No. | MODE |      |      |
|---------|------|------|------|
|         | STOP | PLAY | REC  |
| E       | 0.0  | 0.0  | 0.0  |
| C       | 0.0  | 0.0  | 0.0  |
| B       | 0.6  | -0.7 | -0.1 |

Q410 (2SD2114K) [V]


| Pin No. | MODE |      |      |
|---------|------|------|------|
|         | STOP | PLAY | REC  |
| E       | 0.0  | 0.0  | 0.0  |
| C       | 0.0  | 0.0  | 0.0  |
| B       | 0.6  | -0.8 | -0.2 |

- The parts mounted on this PCB include all necessary parts for several destinations. For further information for respective destinations, be sure to check with the schematic diagram.

PCB-3



REC VR BOARD ASSY



TO SERVO UCOM BOARD ASSY J208

IC405 8040 SIP0

IC403

IC312

IC303

Q301

S0E0

IC306

IC310

IC308

IC301

IC302


IC304

IC803

IC804

IC801

H.P. BOARD ASSY




VR401


TO SERVO UCOM BOARD ASSY J209




TO SERVO UCOM BOARD ASSY  
CN205 (→SCH-3)



FUNCTION BOARD ASSY (2/2)  
(PWZ3042)



CAUTION: FOR CONTINUED PROTECTION AGAINST  
RISK OF FIRE, REPLACE ONLY WITH SAME  
TYPE No. ICP-N10, MFD BY ROHM CO., LTD.  
FOR IC11, IC13 AND IC15.




SCH-5

FUNCTION BOARD ASSY,  
POWER A BOARD ASSY,  
POWER B BOARD ASSY

SCH-5

- **This diagram is viewed from the mounted parts side.**

- The parts mounted on this PCB include all necessary parts for several destinations. For further information for respective destinations, be sure to check with the schematic diagram.



## 6. PCB PARTS LIST

### NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The  $\Delta$  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47K ohm (tolerance is shown by J=5%, and K=10%).

560  $\Omega$   $\rightarrow 56 \times 10^1 \rightarrow 561$  .....RD1/8PM  $\boxed{561} J$

47 k $\Omega$   $\rightarrow 47 \times 10^3 \rightarrow 473$  .....RD1/4PS  $\boxed{473} J$

0.5  $\Omega$   $\rightarrow 0R5$  .....RN2H  $\boxed{0R5} K$

1  $\Omega$   $\rightarrow 010$  .....RS1P  $\boxed{010} K$

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62 k $\Omega$   $\rightarrow 562 \times 10^1 \rightarrow 5621$  .....RN1/4PC  $\boxed{5621} F$

### ■ LIST OF WHOLE PCB ASSEMBLIES

| Mark | PCB Assemblies             | Part No.  |           |            | Remarks |
|------|----------------------------|-----------|-----------|------------|---------|
|      |                            | PDR-99/KU | PDR-05/KU | PDR-05/ME8 |         |
| NSP  | MOTHER BOARD ASSY          | PWM1973   | PWM1971   | PWM1972    |         |
|      | — HEAD BOARD ASSY          | PWZ3022   | PWZ3022   | PWZ3022    |         |
|      | — SERVO UCOM BOARD ASSY    | PWZ3027   | PWZ3029   | PWZ3028    |         |
|      | — AUDIO DIGITAL BOARD ASSY | PWZ3033   | PWZ3031   | PWZ3032    |         |
|      | — REC VR BOARD ASSY        | PWZ3034   | PWZ3034   | PWZ3034    |         |
| NSP  | — H. P BOARD ASSY          | PWZ3038   | PWZ3038   | PWZ3038    |         |
| NSP  | — MECHANISM BOARD ASSY     | PWZ3062   | PWZ3062   | PWZ3062    |         |
| NSP  | FRONT BOARD ASSY           | PWX1416   | PWX1414   | PWX1415    |         |
|      | — FUNCTION BOARD ASSY      | PWZ3042   | PWZ3042   | PWZ3042    |         |
|      | — POWER A BOARD ASSY       | PWZ3049   | PWZ3047   | PWZ3048    |         |
|      | — POWER B BOARD ASSY       | PWZ3053   | PWZ3051   | PWZ3052    |         |

### ■ CONTRAST OF PCB ASSEMBLIES

#### SERVO UCOM BOARD ASSY

PWZ3027, PWZ3029 and PWZ3028 have the same construction except for the following:

| Mark | Symbol & Description                    | Part No.   |  |  | Remarks |
|------|---|--|--|--|---------|
|      |   | PWZ3027  | PWZ3029  | PWZ3028  |         |
|      | IC352<br>C5001<br>J221<br>R5050<br>S201 | LC3517BML-15<br>Not Used<br>Not Used<br>RS1/10S000J<br>PSH1010 | LH5116NA-10<br>Not Used<br>Not Used<br>RS1/10S000J<br>Not Used | LC3517BML-15<br>CQMA104J50<br>XDF-535<br>Not Used<br>PSH1010 |         |

#### POWER A BOARD ASSY

PWZ3049, PWZ3047 and PWZ3048 have the same construction except for the following:

| Mark | Symbol & Description | Part No.               |                          |                        | Remarks                                  |
|------|----------------------|------------------------|--------------------------|------------------------|--|
|      |                      | PWZ3049                | PWZ3047                  | PWZ3048                |  |
|      | C906<br>C911         | PCH1121 *<br>PCH1122 * | CEAS222M16<br>CEAS102M16 | PCH1121 *<br>PCH1122 * | * 2200 $\mu$ F/16V<br>* 1000 $\mu$ F/16V |



## POWER B BOARD ASSY

PWZ3053, PWZ3051 and PWZ3052 have the same construction except for the following:

| Mark | Symbol & Description   | Part No.                            |  |                                     | Remarks   |
|------|------------------------|-------------------------------------|--|-------------------------------------|---|
|      |                        | PWZ3053                             | PWZ3051                                | PWZ3052                             |   |
|      | C28, C29<br>C52<br>C54 | VCH1116 *<br>PCH1126 *<br>PCH1124 * | CEAS471M10<br>CEAS101M35<br>CEAS470M35 | VCH1116 *<br>PCH1126 *<br>PCH1124 * | * 470 $\mu$ F/10V<br>* 2200 $\mu$ F/25V<br>* 47 $\mu$ F/50V |

## AUDIO DIGITAL BOARD ASSY

PWZ3033, PWZ3031 and PWZ3032 have the same construction except for the following:

| Mark | Symbol & Description  | Part No.  |  |   | Remarks            |
|------|---|---|--|---|--------------------|
|      |   | PWZ3033   | PWZ3031  | PWZ3032   |                    |
|      | IC401<br>IC402, IC403<br>C404, C409-C412, C417, C418, C421,<br>C425, C426, C430<br>C443, C444<br>C451, C452                     | PD7009A<br>PD2028B(S)<br>VCH1116 *  | SM5813AP<br>PD2028B<br>CEAS471M6R3   | PD7009A<br>PD2028B(S)<br>VCH1116 *  | * 470 $\mu$ F/16V  |
|      | C457, C458, C805, C806, C811-C814,<br>C842-C844, C848<br>C459, C460, C832<br>C472, C473<br>C817, C818, C833, C835<br>R490, R502 | CEZA470M16<br>CFTXA102J50<br><br>CEZA220M50<br><br>CEZA4R7M50<br>PCH1122 *<br>CEZA100M50<br>RS1/10S000J | CEAS470M16<br>CKSQYB102K50<br><br>CEAS220M50<br><br>CEAS4R7M50<br>CEAS222M16<br>CEAS100M50<br>Not Used | CEZA470M16<br>CFTXA102J50<br><br>CEZA220M50<br><br>CEZA4R7M50<br>PCH1122 *<br>CEZA100M50<br>RS1/10S000J | * 1000 $\mu$ F/16V |
|      | R492, R493  | Not Used  | RS1/10S000J  | Not Used  |                    |

## ■ PARTS LIST FOR PDR-99/KU

## OTHERS

## SERVO UCOM BOARD ASSY

**Note:**  
\* 1: Ask PIONNER subsidiaries/distributors if these parts are to be replaced or repaired.

## SEMICONDUCTORS

|                     |              |
|---------------------|--------------|
| IC5008              | BA4560F      |
| IC360               | * 1          |
| IC201               | CXA1372Q     |
| IC206               | CXD2500BQ    |
| IC204, IC5024       | HD74HC4053FP |
| IC353               | HD74HC573FP  |
| IC352               | LC3517BML-15 |
| IC208               | LM2940CT-5.0 |
| IC205               | PA9004A      |
| IC356               | PD4584A      |
| IC351               | PD4591A      |
| IC207               | PDJ006A      |
| IC311               | PST529C      |
| IC361               | PST572E      |
| IC357, IC358        | TC74HC367AF  |
| IC354               | TC7S00F      |
| IC355, IC359, IC362 | TC7S04F      |
| IC363               | TC7S14F      |
| Q203                | 2SA1037K     |
| Q202                | 2SC2412K     |
| Q14                 | DTA124EK     |
| Q201, Q5026         | DTA124ES     |
| Q13                 | DTC114TK     |
| Q208                | DTC114TS     |
| D219-D222, D353     | ISS133X      |

| Mark                       | No.                                 | Description | Parts No.    |
|----------------------------|-------------------------------------|-------------|--------------|
|                            | D354                                |             | DA114        |
|                            | D206                                |             | DA204K       |
|                            | D1351                               |             | DAN202K      |
|                            | D210                                |             | DAP202K      |
|                            | D202, D205                          |             | MTZJ3.9BX    |
| <b>COILS AND FILTERS</b>   |                                     |             |              |
|                            | L201                                |             | PTL1014      |
| <b>SWITCHES AND RELAYS</b> |                                     |             |              |
|                            | S201                                |             | PSH1010      |
| <b>CAPACITORS</b>          |                                     |             |              |
|                            | C291                                |             | CCSQCH100D50 |
|                            | C1221, C1308, C284, C295, C298      |             | CCSQCH101J50 |
|                            | C247-C257                           |             | CCSQCH121J50 |
|                            | C355, C356                          |             | CCSQCH150J50 |
|                            | C282                                |             | CCSRCH101J50 |
|                            | C12                                 |             | CCSRCH270J50 |
|                            | C278                                |             | CEAS010M50   |
|                            | C241                                |             | CEAS100M50   |
|                            | C209, C212, C290                    |             | CEAS101M6R3  |
|                            | C1302, C264, C271                   |             | CEAS2R2M50   |
|                            | C205, C235-C238, C293, C5016        |             | CEAS470M10   |
|                            | C5018                               |             | CEAS470M10   |
|                            | C240                                |             | CEAS471M10   |
|                            | C351, C358                          |             | CEAS471M6R3  |
|                            | C203, C207                          |             | CEAS4R7M50   |
|                            | C288                                |             | CEASR47M50   |
|                            | C201, C202, C204, C206, C274, C1310 |             | CKSQYB104K25 |
|                            | C5004                               |             | CKSQYB222K50 |
|                            | C1309                               |             | CKSQYB272K50 |
|                            | C5013                               |             | CKSQYB333K50 |
|                            | C1304, C5005-C5008                  |             | CKSQYB471K50 |
|                            | C260                                |             | CKSQYB683K25 |
|                            | C233, C234, C239, C242, C280        |             | CKSQYF103Z50 |
|                            | C5017, C5019                        |             | CKSQYF103Z50 |
|                            | C1301, C1307, C285, C292, C352      |             | CKSQYF104Z25 |
|                            | C357                                |             | CKSQYF104Z25 |
|                            | C283, C294                          |             | CKSQYF473Z50 |
|                            | C279                                |             | CKSRYB102K50 |
|                            | C208, C210, C213, C218, C289        |             | CKSRYB103K50 |
|                            | C287                                |             | CKSRYB152K50 |
|                            | C258                                |             | CKSRYB223K25 |
|                            | C267-C270                           |             | CKSRYB331K50 |
|                            | C219, C262                          |             | CKSRYB332K50 |
|                            | C211, C217                          |             | CKSRYB333K16 |
|                            | C214, C215                          |             | CKSRYB472K50 |
|                            | C216, C261, C286                    |             | CKSRYB473K16 |
|                            | C259                                |             | CKSRYB681K50 |
|                            | C1202, C353, C354, C360, C370       |             | CKSRYF103Z50 |
|                            | C1305, C1306, C359                  |             | CKSRYF104Z25 |
|                            | C281                                |             | CKSRYF473Z25 |
|                            | C272, C273                          |             | CQMA104J50   |
|                            | C361 (0.22 $\mu$ F/5.5V)            |             | PCH1131      |
|                            | C263, C275-C277 (0.33 $\mu$ F/16V)  |             | PCL1043      |
|                            | C5002, C5011 (0.15 $\mu$ F/16V)     |             | PCL1044      |

| Mark             | No.                             | Description         | Parts No.    |
|------------------|---------------------------------|---------------------|--------------|
|                  | C1201 (0.082 $\mu$ F/16V)       |                     | PCL1045      |
|                  | C243 (0.1 $\mu$ F/16V)          |                     | PCL1046      |
| <b>RESISTORS</b> |                                 |                     |              |
|                  | R1, R1211, R1212, R1214         |                     | RS1/16S000J  |
|                  | R1381-R1388                     |                     | RS1/16S101J  |
|                  | R233, R5007                     |                     | RS1/16S102J  |
|                  | R1308, R213, R214, R216         |                     | RS1/16S103J  |
|                  | R247, R248, R256-R259, R266     |                     | RS1/16S103J  |
|                  | R268, R5006, R1215              |                     | RS1/16S103J  |
|                  | R251, R260, R267                |                     | RS1/16S104J  |
|                  | R206, R241                      |                     | RS1/16S105J  |
|                  | R253, R254                      |                     | RS1/16S114J  |
|                  | R5030                           |                     | RS1/16S123J  |
|                  | R353-R361                       |                     | RS1/16S124J  |
|                  | R208, R232                      |                     | RS1/16S133J  |
|                  | R201                            |                     | RS1/16S184J  |
|                  | R210                            |                     | RS1/16S204J  |
|                  | R5022                           |                     | RS1/16S221J  |
|                  | R5023                           |                     | RS1/16S222J  |
|                  | R1202, R1204, R234, R236        |                     | RS1/16S273J  |
|                  | R203, R212                      |                     | RS1/16S274J  |
|                  | R211, R242                      |                     | RS1/16S302J  |
|                  | R270                            |                     | RS1/16S332J  |
|                  | R252                            |                     | RS1/16S333J  |
|                  | R243                            |                     | RS1/16S362J  |
|                  | R1206                           |                     | RS1/16S393J  |
|                  | R215, R217                      |                     | RS1/16S470J  |
|                  | R1205, R218                     |                     | RS1/16S472J  |
|                  | R1351-R1354, R1356-R1358, R1360 |                     | RS1/16S473J  |
|                  | R246, R373, R377, R379-R383     |                     | RS1/16S473J  |
|                  | R389-R391, R393-R399            |                     | RS1/16S473J  |
|                  | R249                            |                     | RS1/16S474J  |
|                  | R235, R237                      |                     | RS1/16S512J  |
|                  | R209                            |                     | RS1/16S514J  |
|                  | R238                            |                     | RS1/16S562J  |
|                  | R255                            |                     | RS1/16S563J  |
|                  | R269                            |                     | RS1/16S682J  |
|                  | R202, R204                      |                     | RS1/16S683J  |
|                  | R250                            |                     | RS1/16S684J  |
|                  | R205                            |                     | RS1/16S754J  |
|                  | R207                            |                     | RS1/16S823J  |
|                  | R5025                           |                     | RS1/16S912J  |
|                  | VR201, VR202 (10k $\Omega$ )    |                     | RCP1045      |
|                  | Other Resistors                 |                     | RS1/10S□□□J  |
| <b>OTHERS</b>    |                                 |                     |              |
|                  | CN202                           | 5P MT CONNECTOR     | 173981-5     |
|                  | CN211                           | 3P JUMPER CONNECTOR | 52147-0310   |
|                  | CN5021                          | 3P TOP POST         | B3P-SHF-1AA  |
|                  | CN203                           | KR CONNECTOR        | B5B-PH-K-S   |
|                  | CN204                           | 6P TOP POST         | B6P-SHF-1AA  |
|                  | CN206                           | 5P SIDE POST        | B55P-SHF-1AA |
|                  | CN205                           | 39P FFC CONNECTOR   | HLEM39S-1    |
|                  | J201                            | 13P CONNECTOR ASSY  | PDE1264      |

| Mark                            | No.                          | Description                     | Parts No. | Mark | No.   | Description | Parts No.     |
|---------------------------------|------------------------------|---------------------------------|-----------|------|---|-------------|---------------|
|                                 | J210                         | 10P CONNECTOR ASSY              | PDE1269   |      | C431, C432, C435, C436                        |             | CCSQCH181J50  |
|                                 | JA201, JA202                 | JACK/12V                        | PKN1004   |      | C433, C434, C437, C438                        |             | CCSQCH330J50  |
|                                 | X352                         | CERAMIC RESONATOR<br>(16.00MHz) | PSS1010   |      | C365, C378, C380, C439-C442                   |             | CCSQCH470J50  |
|                                 |                              | PCB BINDER                      | VEF1008   |      | C449, C450                                    |             | CCSQCH681J50  |
|                                 | X351                         | CERAMIC RESONATOR<br>(4.19MHz)  | VSS1014   |      | C319, C382                                    |             | CCSRCH101J50  |
| <b>AUDIO DIGITAL BOARD ASSY</b> |                              |                                 |           |      | C308  |             | CCSRCH120J50  |
| <b>SEMICONDUCTORS</b>           |                              |                                 |           |      | C330  |             | CCSRCH180J50  |
|                                 | IC801                        | AK5340-VS                       |           |      | C309  |             | CCSRCH270J50  |
|                                 | IC302                        | CD74HC4046AM                    |           |      | C339, C341, C366                              |             | CEAS100M16    |
|                                 | IC406                        | M5218AFP                        |           |      | C302, C306, C310, C314, C324                  |             | CEAS101M6R3   |
|                                 | IC304                        | MB81C4256A-80LPJ                |           |      | C333, C337, C377                              |             | CEAS101M6R3   |
|                                 | IC803, IC804                 | NJM4580D                        |           |      | C453-C456                                     |             | CEAS221M25    |
|                                 | IC404, IC405                 | NJM5532MD                       |           |      | C362  |             | CEAS330M35    |
| △                               | IC407                        | NJM7812FA                       |           |      | C315, C323, C328, C331, C343                  |             | CEAS470M10    |
| △                               | IC408                        | NJM7912FA                       |           |      | C817, C818, C833, C835                        |             | CEZA100M50    |
|                                 | IC303                        | PCX1021                         |           |      | C457, C458, C805, C806                        |             | CEZA220M50    |
|                                 | IC402, IC403                 | PD2028B(S)                      |           |      | C811-C814, C842-C844, C848                    |             | CEZA220M50    |
|                                 | IC401                        | PD7009A                         |           |      | C443, C444                                    |             | CEZA470M16    |
|                                 | IC301                        | PDC019A                         |           |      | C459, C460, C832                              |             | CEZA4R7M50    |
|                                 | IC306                        | PDC020A                         |           |      | C451, C452                                    |             | CFTXA102J50   |
|                                 | IC309, IC310                 | TC74HC00AF                      |           |      | C317, C329                                    |             | CFTXA105J50   |
|                                 | IC307, IC308                 | TC74HCU04AF                     |           |      | C345, C347                                    |             | CKCYB101K50   |
|                                 | IC312                        | TC7S14F                         |           |      | C475  |             | CKCYB103K50   |
|                                 | Q407-Q412                    | 2SD2114K                        |           |      | C346, C348, C363, C823                        |             | CKCYF473Z50   |
|                                 | Q301, Q303                   | DTA114TS                        |           |      | C845  |             | CKSQYB102K50  |
|                                 | Q402-Q404, Q413              | DTA124ES                        |           |      | C326, C385, C387, C405, C406                  |             | CKSQYB103K50  |
|                                 | Q304                         | DTC114EK                        |           |      | C336, C407, C408, C419, C420                  |             | CKSQYB104K25  |
|                                 | Q302                         | DTC124EK                        |           |      | C423, C424                                    |             | CKSQYB104K25  |
|                                 | Q401, Q405, Q406             | DTC124ES                        |           |      | C427, C428, C390                              |             | CKSQYB472K50  |
|                                 | D302                         | 1SR35-100AVL                    |           |      | C303, C307, C402, C403                        |             | CKSQYB473K25  |
|                                 | D402, D403                   | DA114                           |           |      | C447, C448                                    |             | CKSQYB562K50  |
|                                 | D301                         | DA204K                          |           |      | C465, C466                                    |             | CKSQYB683K25  |
|                                 | D801, D803                   | DAN202K                         |           |      | C819, C820                                    |             | CKSQYB821K50  |
|                                 | D401, D802, D804             | DAP202K                         |           |      | C413-C416                                     |             | CKSQYB822K50  |
| <b>COILS AND FILTERS</b>        |                              |                                 |           |      | C1331, C445, C446, C467, C468                 |             | CKSQYF103Z50  |
|                                 | L831, L832                   | LFA010K                         |           |      | C807-C810, C846                               |             | CKSQYF103Z50  |
|                                 | L318                         | PTL1003                         |           |      | C311, C313, C316, C322, C325                  |             | CKSQYF104Z25  |
|                                 | L301-L306, L308-L314         | PTL1014                         |           |      | C327, C332, C334, C338, C342                  |             | CKSQYF104Z25  |
|                                 | L316, L317, L319, L328, L329 | PTL1014                         |           |      | C344, C364, C367, C376, C469                  |             | CKSQYF104Z25  |
|                                 | L401-L406                    | PTL1014                         |           |      | C474, C815, C816, C831, C834                  |             | CKSQYF104Z25  |
|                                 | L321 (80 $\mu$ H)            | PTL1017                         |           |      | C836, C847                                    |             | CKSQYF104Z25  |
|                                 | L320 EMI FILTER              | PTL1019                         |           |      | C320, C349, C350, C371-C375                   |             | CKSQYF473Z50  |
|                                 | L330 EMI FILTER              | PTL1020                         |           |      | C301  |             | CKSR YB102K50 |
| <b>CAPACITORS</b>               |                              |                                 |           |      | C1333, C305, C318                             |             | CKSR YB103K50 |
|                                 | C1332                        | CCSQCH100D50                    |           |      | C312  |             | CKSR YB472K50 |
|                                 | C321, C368, C369, C381, C383 | CCSQCH101J50                    |           |      | C304  |             | CKSR YF104Z25 |
|                                 | C401, C463, C470, C477, C478 | CCSQCH101J50                    |           |      | C379  |             | CQMA103K50    |
|                                 | C801, C821                   | CCSQCH101J50                    |           |      | C335  |             | CQMA104J50    |
|                                 | C803, C804                   | CCSQCH121J50                    |           |      | C472, C473 (2200 $\mu$ F/16V)                 |             | PCH1121       |
|                                 |                              |                                 |           |      | C404, C409-C412, C417, C418 (470 $\mu$ F/16V) |             | VCH1116       |
|                                 |                              |                                 |           |      | C421, C425, C426 (470 $\mu$ F/16V)            |             | VCH1116       |
|                                 |                              |                                 |           |      | C430 (470 $\mu$ F/16V)                        |             | VCH1116       |

| Mark | No. | Description | Parts No. |
|------|-----|-------------|-----------|
|------|-----|-------------|-----------|

## RESISTORS

|                                |             |
|--------------------------------|-------------|
| R3331                          | RS1/16S000J |
| R1329, R1330, R1336, R306-R309 | RS1/16S101J |
| R314-R317, R323, R324, R326    | RS1/16S101J |
| R328, R334-R336, R341-R343     | RS1/16S101J |
| R300, R311, R313, R329, R331   | RS1/16S102J |

|                   |             |
|-------------------|-------------|
| R320              | RS1/16S105J |
| R305, R337        | RS1/16S151J |
| R1333             | RS1/16S221J |
| R1335, R444, R499 | RS1/16S271J |
| R498              | RS1/16S331J |

|            |             |
|------------|-------------|
| R1324      | RS1/16S332J |
| R301, R339 | RS1/16S333J |
| R302       | RS1/16S363J |
| R344       | RS1/16S470J |
| R347, R348 | RS1/16S472J |

|                               |              |
|-------------------------------|--------------|
| R345, R349                    | RS1/16S473J  |
| R303, R304, R338, R340, R1323 | RS1/16S512J  |
| R312, R330                    | RS1/16S681J  |
| R1401-R1404                   | RS1/2LMF270J |
| Other Resistors               | RS1/10S□□□J  |

## OTHERS

|       |                            |            |
|-------|----------------------------|------------|
| CN401 | 3P JUMPER CONNECTOR        | 52147-0310 |
| JA301 | OPTICAL RECEIVER MODULE    | GP1F32R    |
| JA303 | OPTICAL TRANSMITTER MODULE | GP1F32T    |
| JA302 | 1P JACK                    | PKB1027    |
| JA304 | 1P JACK                    | PKB1028    |

|       |                            |         |
|-------|----------------------------|---------|
| JA801 | 2P JACK                    | PKB1029 |
| JA401 | 1P JACK                    | PKB1030 |
| JA402 | 1P JACK                    | PKB1031 |
| KN302 | SCREW TERMINAL             | PNB1558 |
| X301  | XTAL RESONATOR(16.9344MHz) | PSS1008 |

|                           |         |
|---------------------------|---------|
| PCB BINDER                | VEF1008 |
| KN301 EARTH METAL FITTING | VNF1084 |

## REC VR BOARD ASSY

### RESISTORS

|                 |             |
|-----------------|-------------|
| VR801 (50kΩ -A) | RCV1091     |
| VR802 (50kΩ )   | RCV1092     |
| Other Resistors | RS1/10S□□□J |

### OTHERS

|      |                   |         |
|------|-------------------|---------|
| J801 | 7P CONNECTOR ASSY | PDE1274 |
|------|-------------------|---------|

## H. P BOARD ASSY

### COILS AND FILTERS

|           |         |
|-----------|---------|
| L461-L463 | PTL1014 |
|-----------|---------|

### CAPACITORS

|             |              |
|-------------|--------------|
| C1466-C1468 | CCSQCH101J50 |
| C1463-C1465 | CKSQYF103Z50 |

| Mark | No. | Description | Parts No. |
|------|-----|-------------|-----------|
|------|-----|-------------|-----------|

## OTHERS

|       |                            |         |
|-------|----------------------------|---------|
| VR401 | VARIABLE RESISTOR (5kΩ -B) | PCS1003 |
| JA403 | HEADPHONE JACK             | RKN1002 |
|       | PCB BINDER                 | VEF1008 |

## FUNCTION BOARD ASSY

### SEMICONDUCTORS

|                 |          |
|-----------------|----------|
| Q701-Q704       | DTA124ES |
| D701-D703, D706 | SEL6210S |

### SWITCHES AND RELAYS

|           |         |
|-----------|---------|
| S701-S718 | PSG1006 |
|-----------|---------|

### COILS AND FILTERS

|      |         |
|------|---------|
| L701 | PTH1073 |
| L702 | PTH1016 |

### CAPACITORS

|      |             |
|------|-------------|
| C702 | CKCYF103Z50 |
|------|-------------|

### RESISTORS

|               |             |
|---------------|-------------|
| All Resistors | RD1/6PM□□□J |
|---------------|-------------|

## OTHERS

|       |                      |            |
|-------|----------------------|------------|
|       | REMOTE RECEIVER UNIT | GP1U27X    |
| CN701 | 39P FFC CONNECTOR    | HLEM339R-1 |
| V701  | FL INDICATOR TUBE    | PEL1086    |

## POWER A BOARD ASSY

### SEMICONDUCTORS

|             |            |
|-------------|------------|
| △ IC903     | UPC24M05HF |
| △ IC904     | NJM78M05FA |
| △ D901-D908 | 11ES2      |

### COILS AND FILTERS

|            |         |
|------------|---------|
| L901, L902 | VTH1020 |
| L11        | VTL1008 |

### CAPACITORS

|                                 |             |
|---------------------------------|-------------|
| C901, C902, C914, C915          | CKCYF103Z50 |
| C904, C905, C912 (3300 μ F/16V) | DCH1057     |
| C906 ( 2200 μ F/16V)            | PCH1121     |
| C911 (1000 μ F/16V)             | PCH1122     |
| △ C71, C78 (100PF/400VAC)       | PCL1040     |
| △ C72, C75 (0.01UF/400VAC)      | VCG-044     |

### RESISTORS

|               |             |
|---------------|-------------|
| All Resistors | RD1/6PM□□□J |
|---------------|-------------|

## OTHERS

|            |                   |         |
|------------|-------------------|---------|
| △ H11, H12 | FUSE HOLDER       | AKR1003 |
| △ CN12     | 2P-VH CONNECTOR   | B2P3-VH |
| J12        | 7P CONNECTOR ASSY | PDE1270 |
| J901       | EARTH LEAD UNIT   | PDF1168 |
| △ CN11     | TERMINAL          | RKC-061 |
|            | PCB BINDER        | VEF1040 |

| Mark | No. | Description | Parts No. |
|------|-----|-------------|-----------|
|------|-----|-------------|-----------|

**POWER B BOARD ASSY****SEMICONDUCTORS**

|   |              |              |
|---|--------------|--------------|
| △ | IC11-IC15    | ICP-N10      |
| △ | IC23         | LM2940CT-5.0 |
| △ | IC22         | NJM7905FA    |
| △ | D11-D14, D52 | 11ES2        |
| △ | D54          | MTZJ20A      |

**COILS AND FILTERS**

|         |         |
|---------|---------|
| L21-L23 | VTH1020 |
|---------|---------|

**CAPACITORS**

|                             |             |
|-----------------------------|-------------|
| C23, C24                    | CFTXA472J50 |
| C11, C13, C15-C18           | CKCYF103Z50 |
| C26 (3300 $\mu$ F/16V)      | DCH1057     |
| C54 (47 $\mu$ F/50V)        | PCH1124     |
| C52 (100 $\mu$ F/50V)       | PCH1126     |
| C25 (6800 $\mu$ F/16V)      | VCH1060     |
| C28, C29 (2200 $\mu$ F/25V) | VCH1116     |

**RESISTORS**

|               |             |
|---------------|-------------|
| All Resistors | RD1/6PM□□□J |
|---------------|-------------|

**OTHERS**

|      |                     |            |
|------|---------------------|------------|
| CN15 | 5P JUMPER CONNECTOR | 52147-0510 |
| CN17 | KR CONNECTOR        | B5B-PH-K-S |
| J16  | 6P CONNECTOR ASSY   | PDE1271    |
|      | PCB BINDER          | VEF1008    |
|      | EARTH METAL FITTING | VNF-091    |

**MECHANISM BOARD ASSY****SEMICONDUCTORS**

|        |             |
|--------|-------------|
| D1001  | GP1S24      |
| PC1001 | NJL5803K-F1 |

**RESISTORS**

|               |             |
|---------------|-------------|
| All Resistors | RS1/10S□□□J |
|---------------|-------------|

**OTHERS**

|       |                   |         |
|-------|-------------------|---------|
| J1002 | 7P CONNECTOR ASSY | PDE1260 |
|-------|-------------------|---------|

## 7. ADJUSTMENTS

### 1. Adjustment Methods

If a compact disc recorder is adjusted incorrectly or inadequately, it may malfunction or not work at all even though there is nothing at all wrong with the pickup or the circuitry. Adjust correctly following the adjustment procedure.

#### ● Measuring Instruments and Tools

1. Dual trace oscilloscope (10 : 1 probe)
2. Low-frequency oscillator
3. Test disc (STD-903), (STD-R03)
4. Low pass filter ( $15\text{k}\Omega + 0.001\mu\text{F}$ ), ( $39\text{k}\Omega + 0.001\mu\text{F}$ )
5. Hi pass filter ( $3.9\text{k}\Omega + 180\text{PF}$ )
6. Resistor ( $100\text{k}\Omega$ )
7. Hexagonal screwdriver (1.27mm diagonal)
8. Standard tools
9. Small screwdriver
10. Multimeter (Voltage accuracy: Below 1 mV)

#### ● Adjustment Items/Verification Items and Order

##### Adjustment 1

| Step | Item                             | Test Point                | Adjustment Location  |
|------|----------------------------------|---------------------------|--|
| 1    | Playback power adjustment        | CN104 (TP1), Pin7 (PWAJT) | VR103 (PB, PW)   |
| 2    | Coarse focus offset adjustment   | CN204 (TP201), Pin1 (RF)  | VR105 (FE, OFS)  |
| 3    | Coarse skew adjustment           | CN204 (TP201), Pin1 (RF)  | Radial tilt adjustment screw and<br>Tangential tilt adjustment screw |
| 4    | Coarse grating adjustment        | CN104 (TP1), Pin3 (TE)    | Grating adjustment slit  |
| 5    | DPP (tracking offset) adjustment | CN104 (TP1), Pin3 (TE)    | VR112 (TE, OFS)  |
| 6    | Fine focus offset adjustment     | CN204 (TP201), Pin1 (RF)  | VR105 (FE, OFS)  |
| 7    | Fine skew adjustment             | CN204 (TP201), Pin1 (RF)  | Radial tilt adjustment screw and<br>Tangential tilt adjustment screw |
| 8    | Grating re-adjustment            | CN104 (TP1), Pin3 (TE)    | Grating adjustment slit  |

**Adjustment 2**

| Step | Item                                | Test Point   | Adjustment Location  |
|------|-------------------------------------|--|----------------------|
| 1    | WBL+offset adjustment               | CN104 (TP1), Pin 6 (RWBL)                                    | VR107 (WBL+. OFS)    |
| 2    | Coarse WBL offset adjustment        | CN104 (TP1), Pin 5 (WBL)                                     | VR108 (WBL. OFS)     |
| 3    | Playback power re-adjustment        | CN104 (TP1), Pin 7 (PWAJT)                                   | VR103 (PB. PW)       |
| 4    | Coarse focus offset adjustment      | CN204 (TP201), Pin 1 (RF)                                    | VR105 (FE. OFS)      |
| 5    | Main and sub mix ratio adjustment   | CN104 (TP1), Pin 1 (STE)<br>CN104 (TP1), Pin 2 (MSTE)        | VR110 (MS. MIX)      |
| 6    | Tracking amp. gain adjustment       | CN104 (TP1), Pin 3 (TE)                                      | VR111 (TE. GAIN)     |
| 7    | Tracking offset adjustment          | CN104 (TP1), Pin 3 (TE)                                      | VR112 (TE. OFS)      |
| 8    | ACT offset adjustment               | CN5021 (TP00), Pin 1 (ACT ERR)                               | VR1 (ACT. OFS)       |
| 9    | ACT GAIN adjustment                 | CN5021 (TP00), Pin 1 (ACT ERR)                               | VR10 (ACT. GAIN)     |
| 10   | Fine focus offset adjustment        | CN204 (TP201), Pin 1 (RF)                                    | VR105 (FE. OFS)      |
| 11   | WBL BALANCE adjustment              | CN104 (TP1), Pin 5 (WBL)                                     | VR106 (WBL. BALANCE) |
| 12   | Fine WBL offset adjustment          | CN104 (TP1), Pin 5 (WBL)                                     | VR108 (WBL. OFS)     |
| 13   | WBL focus offset adjustment         | CN104 (TP1), Pin 5 (WBL)                                     | VR115 (WFE. OFS)     |
| 14   | Recording power adjustment          | CN104 (TP1), Pin 7 (PWAJT)                                   | VR104 (REC. PW)      |
| 15   | HF Amp. gain adjustment             | CN104 (TP1), Pin 8 (HF)                                      | VR119 (HF. GAIN)     |
| 16   | Focus servo loop gain adjustment    | CN204 (TP201), Pin 5 (FCSIN)<br>CN204 (TP201), Pin 6 (FCSEK) | VR201 (FCS. GAIN)    |
| 17   | Tracking servo loop gain adjustment | CN204 (TP201), Pin 2 (TRKER)<br>CN204 (TP201), Pin 3 (TRKIN) | VR202 (TE. GAIN)     |






Fig. 1 SERVO UCOM BOARD ASSY




Fig. 2 HEAD BOARD ASSY

## ● Notes

1. Use a 10:1 probe for the oscilloscope.
2. All the knob positions (settings) for the oscilloscope in the adjustment procedures are for when a 10:1 probe is used.

## ● Test Mode

This model has a test mode so that the adjustments and checks required for service can be carried out easily. When this model is in test mode, the keys on the front panel work differently from normal. Adjustments and checks can be carried out by operating these keys with the correct procedure. For this model, all adjustments are carried out in test mode.

### [Setting to Test Mode]

How to set this model into test mode.

1. Unplug the power cord from the AC socket.
2. Short the test mode short land. (See Fig. 1.)
3. Plug the power cord back into the AC socket.

When the test mode is set correctly, the display is different from what it usually is when the power is turned on. (lights up all FL display) If the display is still the same as usual, test mode has not been set correctly, so repeat Steps 1 – 3.








### [Release from Test Mode]

Here is the procedure for releasing the test mode:

1. Press the STOP key and stop all operations.
2. Unplug the power cord from the AC socket.

### [Operations of the keys in test mode]


| Code | Key Name        | Function in Test Mode   | Explanation  |
|------|-----------------|-------------------------|--|
|      | DIGITAL SYNCHRO | Playback laser diode ON | Lights up the laser diode by playback power.   |
|      | FINALIZE        | Focus servo closes      | <p>The laser diode is lit up and the focus actuator is lowered, then raised slowly and the focus servo is closed at the point where the objective lens is focused on the disc.</p> <p>With the player in this state, if you lightly rotate the stopped disc by hand, you can hear the sound the focus servo. If you can hear this sound, the focus servo is operating correctly.</p> <p>If you press this key with no disc mounted, the laser diode lights up, the focus actuator is pulled down, then the actuator is raised and lowered three times and returned to its original position.</p> |

| Code  | Key Name                       | Function In Test Mode                       | Explanation  |
|---|--------------------------------|---|--|
|    | PLAY                           | Spindle servo ON                            | Starts the spindle motor in the clockwise direction and when the disc rotation reaches the prescribed speed (about 500 rpm at the inner periphery), sets the spindle servo in a closed loop.   |
|    | PAUSE                          | Tracking servo close/open                   | Pressing this key when the focus servo and spindle servo are operating correctly in closed loops puts the tracking servo into a closed loop, displays the track number being played back and the elapsed time on the front panel.<br>If the elapsed time is not displayed or not counted correctly, it may be that something is out of adjustment, or that there is some other problem.<br>This key is a toggle key and open/close the tracking servo alternately. This key has no effect if no disc is mounted. |
|    | MANUAL/<br>TRACK<br>SEARCH REV | Carriage reverse (inwards)                  | Moves the pickup position toward the inner diameter of the disc. When this key is pressed with the tracking servo in a closed loop, the tracking servo automatically goes into an open loop. Since the motor does not automatically stop at the mechanical end point in test mode, be careful with this operation.   |
|  | MANUAL/<br>TRACK<br>SEARCH FWD | Carriage forward (outwards)                 | Moves the pickup position toward the outer diameter of the disc. When this key is pressed with the tracking servo in a closed loop, the tracking servo automatically goes into an open loop. Since the motor does not automatically stop at the mechanical end point in test mode, be careful with this operation.   |
|  | STOP                           | Stop  | Initializes and the disc rotation stops.<br>The pickup and disc remain where they are when this key is pressed.  |
|  | OPEN/CLOSE                     | Disc tray open/close                        | Open/close the disc tray. This key is a toggle key and open/close tray alternately.<br>Pressing this key when the disc is turning stops the disc, then opens the tray.<br>This key operation does not affect the position of the pickup.   |
|  | REC<br>↓<br>REC MUTE           | Maximum recording power.<br>Laser diode ON. | Lights up the laser diode with maximum recording power and normal EFM by pressing REC and REC MUTE keys in order.<br>* The laser diode may be damaged if adjustments are made before pressing these keys.  |
|   | DISPLAY OFF                    | Focus offset switching                      | Switches the focus offset state.<br>DISPLAY OFF LED LIGHTS UP : C/N in the best condition.<br>LIGHTS OFF: Jitter in the best condition.  |
|   | WRITE                          | Optical axis servo switching                | Switches the ON/OFF of the optical axis servo.<br>(MANUAL) LED LIGHTS UP : Optical axis servo ON<br>LIGHTS OFF: Optical axis servo OFF   |

### [How to play back a disc in test mode]

In test mode, since the servos operate independently, playing back a disc requires that you operate the keys in the correct order to close the servos.

Here is the key operation sequence for playing back a disc in test mode.



Wait at least 2-3 seconds between each of these operations.

## Adjustment 1

### 1. Playback Power Adjustment

Adjustment 1

|                                      |   |                       |                                     |
|--------------------------------------|---|-----------------------|-------------------------------------|
| ● Objective                          | To optimize the playback power of the laser diode.                  |                       |                                     |
| ● Symptom when out of adjustment     | Play does not start, track search is impossible, track are skipped. |                       |                                     |
| ● Measurement instrument connections | Connect the multimeter to CN104 (TP1), Pin 7 (PWAJT)                | ● Player state        | Test mode, Playback laser diode ON  |
|                                      |   | ● Adjustment location | VR103 (PB. PW)<br>(Head board assy) |
|                                      |   | ● Disc                | None needed                         |

#### [Procedure]


When adjusting with the multimeter

1. Light up the playback laser diode using the DIGITAL SYNCHRO key.
2. Adjust the voltage value of Pin 7 (PWAJT) of CN104 (TP1) to the voltage value (PB PW voltage  $\pm 5$  mV) displayed on the pickup flexible cable using VR103 (PB PW).

Note) This adjustment cannot be performed accurately if disc is set. Be sure to remove disc first before adjustments.

Reference: When adjusting with the optical power meter

1. Move the pickup to the outer edge of the disc with the MANUAL/TRACK SEARCH FWD ▶▶▶▶ key.
2. Lights up the playback laser diode by DIGITAL SYNCHRO key.
3. Shine the light discharged from the objective lens in the pickup on the light power meter sensor. Adjust VR103 (PB.PW) so that the playback laser diode output is an average  $0.6 \text{ mW} \pm 0.05 \text{ mW}$ .  
(Wavelength 790nm, Average mode)



\* Recording on the disc is not possible in test mode.


## 2. Coarse Focus Offset Adjustment

Adjustment 1


|                                      |  |   |  |
|--------------------------------------|--|---|--|
| ● Objective                          | To coarse adjust the DC offset voltage of the focus servo circuit for perform the tracking and slider adjustments correctly.           |   |  |
| ● Symptom when out of adjustment     | The model does not focus in, sound broken and the RF signal is dirty.  |   |  |
| ● Measurement instrument connections | Connect the oscilloscope to CN204 (TP201), Pin 1 (RF) (SERVO UCOM board assy)<br>[Settings] 20 mV/division<br>2 ms/division<br>DC mode | ● Player state<br><br>● Adjustment location<br><br>● Disc | Test mode, focus and spindle servos closed and tracking servo open.<br>VR105 (FE. OFS)<br>(Head board assy)<br>STD-903 |

### [Procedure]

1. Press the FINALIZE key, then the PLAY ► key in that order to close the focus servo then the spindle servo.
2. Adjust VR105 (FE. OFS) so that the amplitude of waveform at CN204 (TP201), Pin 1 (RF) is maximum.



OUT of adjustment



Optimum adjustment

### 3. Coarse Skew Adjustment

Adjustment 1

|                                     |   |                      |   |
|-------------------------------------|---|----------------------|---|
| ●Objective                          | To coarse adjust the angle of pickup to the disc for perform the grating and DPP (tracking offset) adjustments correctly. |                      |   |
| ●Symptom when out of adjustment     | Sound broken, some discs can be played but not others.  |                      |   |
| ●Measurement instrument connections | Connect the oscilloscope to CN204 (TP201), Pin 1 (RF). (SERVO UCOM board assy)  | ●Player state        | Test mode, focus and spindle servos closed and tracking servo open. |
|                                     | [Settings] 20 mV/division<br>200 ns/division<br>AC mode   | ●Adjustment location | Radial adjustment screw and tangential adjustment screw             |
|                                     |   | ●Disc                | STD-903   |

#### [Procedure]

1. Move the pickup to the position where the radial/ tangential adjustment screws will be seen with the MANUAL/TRACK SEARCH FWD ►►►► or REV ◄◄◄◄ keys so that the radial/tangential adjustment screws can be adjusted.
2. Press the FINALIZE key, then the PLAY ► key in that order to close the focus servo then the spindle servo.
3. Adjust the RAD (radial direction) and TAN (tangential direction) adjustment screws alternately with hexagonal screwdriver (1.27 mm diagonal) to maximize the RF output at CN204 (TP201), pin 1.

Note: Radial direction and tangential direction mean the direction relative to the disc shown in Fig. 3.





Fig. 3



#### 4. Coarse Grating Adjustment

Adjustment 1

|                                      |  |                       |  |
|--------------------------------------|--|-----------------------|--|
| ● Objective                          | To align the tracking error generation laser beam spots to the optimum angle on the track.   |                       |  |
| ● Symptom when out of adjustment     | Play does not start, track search is impossible, tracks are skipped.   |                       |  |
| ● Measurement instrument connections | Connect the oscilloscope to CN104 (TP1), Pin 3 (TE)<br>This connection may be via a low pass filter. (See Fig. 4)<br>[Settings] 50 mV/division<br>5 ms/division<br>DC mode | ● Player state        | Test mode, focus and spindle servos closed and tracking servo open |
|                                      |  | ● Adjustment location | Grating slit on pickup   |
|                                      |  | ● Disc                | STD-903  |

##### [Procedure]

1. Move the pickup to the position where the grating adjustment slit will be seen with the MANUAL/TRACK SEARCH FWD ►►►► or REV ◄◄◄◄ keys so that the grating adjustment can be adjusted.
  2. Press the FINALIZE key, then the PLAY ► key in that order to close the focus servo then spindle servo.
  3. Insert a screwdriver into the grating adjustment slit and adjust the grating to find the null point.  
For more details, see next page.
  4. If you slowly turn the screwdriver clockwise from the null point, the amplitude of the wave gradually increases, then if you continue turning the screwdriver, the amplitude of the wave becomes smaller again. Turn the screw driver counterclockwise from the null point and set the grating to the first point where the wave amplitude reaches its maximum.
- Reference : Fig.5 shows the relation between the angle of the tracking beam with the track and the waveform.
5. Return the pickup to more or less midway across disc with the MANUAL/TRACK SEARCH REV ◄◄◄◄ key, press the PAUSE ■■ key and check that the track number and elapsed time are displayed on the front panel. If they are not displayed at this time or the elapsed time changes irregularly, check the null point and adjust the grating again.





Fig. 4



**[How to find the null point]**

When you insert the small screwdriver into the slit for the grating adjustment and change the grating angle, the amplitude of the tracking error signal at CN104 (TP1), Pin 3 (TE) changes. Within the range for the grating, there are five or six locations where the amplitude of the wave reaches a minimum. Of these five or six locations, there is only one at which the envelope of the waveform is smooth. This location is where the three laser beams divided by the grating are all right above the same track. (See Fig. 5.)

This point is called the null point. When adjusting the grating, this null point is found and used as the reference position.





Fig. 5



Note : If the difference between the amplitude of the error signal at the innermost edge and outermost edge of the disc is more than 10%, adjust the grating again.




## 5. DPP (Tracking Offset) Adjustment

Adjustment 1

|                                      |   |   |   |
|--------------------------------------|---|---|---|
| ● Objective                          | To correct for the variation in the sensitivity of the tracking photodiode.   |   |   |
| ● Symptom when out of adjustment     | Player does not playback, track search is impossible, tracks are skipped.   |   |   |
| ● Measurement instrument connections | Connect the oscilloscope to CN104 (TP1), Pin 3 (TE)<br>[This connection may be via a low pass filter (15k $\Omega$ +0.001 $\mu$ F).]<br>[Settings] 50 mV/division<br>5 ms/division<br>DC mode | ● Player state<br><br>● Adjustment location<br><br>● Disc | Test mode, focus and spindle servos closed and tracking servo open<br><br>VR112 (TE. OFS)<br>(Head board assy)<br>STD-903 |

### [Procedure]

1. Move the pickup to midway across the disc (R=35mm) with the MANUAL/TRACK SEARCH FWD ►►►► or REV ◄◄◄◄ keys.
2. Press the FINALIZE key, then the PLAY ► key in that order to close the focus servo then the spindle servo.
3. Line up the bright line (ground) at the center of the oscilloscope screen and put the oscilloscope into DC mode.
4. Adjust VR112 (TE. OFS) so that the positive amplitude and negative amplitude of the tracking error signal at CN104 (TP1), Pin 3 (TE) are the same (in other words, so that there is no DC component).




## 6. Fine Focus Offset Adjustment

Adjustment 1


|                                      |   |                       |                                      |
|--------------------------------------|---|-----------------------|--------------------------------------|
| ● Objective                          | To optimize the DC offset voltage of the focus servo circuit.                     |                       |                                      |
| ● Symptom when out of adjustment     | The player does not focus in, sound broken and the RF signal is dirty.            |                       |                                      |
| ● Measurement instrument connections | Connect the oscilloscope to CN204 (TP201), Pin 1 (RF).<br>(SERVO UCOM board assy) | ● Player state        | Test mode, play                      |
|                                      | [Settings] 20 mV/division<br>500 ns/division<br>AC mode                           | ● Adjustment location | VR105 (FE. OFS)<br>(Head board assy) |
|                                      |   | ● Disc                | STD-903                              |

**[Procedure]**

1. Move the pickup to midway across the disc (R=35mm) with the MANUAL/TRACK SEARCH FWD ►► ►►I or REV ◀◀ ◀◀ keys.
2. Press the FINALIZE key, the PLAY ► key, then the PAUSE || key in that order to close the respective servos and put the player into play mode.
3. Adjust VR105 (FE. OFS) so that the 3T waveform at CN204 (TP201), Pin 1 (RF) is maximum.



Out of adjustment



Optimum adjustment


## 7. Fine Skew Adjustment

Adjustment 1


|                                      |   |                       |  |
|--------------------------------------|---|-----------------------|--|
| ● Objective                          | To adjust the angle of the pickup relative to the disc so that the laser beams are shone straight down into the disc for the best read out of the RF signals. |                       |  |
| ● Symptom when out of adjustment     | Sound broken, some discs can be played but not others.  |                       |  |
| ● Measurement instrument connections | Connect the oscilloscope to CN204 (TP201), Pin 1 (RF).<br>(SERVO UCOM board assy)   | ● Player state        | Test mode, play  |
|                                      | [Settings] 20mV/division<br>200ns/division<br>AC mode   | ● Adjustment location | Pickup radial adjustment screw and tangential adjustment screw |
|                                      |   | ● Disc                | STD-903  |

### [Procedure]

1. Move the pickup to the position where the radial/tangential adjustment screws will be seen with the MANUAL/TRACK SEARCH FWD ►►►► or REV ◄◄◄◄ keys so that the radial/ tangential adjustment screws can be adjusted.
2. Press the FINALIZE key, then the PLAY ► key to the PAUSE || key in that order to close the respective servos and put the player into play mode.
3. First, adjust the radial adjustment screw with the hexagonal screwdriver (1.27 mm) so that the eye pattern (the diamond shape at the center of the RF signal) can be seen the most clearly.
4. Next, adjust the tangential adjustment screw with the hexagonal screwdriver so that the eye pattern can be seen the most clearly (Fig. 6).
5. Adjust in the order of the radial adjustment screw and the tangential screw again, so that the eye pattern can be seen the most clearly. As necessary, adjust the two screws alternately so that the eye pattern can be seen the most clearly.
6. After the adjustment, remove the float screw, turn over the servo mechanism assembly, then stabilize the radial adjustment screw and the tangential adjustment screw with an adhesive.



Adjustment 1



8. Grating Re-Adjustment

Adjustment 1

Adjust in the same manner as "4. Coarse Grating Adjustment" in Adjustment 1.

## Adjustment 2

### 1. WBL+Offset Adjustment

Adjustment 2

|  |  |   |  |
|--|--|---|--|
| ● Objective  | To adjust the gain balance of the wobble signal.   |   |  |
| ● Symptom when out of adjustment   | Player does not record or playback CD-R discs.   |   |  |
| ● Measurement instrument connections   | Connect the oscilloscope to CN104 (TP1), Pin 6 (RWBL). (Head board assy)<br>[Settings] 1 mV/division<br>5 ms/division<br>DC mode | ● Player state<br><br>● Adjustment location<br><br>● Disc | Test mode, stop<br><br>VR107 (WBL +. OFS) (Head board assy)<br><br>None needed |
| <b>[Procedure]</b><br>1. Turn VR108 (WBL. OFS) to fully counterclockwise.<br>2. Adjust VR107 (WBL+. OFS) so that the DC voltage at CN104 (TP1), Pin 6 (RWBL) is $-20\text{mV} \pm 10\text{mV}$ . |  |   |  |

### 2. Coarse WBL Offset Adjustment

Adjustment 2

|  |   |   |  |
|--|---|---|--|
| ● Objective  | To optimize the DC offset voltage of the wobble amp.  |   |  |
| ● Symptom when out of adjustment   | Player does not record or playback CD-R discs.  |   |  |
| ● Measurement instrument connections   | Connect the oscilloscope to CN104 (TP1), Pin 5 (WBL).<br><br>[Settings] 1 mV/division<br>5 ms/division<br>DC mode | ● Player state<br><br>● Adjustment location<br><br>● Disc | Test mode, stop<br><br>VR108 (WBL. OFS) (Head board assy)<br><br>None needed |
| <b>[Procedure]</b><br>1. Adjust VR108 (WBL. OFS) so that the DC voltage at CN104 (TP1), Pin 5 (WBL) is $0 \pm 10\text{mV}$ . |   |   |  |

### 3. Playback power Re-Adjustment

Adjustment 2


Adjust in the same manner as "1. Playback power Adjustment" in Adjustment 1.

**4. Coarse Focus Offset Adjustment**Adjustment 2


|                                      |   |                       |   |
|--------------------------------------|---|-----------------------|---|
| ● Objective                          | To optimize the DC offset voltage of the focus error amp.                         |                       |   |
| ● Symptom when out of adjustment     | The player does not focus in and the RF signal is dirty.                          |                       |   |
| ● Measurement instrument connections | Connect the oscilloscope to CN204 (TP201), Pin 1 (RF).<br>(SERVO UCOM board assy) | ● Player state        | Test mode, focus and spindle servos closed and tracking servo open. |
|                                      | [Settings] 20 mV/division<br>2m sec/division<br>DC mode                           | ● Adjustment location | VR105 (FE. OFS)<br>(Head board assy)                                |
|                                      |   | ● Disc                | STD-903   |

**[Procedure]**

1. Press the FINALIZE key, then the PLAY ► key in that order to close the focus servo then the spindle servo.
2. Adjust VR105 (FE. OFS) so that the amplitude of RF signal at CN204 (TP201), Pin 1 (RF) is maximum.



Out of adjustment



Optimum adjustment

## 5. Main and Sub Mix Ratio Adjustment


Adjustment 2

|  |   |   |   |
|--|---|---|---|
| ● Objective  | To mix the gain of the main signal output and sub signal output of the pickup.  |   |   |
| ● Symptom when out of adjustment   | Player does not playback.   |   |   |
| ● Measurement instrument connections   | Connect the oscilloscope to<br>CH1 : CN104 (TP1),<br>Pin 1 (STE)<br>CH2 : CN104 (TP1),<br>Pin 2 (MSTE).<br>[These connections must be via low pass filters.]<br><br>[Settings]<br>CH 1 : 50 mV/div. AC mode<br>10 ms/div. ADD mode<br>CH 2 : 100 mV/div.<br>AC mode | ● Player state<br><br>● Adjustment location<br><br>● Disc | Test mode, focus and spindle servos closed and tracking servo open<br><br>VR110 (MS. MIX)<br>(Head board assy)<br><br>STD-903 |
| <b>[Procedure]</b><br><br>1. Press the FINALIZE key, then the PLAY ► key in that order to close the focus servo then the spindle servo.<br>2. Set the oscilloscope to ADD mode (waveform adding mode of CH1 and CH2) and observe the adding waveform of CH1 and CH2.<br>3. Adjust VR110 (MS. MIX) so that the amplitude of waveform becomes minimum. |   |   |   |

## 6. Tracking Amp. Gain Adjustment

Adjustment 2

|  |   |   |  |
|--|---|---|--|
| ● Objective  | To correct the discrepancy in the tracking error level with the pickup.   |   |  |
| ● Symptom when out of adjustment   | Player does not playback, track search is impossible, tracks are skipped.   |   |  |
| ● Measurement instrument connections   | Connect the oscilloscope to<br>CN104 (TP1), Pin 3 (TE).<br>[This connection must be via a low pass filter<br>(15kΩ+0.001μF).]<br><br>[Settings]    20 mV/division<br>5 ms/division<br>DC mode | ● Player state<br><br>● Adjustment location<br><br>● Disc | Test mode, focus and spindle servos closed and tracking servo open<br><br>VR111 (TE. GAIN)<br>(Head board assy)<br><br>STD-903 |
| <b>[Procedure]</b><br><br>1. Move the pickup to midway across the disc (R=35mm) with the MANUAL/TRACK SEARCH FWD ►► ►► or REV ◄◄ ◄◄ keys.<br>2. Press the FINALIZE key, then the PLAY ► key in that order to close the focus servo then the spindle servo.<br>3. Line up the bright line (ground) at the center of the oscilloscope screen and put the oscilloscope into DC mode.<br>4. Adjust VR111 (TE. GAIN) so that the positive amplitude and negative amplitude of the tracking error signal at CN104 (TP1), Pin 3 (TE) is 1.0V ± 0.05V. |   |   |  |



## 7. Tracking Offset Adjustment


Adjustment 2

|                                      |  |   |   |
|--------------------------------------|--|---|---|
| ● Objective                          | To correct for the variation in the sensitivity of the tracking photodiode.  |   |   |
| ● Symptom when out of adjustment     | Player does not playback, track search is impossible, tracks are skipped.  |   |   |
| ● Measurement instrument connections | Connect the oscilloscope to CN104 (TP1), Pin 3 (TE)<br>[This connection must be via a low pass filter (15k $\Omega$ +0.001 $\mu$ F).]<br>[Settings] 20 mV/division<br>5 ms/division<br>DC mode | ● Player state<br><br>● Adjustment location<br><br>● Disc | Test mode, focus and spindle servos closed and tracking servo open<br><br>VR112 (TE. OFS)<br>(Head board assy)<br>STD-903 |

**[Procedure]**

1. Move the pickup to midway across the disc (R=35mm) with the MANUAL/TRACK SEARCH FWD ►►►► or REV ◄◄◄◄ keys.
2. Press the FINALIZE key, then the PLAY ► key in that order to close the focus servo then the spindle servo.
3. Line up the bright line (ground) at the center of the oscilloscope screen and put the oscilloscope into DC mode.
4. Adjust VR112 (TE. OFS) so that the positive amplitude and negative amplitude of the tracking error signal at CN104 (TP1), Pin 3 (TE) are the same (in other words, so that there is no DC component).

Note : Perform the run-on adjustment in the section 6 and 7.





## 8. ACT offset Adjustment

Adjustment 2

|   |   |   |   |
|---|---|---|---|
| ● Objective   | To optimize the DC offset voltage of the actuator servo.  |   |   |
| ● Symptom when out of adjustment  | Player does not pause, track search is impossible, tracks are skipped.  |   |   |
| ● Measurement instrument connections  | Connect the oscilloscope to CN5021 (TP00), Pin 1 (ACT ERR) (SERVO UCOM board assy)<br><br>[Settings] 5mV/division<br>5 ms/division<br>DC mode | ● Player state<br><br>● Adjustment location<br><br>● Disc | Test mode, focus and spindle servos closed and tracking servo open<br><br>VR1 (ACT. OFS) (Head board assy)<br><br>STD-903 |
| <b>[Procedure]</b><br><br>1. Move the pickup to midway across the disc (R=35mm) with the MANUAL/TRACK SEARCH FWD ►► ►► or REV ◄◄ ◄◄ keys.<br>2. Press the FINALIZE key, then the PLAY ► key in that order to close the focus servo then the spindle servo.<br>3. Adjust VR1 (ACT. OFS) so that the DC voltage at CN5021 (TP00), pin 1 (ACT ERR) is $0\pm 20\text{mV}$ . |   |   |   |

## 9. ACT GAIN Adjustment

Adjustment 2

|  |  |   |   |
|--|--|---|---|
| ● Objective  | To optimize the actuator servo gain.   |   |   |
| ● Symptom when out of adjustment   | Player does not pause, track search is impossible, tracks are skipped.   |   |   |
| ● Measurement instrument connections   | Connect the oscilloscope to CN5021 (TP00), Pin 1 (ACT ERR) (SERVO UCOM board assy)<br><br>[Settings] 10mV/division<br>5 ms/division<br>DC mode | ● Player state<br><br>● Adjustment location<br><br>● Disc | Test mode, focus and spindle servos closed and tracking servo open<br><br>VR10 (ACT. GAIN) (Head board assy)<br><br>STD-903 |
| <b>[Procedure]</b><br><br>1. Move the pickup to midway across the disc (R=35mm) with the MANUAL/TRACK SEARCH FWD ►► ►► or REV ◄◄ ◄◄ keys.<br>2. Press the FINALIZE key, then the PLAY ► key in that order to close the focus servo then the spindle servo.<br>3. Press the WRITE key to light up the WRITE KEY LED, and short-circuit the Pin 2 and Pin 3 of CN5021 (TP00).<br>4. Adjust VR10 (ACT. GAIN) so that the DC voltage at CN5021 (TP00), Pin 1 (ACT ERR) is $-380\pm 20\text{mV}$ .<br>Note: Perform the run-on adjustment in the section 8 and 9. |  |   |   |


## 10. Fine Focus Offset Adjustment

Adjustment 2


|                                      |   |                       |                                      |
|--------------------------------------|---|-----------------------|--------------------------------------|
| ● Objective                          | To optimize the DC offset voltage of the focus servo circuit.                     |                       |                                      |
| ● Symptom when out of adjustment     | The player does not focus in, sound broken and the RF signal is dirty.            |                       |                                      |
| ● Measurement instrument connections | Connect the oscilloscope to CN204 (TP201), Pin 1 (RF).<br>(SERVO UCOM board assy) | ● Player state        | Test mode, play                      |
|                                      | [Settings] 20 mV/division<br>500 ns/division<br>AC mode                           | ● Adjustment location | VR105 (FE. OFS)<br>(Head board assy) |
|                                      |   | ● Disc                | STD-R03                              |

### [Procedure]

1. Move the pickup to midway across the disc (R=35mm) with the MANUAL/TRACK SEARCH FWD ►► ►► or REV ◄◄ ◄◄ keys.
  2. Press the FINALIZE key, the PLAY ► key, then the PAUSE || key in that order to close the respective servos and put the player into play mode.
  3. Adjust VR105 (FE. OFS) so that the 3T waveform at CN204 (TP201), Pin 1 (RF) is maximum.
- Note) Adjust after confirming that the WRITE KEY LED is OFF.



Out of adjustment



Optimum adjustment


## 11. WBL BALANCE Adjustment

Adjustment 2


|                                      |   |   |   |
|--------------------------------------|---|---|---|
| ● Objective                          | To adjust the gain balance of the wobble signal.  |   |   |
| ● Symptom when out of adjustment     | Player does not record or search or pause CD-R discs.   |   |   |
| ● Measurement instrument connections | Connect the oscilloscope to CN104 (TP1), Pin 5 (WBL).<br>[This connection must be via a high-pass filter (180pF+3.9kΩ).]<br><br>[Settings] 5mV/division<br>20μsec/division<br>DC mode | ● Player state<br><br>● Adjustment location<br><br>● Disc | Test mode, play<br><br>VR106 (WBL. BALANCE)<br>(Head board assy)<br><br>STD-R03 |

### [Procedure]

1. Move the pickup to midway across the disc (R=35mm) with the MANUAL/TRACK SEARCH FWD ►► ►► or REV ◄◄ ◄◄ keys.
2. Press the FINALIZE key, the PLAY ► key, then the PAUSE || key in that order to close the respective servos and put the player into play mode.
3. Adjust VR106 (WBL. BALANCE) so that the amplitude of the waveform at CN104 (TP1), Pin 5 (WBL) is minimum.



Out of adjustment



Optimum adjustment


## 12. Fine WBL offset Adjustment

Adjustment 2


|                                      |   |   |   |
|--------------------------------------|---|---|---|
| ● Objective                          | To adjust the gain balance of the wobble signal.  |   |   |
| ● Symptom when out of adjustment     | Player does not record or search or pause CD-R discs.   |   |   |
| ● Measurement instrument connections | Connect the oscilloscope to CN104 (TP1), Pin 5 (WBL)<br>[This connection must be via a high-pass filter (180pF+3.9kΩ)]<br>[Settings] 5mV/division<br>20μsec/division<br>DC mode | ● Player state<br><br>● Adjustment location<br><br>● Disc | Test mode, play<br><br>VR108 (WBL. OFS)<br>(Head board assy)<br><br>STD-R03 |

## [Procedure]

1. Move the pickup to midway across the disc (R=35mm) with the MANUAL/TRACK SEARCH FWD ►► ►► or REV ◄◄ ◄◄ keys.
2. Press the FINALIZE key, the PLAY ► key, then the PAUSE || key in that order to close the respective servos and put the player into play mode.
3. Adjust VR108 (WBL. OFS) so that the waveform at CN104 (TP1), Pin 5 (WBL) is minimum.



Out of adjustment



Optimum adjustment


### 13. WBL focus offset Adjustment

Adjustment 2


|                                      |   |   |   |
|--------------------------------------|---|---|---|
| ● Objective                          | To adjust the gains balance of the wobble signal.   |   |   |
| ● Symptom when out of adjustment     | Player does not record or search or pause CD-R discs.   |   |   |
| ● Measurement instrument connections | Connect the oscilloscope to CN104 (TP1), Pin 5 (WBL).<br>[This connection must be via a high-pass filter (180pF+3.9kΩ).]<br><br>[Settings] 5mV/division<br>20μsec/division<br>DC mode | ● Player state<br><br>● Adjustment location<br><br>● Disc | Test mode, play<br><br>VR115 (WFE. OFS)<br>(Head board assy)<br><br>STD-R03 |

#### [Procedure]

1. Move the pickup to midway across the disc (R=35mm) with the MANUAL/TRACK SEARCH FWD ►► ►►I or REV ◄◄ ◄◄ keys.
2. Press the FINALIZE key, the PLAY ► key, then the PAUSE II key in that order to close the respective servos and put the player into play mode.
3. Press the DISPLAY OFF key to light up the DISPLAY OFF KEY LED.
4. Adjust VR115 (WFE. OFS) so that the amplitude of the waveform at CN104 (TP1), Pin 5 (WBL) is minimum.



Out of adjustment



Optimum adjustment

## 14. Recording Power Adjustment

Adjustment 2

|                                      |  |                       |                                       |
|--------------------------------------|--|-----------------------|---------------------------------------|
| ● Objective                          | To optimize the recording power of the laser diode.  |                       |                                       |
| ● Symptom when out of adjustment     | The player does not record nor playback self-recorded discs. It also skips tracks and the RF waveform is dirty. (No problems during CD playback) |                       |                                       |
| ● Measurement instrument connections | Connect the multimeter to CN104 (TP1), Pin 7 (PWAJT).  | ● Player state        | Test mode, maximum recording power ON |
|                                      |  | ● Adjustment location | VR104 (REC. PW)<br>(Head board assy)  |
|                                      |  | ● Disc                | None needed                           |


**[Procedure]**

When adjusting with the multimeter

1. Fully turn VR104 (REC. PW) counterclockwise to reduce the power to the minimum.
2. Press REC ○ and REC MUTE ● keys in this order to lights up the laser diode.
3. Adjust the voltage value of Pin 7 (PWAJT) of CN104 (TP1) to the voltage value (REC. PW voltage  $\pm 10$  mV) displayed on the pickup flexible cable using VR104 (REC. PW).

**Notes**

- Power more than ten times greater than playback power is released during these adjustment  
Never look directly at the objective lens.
- This adjustment cannot be performed accurately if disc is set. Be sure to remove disc first before adjustments.
- Perform this adjustment more than two minutes after starting up the test mode (after inserting the AC plug).
- The laser diode may be damaged if the recording power is greater than the specified value.  
Always perform step 1 before making adjustments and be careful not to exceed the adjustment value by more than 50mV (specified value in step 3).



Reference : When adjusting with optical power meter.

1. Fully turn VR104 (REC. PW) counterclockwise to reduce the power to the minimum.
2. Move the pickup to the outer edge of the disc with the MANUAL/TRACK SEARCH FWD ►►► key.
3. Press REC ○ and REC MUTE ● keys in that order to lights up the laser diode.
4. Shine the light discharged from the objective lens in the pickup on the light power meter sensor and adjust VR104 (REC. PW) so that the recording laser diode output is an average of  $4.5\text{mW} \pm 0.1\text{mW}$  (Wavelength 790nm, Average mode).

**Notes**

- Perform this adjustment more than two minutes after starting up the test mode (after inserting the AC plug).
- The laser diode may be damaged if the recording power is greater than the specified value.  
Always perform step 1 before making adjustments and be careful not to exceed the adjustment value by more than 0.3mW (specified value in step 3).
- Power more than ten times greater than playback power is released during these adjustment  
Never look directly at the objective lens.

15. HF Amp. Gain Adjustment


Adjustment 2

|   |   |                                     |  |
|---|---|-------------------------------------|--|
| ● Objective                               | To correct the discrepancy in the HF level with the pickup. |                                     |  |
| ● Symptom when out of adjustment          | Player does not record, track search is impossible.         |                                     |  |
| ● Measurement instru-<br>ment connections | Connect the oscilloscope to<br>CN104 (TP1), Pin 8 (HF).     | ● Player state                      | Test mode, play                                      |
|   | [Settings] 50 mV/division<br>500nsec/division<br>DC mode    | ● Adjustment location<br><br>● Disc | VR119 (HF. GAIN)<br>(Head board assy)<br><br>STD-903 |

[Procedure]

1. Move the pickup to midway acrosss the disc (R=35mm) with the MANUAL/TRACK SEARCH FWD ►► ►► or REV ◄◄ ◄◄ keys.
2. Press the FINALIZE key, the PLAY ► key, then the PAUSE || key in that order to close respective servos and put the player into PLAY mode.
3. Line up the bright line (ground) at the center of the oscilloscope screen and put the oscilloscope into DC mode.
4. Adjust VR119 (HF. GAIN) so that the amplitude of the waveform at CN104 (TP1), Pin 8 (HF) is  $2.0V \pm 0.1 V$ .

Note) Adjust after checking that the DISPLAY OFF KEY LED is OFF.



## 16. Focus Servo Loop Gain Adjustment

Adjustment 2

|                                      |   |   |  |
|--------------------------------------|---|---|--|
| ● Objective                          | To optimize the focus servo loop gain.  |   |  |
| ● Symptom when out of adjustment     | Playback does not start or focus actuator noisy.  |   |  |
| ● Measurement instrument connections | See Fig. 7<br>(SERVO UCOM board assy)<br><br>[Settings]<br>CH 1 : 0.1 V/division<br>X-Y mode<br>CH 2 : 10 mV/division | ● Player state<br><br>● Adjustment location<br><br>● Disc | Test mode, play<br><br>VR201 (FCS. GAIN)<br>(SERVO UCOM board assy)<br><br>STD-903 |

## [Procedure]

1. Set the AF generator output to 1.4kHz and 1Vp-p.
2. Move the pickup to midway across the disc (R=35mm) with the MANUAL/TRACK SEARCH FWD ►►►► or REV ◄◄◄◄ keys.
3. Press the FINALIZE key, the PLAY ► key, then the PAUSE || key in that order to close the respective servos and put the player into play mode.
4. Adjust VR201 (FCS. GAIN) so that the lissajous waveform is symmetrical about the X axis and the Y axis.







Fig. 7



Higher gain



Optimum gain



Lower gain



## 17. Tracking Servo Loop Gain Adjustment

Adjustment 2

|                                      |  |                       |   |
|--------------------------------------|--|-----------------------|---|
| ● Objective                          | To optimize the tracking servo loop gain.  |                       |   |
| ● Symptom when out of adjustment     | Playback does not start, during searches the actuator is noisy, or tracks are skipped. |                       |   |
| ● Measurement instrument connections | See Fig. 8<br>(SERVO UCOM board assy)  | ● Player state        | Test mode, play                             |
|                                      | [Settings]<br>CH 1 : 0.1 V/division<br>X - Y mode<br>CH 2 : 10 mV/division             | ● Adjustment location | VR202 (TE. GAIN)<br>(SERVO UCOM board assy) |
|                                      |  | ● Disc                | STD-903                                     |

### [Procedure]

1. Set the AF generator output to 1.2kHz and 2Vp-p:
2. Move the pickup to midway across the disc (R=35mm) with the MANUAL/TRACK SEARCH FWD ►►►► or REV ◄◄◄◄ keys.
3. Press the FINALIZE key, the PLAY ► key, then the PAUSE || key in that order to close the respective servos and put the player into play mode.
4. Adjust VR202 (TE. GAIN) so that the lissajous waveform is symmetrical about the X axis and the Y axis.







Fig. 8



Higher gain



Optimum gain



Lower gain

## 8. TROUBLESHOOTING

### 8.1 Service Number Display

This unit displays "CHECK" or "CHECK" "DISC?" during abnormal operations and stops.

When the STOP key or CLEAR key of the remote control unit is pressed continuously for about 10 seconds, the last service number will be displayed.

To correct the error, check the peripheral circuits mainly for the check point devices.

### 8.2 Service Codes and Countermeasures

| Code     | Contents   | Location of Fault  | Cause   | Checkpoint                               |
|----------|--|--|---|--|
| H0<br>H1 | Unit does not operate even when the cord is inserted into outlet. (CHECK displayed)  | H0: Communication is NG in mechanism controller, mode controller.<br>H1: Mechanism controller detected fault in circuit.   | • Faulty soldering<br>• Pattern short-circuit<br>• Parts short-circuit<br>• Faulty power  | IC356, IC357, IC207, IC358, IC352, IC353 |
| H2       | Recording preparations cannot be performed, tray does not open. (CHECK displayed)  | H2: Mechanism controller pins 22, 23, 24 pin input voltage error   |   | IC205                                    |
| H5       | Recording impossible (CHECK displayed)   | IC360  | • IC360 fault   | IC360                                    |
| L *      | Unit stops during tray open/close. (CHECK displayed)   | Loading section fault has been detected  | • Faulty tray position sensor<br>• Faulty loading motor<br>• Faulty soldering, pattern short-circuit<br>• Pattern short-circuit, faulty power   | IC203                                    |
| E *      | Operations stop when disc is inserted, playback start is requested, REC/P is requested, and operations are acknowledged. (CHECK displayed) | Slider section fault has been detected<br>• Pickup could not be moved to designated position.  | • Flexible cable absent<br>• Faulty drive circuit<br>• Faulty TOC position SW<br>• Faulty soldering, pattern short-circuit<br>• Pattern short-circuit, faulty power   | D1001, IC203, IC201, IC206               |
| P *      | Unit stops when disc is inserted without reading the internal information. (CHECK displayed)   | Spindle section fault has been detected.<br>• Back side of disc has been inserted.<br>• Disc with scratches or dusts has been inserted.<br>• Disc could not be rotated normally.<br>• Designated signal could not be obtained from disc. | • Faulty spindle motor<br>• Faulty spindle drive circuit<br>• Error in FG detection<br>• Faulty WBL circuit<br>• Faulty decoder circuit<br><br>• ATIP, sub codes cannot be read.<br>• Error rate is high.   | PC1001, IC202, IC201, IC206              |
| C *      | Operations stop before REC/P is set. (CHECK displayed)   | Recording laser power related fault has been detected<br>• Disc with scratches or dusts has been inserted.<br>• Proper recording power is not output.<br>• RF detection is not normal.   | • Faulty laser diode.<br>• Error in RF detection.<br>• Faulty RFT, RFB circuit.<br>• Insufficient recording power.<br>• Faulty soldering, pattern short-circuit<br>• Pattern short-circuit, faulty power<br><br>• This error also occurs when ATIP, sub codes cannot be read. | IC205, IC101, IC362, IC363               |
| F *      | Operations stop during playback or recording. (CHECK displayed)  | Pickup section fault has been detected.<br>• Disc with scratches or dusts has been inserted and therefore no focus.<br>• Proper laser power is not output.<br>• No focus.  | • Faulty laser diode.<br>• Faulty focus drive circuit.<br>• Faulty pickup.<br>• Faulty soldering, pattern short-circuit<br>• Pattern short-circuit, faulty power.   | IC206, IC203                             |

| Code | Symptom   | Location of Fault  | Cause  | Checkpoint |
|------|---|--|--|------------|
| A*   | CHECK DISC is displayed and unit stops during recording related operations.   | Stop has been detected during recording.<br>• Disc scratches, dusts, etc. are obstructing operations and unit has stopped. | If hardware problems have occurred, before A* and d* numbers are generated, codes other than those above are generated and the unit stops. Consequently, these service codes are generated only when operational problems have occurred due to the disc. |            |
| d*   | CHECK DISC is displayed and unit stops during recording related operations.<br><br>Disc internal information cannot be read and unit stops when disc is inserted. | Stop has been detected during recording.<br>• Disc scratches, dusts, etc. are obstructing operations and unit has stopped. | Faulty soldering, pattern short-circuit<br>Possible if pattern has short-circuit or power is faulty.   |            |

**Note)** \* indicates the mechanism mode and are the following numbers.

| No. | Mechanism Mode | No. | Mechanism Mode | No. | Mechanism Mode              |
|-----|----------------|-----|----------------|-----|-----------------------------|
| 0   | PLAY           | 5   | Setup          | A   | REC                         |
| 1   | OPEN           | 6   | TOC read       | B   | TOC REC                     |
| 2   | STOP           | 7   | —              | C   | OPC                         |
| 3   | —              | 8   | Search         | D   | TOC check                   |
| 4   | —              | 9   | REC/PAUSE      | E   | PMA, actual pause recording |

## 9. IC INFORMATION

• The information shown in the list is basic information and may not correspond exactly to that shown in schematic diagrams.

### ■ PD4584A (SERVO UCOM BOARD ASSY, IC356)

#### Mechanism Control Microcomputer

##### ● Pin Function

| Pin No. | Mark         | Name   | I/O   | Initial | Function  |
|---------|--------------|--------|-------|---------|---|
| 1       | P43/AD3      | AD3    | I/O   | —       | Data address line   |
| 2       | P44/AD4      | AD4    | I/O   | —       |   |
| 3       | P45/AD5      | AD5    | I/O   | —       |   |
| 4       | P46/AD6      | AD6    | I/O   | —       |   |
| 5       | P47/AD7      | AD7    | I/O   | —       |   |
| 6       | P50/A8       | A8     | O     | —       | Address line  |
| 7       | P51/A9       | A9     | O     | —       |   |
| 8       | P52/A10      | A10    | O     | —       |   |
| 9       | P53/A11      | A11    | O     | —       |   |
| 10      | P54/A12      | A12    | O     | —       |   |
| 11      | P55/A13      | A13    | O     | —       |   |
| 12      | NC           | GND    | —     | —       | Not used  |
| 13      | P56/A14      | A14    | O     | —       | Address line  |
| 14      | P57/A15      | A15    | O     | —       |   |
| 15      | Vdd          | +5V    | —     | —       | Positive power supply voltage   |
| 16      | AVss         | GND    | —     | —       | A/D converter GND   |
| 17      | P70/AN0      | XOPEN  | I     | —       | OPEN SW. "L" when open is completed                                   |
| 18      | P71/AN1      | XCLMP  | I     | —       | CLAMP SW. "L" when clamp DOWN   |
| 19      | NC           | GND    | —     | —       | Not used  |
| 20      | P72/AN2      | GND    | I     | —       |   |
| 21      | P73/AN3      | GND    | I     | —       |   |
| 22      | P74/AN4      | TEPP   | I (A) | —       | Tracking error peak to peak (For tracking gain adjustment)            |
| 23      | P75/AN5      | RFT    | I (A) | —       | Playback RF upper envelope  |
| 24      | P76/AN6      | RFB    | I (A) | —       | Playback RF lower envelope  |
| 25      | P77/AN7      | MACK   | I     | —       | "L" when opposite mode controller serial handshake is input           |
| 26      | AVref        | +5V    | —     | —       | A/D converter reference voltage input                                 |
| 27      | AVdd         | +5V    | —     | —       | A/D converter analog power supply                                     |
| 28      | Vdd          | +5V    | —     | —       | Positive power supply pin   |
| 29      | P20/NM1      | XPFAIL | I     | —       | "L" when power failure is detected. ↓ detection                       |
| 30      | P21/INTP0    | FG     | I     | —       | Spindle FG ↓ detection  |
| 31      | P22/INTP1    | SCOR   | I     | —       | EFM decoder frame sync ↓ detection                                    |
| 32      | P23/INTP2    | ATIP   | I     | —       | ATIP sync ↑ ↓ detection   |
| 33      | P24/INTP3    | ESYN   | I     | —       | EFM encoder frame sync ↓ detection                                    |
| 34      | P25/INTP4    | XRFDI  | I     | —       | "L" when EFM playback RF detected. ↓ detection                        |
| 35      | P26/INTP5    | TOCP   | I     | —       | TOC position sensor (For slider stop processing at TOC position (=L)) |
| 36      | P27/INTP3/TI | SENS   | I     | —       | SONY servo IC SENS signal (For details, refer to 7. Timing Chart.)    |
| 37      | NC           | GND    | —     | —       | Not used  |
| 38      | P30/TxD      | FOK    | I     | —       | Focus OK input ("H" when Focus OK)                                    |
| 39      | P31/RxD      | XECE   | O     | H       | "L" when test tool reading enable is output                           |
| 40      | P32/SO/SBO   | MSO    | O     | L       | Clock sync serial transformer data output)                            |


**Note)** "A" in the I/O column indicates analog.

| Pin No. | Mark                 | Name            | I/O | Initial | Function  |
|---------|----------------------|-----------------|-----|---------|---|
| 41      | P33/SI/SBI           | MSI             | I   | L       | Clock sync serial transfer data input   |
| 42      | P34/SCK              | MSCK            | O   | H       | Clock sync serial transfer clock output   |
| 43      | NC                   | GND             | —   | —       | Not used  |
| 44      | P80/T000             | XFUSE           | I   | H       | "L" when communication between PDC019 ⇄ Mode controller                         |
| 45      | P81/T001             | GFS             | I   | —       | GFS input ("H" when GFS OK)   |
| 46      | P82/T002             | ECLV            | O   | H       | Spindle servo EFM/Wobble CLV mode   |
| 47      | P83/T003             | CLV             | O   | H       | Spindle servo CLV/CAV mode  |
| 48      | P84/T010             | SPSQ            | O   | —       | Spindle drive PWM output during spindle CAV                                     |
| 49      | P85/T001             | MREQ            | O   | H       | "L" when opposite mode controller serial handshake is output                    |
| 50      | RESET                | XRST            | I   | —       | "L" when reset input  |
| 51      | X1                   | CLOCK           | I   | —       | System clock oscillation crystal connection pin                                 |
| 52      | X2                   | CLOCK           | —   | —       | Input to X1 pin when clock is supplied from outside                             |
| 53      | NC                   | GND             | —   | —       | Not used  |
| 54      | Vss                  | GND             | —   | —       | GND pin   |
| 55      | WDTO                 | NC              | O   | L       | Not used  |
| 56      | P00/RTP0             | XSUBQE          | O   | H       | "L" when EFM decoder sub code Q reading is enabled                              |
| 57      | NC                   | GND             | —   | —       | Not used  |
| 58      | P01/RTP1             | XENCE           | O   | L       | "H" when PDC019 serial enable is output   |
| 59      | P02/RTP2             | XASYN           | O   | L       | ATIP frame sync "L"   |
| 60      | P03/RTP3             | XEXSC           | O   | H       | "L" when PDC019 external sync enable is output                                  |
| 61      | P04/RTP4             | SSO             | O   | L       | SONY servo IC command special serial data output                                |
| 62      | P05/RTP5             | SSCK            | O   | H       | SONY servo IC command special serial clock output                               |
| 63      | P06/RTP6             | XLT             | O   | H       | "L" when SONY servo IC command is latched                                       |
| 64      | P07/RTP7             | RECE            | O   | L       | "H" when laser diode recording power is on                                      |
| 65      | EA <sup>—</sup> /Vpp | EA <sup>—</sup> | I   | —       | Used as internal ROM mode when connected to +5V                                 |
| 66      | Vss                  | GND             | —   | —       | GND pin   |
| 67      | P93/TMD              | RAME            | O   | H       | "H" when external SRAM is enable  |
| 68      | P92/TAS              | XSVRST          | O   | L       | "L" when servo system IC mode control reset is output                           |
| 69      | P91/WR               | XWR             | O   | L       | Strobe signal output for external memory write operations                       |
| 70      | P90/RD               | XRD             | O   | L       | Strobe signal output for external memory read operations                        |
| 71      | ASTB                 | ASTB            | O   | —       | Signal which latches lower address signal for external memory access externally |
| 72      | P40/ADD              | AD0             | I/O | —       | Data address line   |
| 73      | P41/AD1              | AD1             | I/O | —       |   |
| 74      | P42/AD2              | AD2             | I/O | —       |   |


1. "External Port"-output from PDJ006A (SERVO UCOM BOARD ASSY, IC207) (External RAM area (8000H to 8FFFH))

| Pin No. | Mark | Name   | I/O | Initial | Function   |
|---------|------|--------|-----|---------|--|
| 45      | POA0 | LDPW0  | O   | L       | LSB —<br>— 5 bit (D/A out) recording laser power output setting<br>— MSB   |
| 46      | POA1 | LDPW1  | O   | L       |  |
| 47      | POA2 | LDPW2  | O   | L       |  |
| 49      | POA3 | LDPW3  | O   | L       |  |
| 50      | POA4 | LDPW4  | O   | L       |  |
| 51      | POA5 | SSEL   | O   | L       | "L" when tracking error envelope detection is reset  |
| 52      | POA6 | —      | O   | L       | Not used   |
| 53      | POA7 | LJUMP  | O   | L       | "H" during N track jump  |
| 54      | POB0 | LIN    | O   | L       | "H" during loading close   |
| 55      | POB1 | LOUT   | O   | L       | "H" during loading open  |
| 56      | POB2 | KOJK   | O   | L       | Optical axis switching circuit ON/OFF  |
| 57      | POB3 | EECS   | O   | L       | EEPROM data writing and reading enable output  |
| 59      | POB4 | —      | O   | L       | Not used   |
| 60      | POB5 | FC_OST | O   | L       | Focus offset switching output. During search: L. Other than search: H  |
| 61      | POB6 | —      | O   | L       | Not used   |
| 62      | POB7 | —      | O   | L       |  |
| 63      | POC0 | TEG0   | O   | L       | LSB —<br>— Tracking error amplifier gain adjustment<br>— MSB   |
| 64      | POC1 | TEG1   | O   | L       |  |
| 65      | POC2 | TEG2   | O   | L       |  |
| 66      | POC3 | TEGM   | O   | L       |  |
| 67      | POC4 | DIRC   | O   | H       | "L" when SONY servo IC DIRC is output  |
| 69      | POC5 | XCDMIR | O   | H       | Mirror detection circuit selection SW CD__R/CD   |
| 70      | POC6 | XLDON  | O   | H       | Laser diode OFF/ON   |
| 71      | POC7 | AMUTE  | O   | H       | Audio final stage mute H (According to mode controller instructions)<br>Turns mute ON during REC PAUSE, when input selector is switched, and during STOP |

## 2. Peripheral Block Diagram (Servo Section)




### 3. Operating Flow Chart (1)







## 4. Operating Flow Chart (2)




Operating image diagram




Tracking error waveforms



## 5. Operating Flow Chart (3)



## 6. Operating Flow Chart (4)




**OPEN**

flashes on the display during these operations.


## 7. Timing Chart

### ① Timing Chart when Power On (Outlet On)



- 1) Power turns on.
- 2) XRST becomes H and reset is turned off.
- 3) After reset is turned off, wait for XPFAIL to become H.
- 4) After XPFAIL becomes H, the microprocessor starts.  
RAME becomes H, and the external SRAM is set to the enable state.
- 5) XSVRST becomes H, and servo circuit operations start.


### ② Timing Chart when Power Failure




- 1) The power starts dropping and after a certain point, XPFAIL becomes L.
  - 2) When XPFAIL becomes L, an internal interrupt is imposed, and the current operation mode and disc data are backed up.
  - 3) At the same time, XSVRST becomes L, servo is reset, RAME is set to L, and the external SRAM is set to the disable state.
  - 4) XRST then becomes L, and reset is set.
- NOTE:** If XRST becomes L first before RAME becomes L, the value of the backup RAM (IC352) will not be stored properly.

## ③ Seek Track 0


Carriage is moved to TOC area (Home position).



## ④ Focus ON




## 8. Tracking Error Gain Adjustment Flow Chart




9. Tracking Gain Adjustment Timing Chart

CD Optimum TEPP value : 2.26V ±0.103V (2.157 to 2.372V)  
CD-R Optimum TEPP value : 2.494V ±0.103V (2.372 to 2.649V)


1) Example of increasing gain to maximum after disc gain became low



2) Example of increasing gain after disc gain became low




3) Example of decreasing gain to minimum after disc gain became high




10. Loading Control for Turn Table

Open/Close Control and SW States

The following shows the timing chart of the loading-related input/output pins.



11. Spindle Servo Mode Selection during CD-R, STOP→PLAY→Search→STOP Operations



# ■ PD4591A (SERVO UCOM BOARD ASSY, IC351)

## Mode Control Microcomputer

### ● Pin Function

| Pin No. | Mark  | Name    | I/O | Initial | Function  |
|---------|-------|---------|-----|---------|---|
| 1       | FIP6  | GRID 6  | O   | L       | FL grid output 5  |
| 2       | FIP5  | GRID 5  | O   | L       | FL grid output 6  |
| 3       | FIP4  | GRID 4  | O   | L       | FL grid output 7  |
| 4       | FIP3  | GRID 3  | O   | L       | FL grid output 8  |
| 5       | FIP2  | GRID 2  | O   | L       | FL grid output 9  |
| 6       | FIP1  | GRID 1  | O   | L       | FL grid output 10                                       |
| 7       | FIP0  | GRID 0  | O   | L       | FL grid output 11                                       |
| 8       | VDD   | VDD     | O   | L       | Connected to VDD  |
| 9       | SCK0  | RSCK    | O   | H       | Not used  |
| 10      | SO0   | RSO     | O   | L       |   |
| 11      | SI0   | RSI     | I   | —       |   |
| 12      | P24   | RACK    | O   | L       |   |
| 13      | P23   | RREQ    | O   | L       |   |
| 14      | SCK1  | FSCK    | I/O | H       | Mechanism controller, LSI serial clock                  |
| 15      | SO1   | FSO     | O   | L       | Mechanism controller, serial output                     |
| 16      | SI1   | FSI     | I   | —       | Mechanism controller, serial input                      |
| 17      | RESET | XRESET  | I   | L       | Mode controller reset input                             |
| 18      | P74   | LED4    | O   | H       | Display ON/OFF LED (L: LED ON)                          |
| 19      | P73   | LED3    | O   | H       | Standby LED (L: LED ON)                                 |
| 20      | AVSS  | GND     | I   | —       | Connected to GND  |
| 21      | P17   | XFUSE   | O   | H       | Mode controller serial communication currently used (L) |
| 22      | P16   | —       | O   | L       | Not used  |
| 23      | P15   | FSLAT   | O   | H       | CE for PDC020A. L: Select                               |
| 24      | P14   | XTALOFF | O   | L       | XTAL ON (L), OFF (H)                                    |
| 25      | P13   | XEMP    | O   | H       | Emphasis control. L: deemphasis                         |
| 26      | P12   | XRST    | O   | L       | Mechanism controller, ATIP decoder reset                |
| 27      | P11   | —       | O   | L       | Not used  |
| 28      | P10   | —       | O   | L       |   |
| 29      | AVDD  | VDD     | —   | —       | Connected to VDD  |
| 30      | AVREF | VDD     | —   | —       |   |
| 31      | P04   | MODE    | I   | —       | Not used. L: Fixed                                      |
| 32      | XT2   | —       | O   | —       | Not used  |
| 33      | VSS   | GND     | —   | —       | Connected to GND  |
| 34      | X1    | —       | I   | —       | System oscillation 4.19MHz                              |
| 35      | X2    | —       | O   | —       |   |
| 36      | P37   | SW1     | I   | L       | Mode ON/OFF (L: Fixed)                                  |
| 37      | P36   | DIP1    | O   | L       | Not used  |
| 38      | P35   | DIP2    | O   | L       |   |
| 39      | P34   | DIP3    | O   | L       |   |
| 40      | P33   | DIP4    | O   | L       |   |

**Note)** U: Pull-up, D: Pull-down




| Pin No. | Mark  | Name    | I/O | Initial | Function   |
|---------|-------|---------|-----|---------|--|
| 41      | P32   | MACK    | O   | H       | Mechanism controller communication response            |
| 42      | P31   | LREQ    | O   | H       | PDC019A CE signal                                      |
| 43      | P30   | UNLOCK  | I   | —       | Digital unlock detection                               |
| 44      | INTP3 | DIGOUT  | I   | —       | Digital output ON/OFF. (H: DIGITAL OUTPUT ON)          |
| 45      | INTP2 | XPFAIL  | I   | —       | Power down detection. L:Power down                     |
| 46      | INTP1 | MREQ    | I   | —       | Mechanism controller communication request (Interrupt) |
| 47      | INTP0 | REMIN   | I   | —       | Remote control input (Interrupt)                       |
| 48      | IC    | VPP     | I   | —       | Connected to GND                                       |
| 49      | P72   | LED2    | O   | L       | Not used   |
| 50      | P71   | LED1    | O   | H       | REC indicator LED (L: LED ON)                          |
| 51      | P70   | LED0    | O   | H       | Manual track increment enable (L: LED ON)              |
| 52      | VDD   | VDD     | —   | —       | Connected to VDD                                       |
| 53      | P127  | SCAN4   | O   | L       | Key matrix output 4                                    |
| 54      | P126  | SCAN3   | O   | L       | Key matrix output 3                                    |
| 55      | P125  | SCAN2   | O   | L       | Key matrix output 2                                    |
| 56      | P124  | SCAN1   | O   | L       | Key matrix output 1                                    |
| 57      | P123  | SCAN0   | O   | L       | Key matrix output 0                                    |
| 58      | P122  | KEYIN3  | I   | —       | Key matrix input 3                                     |
| 59      | P121  | KEYIN2  | I   | —       | Key matrix input 2                                     |
| 60      | P120  | KEYIN1  | I   | —       | Key matrix input 1                                     |
| 61      | P117  | KEYIN0  | I   | —       | Key matrix input 0 (Including test SW)                 |
| 62      | P116  | —       | O   | L       | Not used   |
| 63      | P115  | —       | O   | L       |  |
| 64      | P114  | —       | O   | L       |  |
| 65      | P113  | SEG 10  | O   | L       | FL segment output 10                                   |
| 66      | P112  | SEG 9   | O   | L       | FL segment output 9                                    |
| 67      | P111  | SEG 8   | O   | L       | FL segment output 8                                    |
| 68      | P110  | SEG 7   | O   | L       | FL segment output 7                                    |
| 69      | P107  | SEG 6   | O   | L       | FL segment output 6                                    |
| 70      | P106  | SEG 5   | O   | L       | FL segment output 5                                    |
| 71      | VLOAD | VLOAD   | —   | —       | VLOAD  |
| 72      | P105  | SEG 4   | O   | L       | FL segment output 4                                    |
| 73      | P104  | SEG 3   | O   | L       | FL segment output 3                                    |
| 74      | P103  | SEG 2   | O   | L       | FL segment output 2                                    |
| 75      | P102  | SEG 1   | O   | L       | FL segment output 1                                    |
| 76      | P101  | SEG 0   | O   | L       | FL segment output 0                                    |
| 77      | P100  | GRID 10 | O   | L       | FL grid output 10                                      |
| 78      | FIP9  | GRID 9  | O   | L       | FL grid output 9                                       |
| 79      | FIP8  | GRID 8  | O   | L       | FL grid output 8                                       |
| 80      | FIP7  | GRID 7  | O   | L       | FL grid output 7                                       |

## 1. System serial communication

The mode controller performed serial communication between the mechanism controller and PDC019A (digital interface LSI) and PDC020A (FS converter LSI).

The mechanism controller also performed communication with PDC019A at the following timings.


- ① Communication request from mechanism controller.
- ② Mechanism/mode controller communication
- ③ Communication with mode controller/PDC019A  
During this time, XFUSE is set to L and serial communication of mechanism controller is disabled.
- ④ Serial communication with mode controller/PDC020A
- ⑤ Communication with mechanism controller/PDC019A



## 2. Communication with Mechanism Controller and Mode Controller


### Communication Format

This CPU and the mechanism control CPU performed serial communication with 5 signal lines.



- FSCK ..... Serial transmission clock (1 MHz)
- FSI/FSO ..... Serial data transmission line
- MREQ/MACK ..... Handshake line

The communication timing is control by the mechanism control CPU. 13 byte data is transmitted every 13.33 to 40 ms. (Average:13.33 msec)



Communication is performed by the following procedure.


- ① The MREQ signal becomes L as communication request from the mechanism control microprocessor.
  - ② This microprocessor sets the MACK signal to L as communication enable signal.
  - ③ The mechanism controller sets the MREQ signal to H after 1 byte serial transmission.
  - ④ This microprocessor sets MACK to H if serial transmission has ended normally.
  - ⑤ Hereafter ① to ④ are repeated until the 13 byte data transmission has completed.
- ※ The mechanism controller and mode controller observes the state of the other side's control line, and stops communication processing of transmission if conditions are not satisfied after a certain time.

## 3. Communication with digital interface LSI (PDC019A, IC301)

Communication format

Communication with the digital interface LSI is performed using four lines.

XFUSE is set to L during communication so that there are no clashes with the mechanism controller.




- FSK ..... Serial transmission clock (1 MHz)
- FSI/FSO ..... Serial data transmission line
- BLREQ ..... Data enable
- XFUSE ..... L when the mode controller is using the communication line

Communication is performed in one main routine.


The communication timing is controlled by the mode controller.

No transmission is performed during communication between the mechanism controller and PDC019A.

(Command control)




(Data reading)



## 4. fs Converter Control


Communication is performed by 1 byte transmission only in one direction from the microprocessor to fs converter (PDC020A, IC306).

The communication format is as follows.



- FSK ..... Serial transmission clock (1 MHz)
- FSO ..... Serial data transmission line
- FSLAT ..... fs converter communication enable signal

1 byte is transmitted after communication with the PDC019A LSI.




The data obtained by communication is 1 byte of LSB first.

| Bit | Name     | Initial | Function   |
|-----|----------|---------|--|
| D0  | MKSEL    | L       | L: 384fs, H: 512fs   |
| D1  | FSEL1    | L       | L: 44.1k   |
| D2  | FSEL2    | L       | When FSEL=1 L: 48k, H: 32k   |
| D3  | MUTE     | L       | L: OFF, H: Mute  |
| D4  | STOP VCO | L       | L: PLL transmission stop, H: PLL transmission VCO ON/OFF (H: ON) (Used together) |
| D5  | XOPTSW   | H       | OPT SW ON/OFF (L: ON)  |
| D6  | XENVCO   | H       | VCO for PDC019A ON/OFF (L: ON)   |
| D7  | XTALSEL  | H       | Crystal select (H: XTAL)   |

# ■ PA9004A (SERVO UCOM BOARD ASSY, IC205)

## CDR SERVO AMP

### ● Block Diagram



### ● Pin Function

| Pin No. | Name  | I/O | Function   |      |     |           |        |
|---------|-------|-----|--|------|-----|-----------|--------|
| 1       | VDD   | –   | +5V power supply pin                                       |      |     |           |        |
| 2       | PWM1  | I   | CAV PWM rectification amplifier input pin                  |      |     |           |        |
| 3       | PWM2  | I   | WOBBLE CLV rectification amplifier input pin               |      |     |           |        |
| 4       | PWM2O | O   | WOBBLE CLV rectification amplifier output pin              |      |     |           |        |
| 5       | PWM2+ | I   | WOBBLE CLV LPF capacity connection pin                     |      |     |           |        |
| 6       | PWM3  | I   | EFM CLV rectification amplifier input pin                  |      |     |           |        |
| 7       | PWM3O | O   | EFM CLV rectification amplifier output pin                 |      |     |           |        |
| 8       | SPDL– | I   | Amplifier inversion input pin for spindle motor with brush |      |     |           |        |
| 9       | SPDLO | O   | Amplifier output pin for spindle motor with brush          |      |     |           |        |
| 10      | REFV  | O   | Spindle reference voltage output pin                       |      |     |           |        |
| 11      | GND1  | –   | Ground pin   |      |     |           |        |
| 12      | REFIN | I   | Spindle reference voltage input pin                        |      |     |           |        |
| 13      | CLV   | I   | Spindle control mode setting signal input pin              |      |     |           |        |
|         |       |     | MODE   | STOP | CAV | WOBBLECLV | FEMCLV |
|         |       |     | CLV  | L    | L   | H         | H      |
| 14      | ECLV  | I   | ECLV   | L    | H   | L         | H      |
| 15      | SPDL  | O   | Brushless spindle motor amplifier output pin               |      |     |           |        |

| Pin No. | Name   | I/O | Function  |
|---------|--------|-----|---|
| 16      | FWREV  | O   | Brushless spindle motor polarity signal output pin          |
| 17      | FGOUT  | O   | FG comparator output pin                                    |
| 18      | VEE1   | –   | –4V power supply pin  |
| 19      | FGIN   | I   | FG comparator input pin                                     |
| 20      | Q0     | I   | DA converter data input pin for setting LD power            |
| 21      | Q1     | I   |   |
| 22      | Q2     | I   |   |
| 23      | Q3     | I   |   |
| 24      | Q4     | I   |   |
| 25      | LDPWO  | O   | Voltage output pin for setting LD power                     |
| 26      | TEG0   | I   | Data input pin for setting tracking error gain              |
| 27      | TEG1   | I   |   |
| 28      | TEG2   | I   |   |
| 29      | TE     | I   | Tracking error signal input pin                             |
| 30      | TEO    | O   | Amplifier output pin for setting tracking error gain        |
| 31      | TRKG–  | I   | Tracking error amplifier inversion input pin                |
| 32      | TRKER  | O   | Tracking error amplifier output pin                         |
| 33      | VCC1   | –   | +4V power supply pin  |
| 34      | TEG3   | I   | Tracking error signal level detection mute signal input pin |
| 35      | CTR    | I   | Hold capacitor connection pin for level detection           |
| 36      | TEDET  | O   | Tracking error signal level detection signal output pin     |
| 37      | BIAS   | I   | Ground pin  |
| 38      | WBL1–  | I   | WOBBLE BPF amplifier 1 inversion input pin                  |
| 39      | WBL1O  | O   | WOBBLE BPF amplifier 1 output pin                           |
| 40      | WBL2–  | I   | WOBBLE BPF amplifier 2 inversion input pin                  |
| 41      | WBL2O  | O   | WOBBLE BPF amplifier 2 output pin                           |
| 42      | WBL3–  | I   | WOBBLE BPF amplifier 3 inversion input pin                  |
| 43      | WBL3O  | O   | WOBBLE BPF amplifier 3 output pin                           |
| 44      | WBLC–  | I   | WOBBLE comparator inversion input pin                       |
| 45      | WBLO   | O   | WOBBLE comparator output pin                                |
| 46      | GND2   | –   | Ground pin  |
| 47      | RFB    | O   | OPC RF bottom level detection signal output pin             |
| 48      | RFB+   | I   | OPC RF bottom level detection time-constant setting pin     |
| 49      | RFT    | O   | OPC RF top level detection signal output pin                |
| 50      | RFT+   | I   | OPC RF top level detection time-constant setting pin        |
| 51      | RFOPC  | I   | OPC RF signal input pin                                     |
| 52      | HF     | I   | Mirror detection HF signal input pin                        |
| 53      | VEE2   | –   | –4V power supply pin  |
| 54      | CBL    | I   | Mirror detection bottom hold capacity connection pin        |
| 55      | CPL    | I   | Mirror detection peak hold capacity connection pin          |
| 56      | CDRMR1 | O   | CDR mirror detection signal output pin                      |
| 57      | CDRMR2 | I   | CDR mirror detection signal input pin                       |
| 58      | CDRMRC | I   | CDR mirror comparator non-inversion input pin               |
| 59      | RFDT–  | I   | RF detection comparator inversion input pin                 |
| 60      | RFREF  | I   | RF detection comparator non-inversion input pin             |
| 61      | RFDET  | O   | RF detection signal output pin                              |
| 62      | XCD    | I   | Mirror selection signal input pin                           |
| 63      | MIRR   | O   | Mirror signal output pin                                    |
| 64      | VCC2   | –   | +4V power supply pin  |

# ■ PDJ006A (SERVO UCOM BOARD ASSY, IC207)

## ATIP DECODER

### ● Pin Function


| Pin No. | Name    | I/O | Function   |
|---------|---------|-----|--|
| 1       | WBL     | I   | WOBBLE signal input pin  |
| 2       | FSK     | O   | FSK demodulation signal output pin   |
| 3       | SBSY    | I   | Subcode sync signal input pin  |
| 4       | MDP     | O   | CLV servo MDP output pin   |
| 5       | SPSEL   | I   | CPU interface mode selection signal input pin. H : Serial. L : Parallel                        |
| 6       | ASYN    | O   | ATIP sync output pin   |
| 7       | ACK     | I   | Serial interface clock input pin   |
| 8       | GND     | —   | Ground pin   |
| 9       | AOUTPE  | I   | Serial mode data read enable input pin   |
| 10      | AOUT    | O   | Serial mode data output pin  |
| 11      | AINPE   | I   | Serial mode data write enable input pin  |
| 12      | AIN     | I   | Serial mode data input pin   |
| 13      | XCK     | I   | Master clock input pin   |
| 14      | XSRST   | I   | System reset input pin. L : reset  |
| 15      | SIOK    | O   | Special information standby flag output pin. H: Special information readable. L : Not readable |
| 16      | CRCOK   | O   | CRC calculation results output pin. H : CRCOK. L : CRCNG                                       |
| 17      | RPOTECT | O   | ATIP sync protection state output pin. H : Protected. L : Not protected.                       |
| 18      | VCC     | —   | +5V power supply pin   |
| 19      | N. C.   | —   | Not connected  |
| 20      | XADSEL  | I   | Address decoder start address setting strobe input pin   |
| 21      | XWE     | I   | Parallel mode data write enable input pin  |
| 22      | XRE     | I   | Parallel mode data read enable input pin   |
| 23      | SYA0    | I   | Parallel mode address bus input pin  |
| 24      | SYA1    | I   |  |
| 25      | SYA2    | I   |  |
| 26      | SYA3    | I   |  |
| 27      | SYA12   | I   |  |
| 28      | GND     | —   | Ground pin   |
| 29      | SYA13   | I   | Parallel mode address bus input pin  |
| 30      | SYA14   | I   |  |
| 31      | SYA15   | I   |  |
| 32      | SYD0    | I/O | Parallel mode data bus input/output pin  |
| 33      | SYD1    | I/O |  |
| 34      | SYD2    | I/O |  |
| 35      | SYD3    | I/O |  |
| 36      | SYD4    | I/O |  |
| 37      | SYD5    | I/O |  |
| 38      | VCC     | —   | +5V power supply pin   |
| 39      | SYD6    | I/O | Parallel mode data bus input/output pin  |
| 40      | SYD7    | I/O |  |

| Pin No. | Name  | I/O | Function                               |
|---------|-------|-----|--|
| 41      | XCE0  | O   | Chip select output pin                 |
| 42      | XCE1  | O   |  |
| 43      | XCE2  | O   |  |
| 44      | XCE3  | O   |  |
| 45      | POA0  | I/O | General register A parallel output pin |
| 46      | POA1  | I/O |  |
| 47      | POA2  | I/O |  |
| 48      | GND   | -   | Ground pin                             |
| 49      | POA3  | I/O | General register A parallel output pin |
| 50      | POA4  | I/O |  |
| 51      | POA5  | I/O |  |
| 52      | POA6  | I/O |  |
| 53      | POA7  | I/O |  |
| 54      | POB0  | O   | General register B parallel output pin |
| 55      | POB1  | O   |  |
| 56      | POB2  | O   |  |
| 57      | POB3  | O   |  |
| 58      | VCC   | -   | +5V power supply pin                   |
| 59      | POB4  | O   | General register B parallel output pin |
| 60      | POB5  | O   |  |
| 61      | POB6  | O   |  |
| 62      | POB7  | O   |  |
| 63      | POC0  | O   | General register C parallel output pin |
| 64      | POC1  | O   |  |
| 65      | POC2  | O   |  |
| 66      | POC3  | O   |  |
| 67      | POC4  | O   |  |
| 68      | GND   | -   | Ground pin                             |
| 69      | POC5  | O   | General register C parallel output pin |
| 70      | POC6  | O   |  |
| 71      | POC7  | O   |  |
| 72      | TESTB | I   | For tests                              |
| 73      | TEST  | I   |  |
| 74      | TEST0 | I   |  |
| 75      | TEST1 | I   |  |
| 76      | TEST2 | I   |  |
| 77      | TEST3 | I   |  |
| 78      | VCC   | -   | +5V power supply pin                   |
| 79      | TEST4 | I   | For tests                              |
| 80      | N. C. | -   | Not connected                          |

# ■ (SERVO UCOM BOARD ASSY, IC360)

## 64×16 BIT EEPROM

### ● Block Diagram



### ● Pin Function

| Pin No. | Name  | I/O | Function  |
|---------|-------|-----|---|
| 1       | N. C. | –   | Not connected   |
| 2       | Vcc   | –   | Power supply pin  |
| 3       | CS    | I   | Chip select input pin   |
| 4       | SK    | I   | Serial clock input pin  |
| 5       | DI    | I   | Start bit, ope-code, address, serial data input pin           |
| 6       | DO    | O   | Serial data output. READY/XBUSY internal state display output |
| 7       | GND   | –   | Ground pin  |
| 8       | N. C. | –   | Not connected   |



■ PDC020A (AUDIO DIGITAL BOARD ASSY, IC306)

FS CONVERTER

● Pin Function


| Pin No. | Name  | I/O | Function   |
|---------|-------|-----|--|
| 1       | MKSEL | I   | Digital filter master clock selection signal input pin. H : 512fs L : 384 fs                     |
| 2       | INITB | I   | System reset input pin. L : Reset  |
| 3       | MCK1  | I   | Digital filter master clock input pin  |
| 4       | BCLKI | I   | Bit clock input pin  |
| 5       | WCLKI | I   | Word clock input pin   |
| 6       | DGND  | -   | Ground pin   |
| 7       | DVDD  | -   | +5V power supply pin   |
| 8       | LRCKI | I   | LR clock input pin   |
| 9       | DATAI | I   | Audio data input pin   |
| 10      | CCB   | I   | CPU interface method selection signal input pin. H : Sanyo CCB format. L : General serial format |
| 11      | SPSEL | I   | Mode setting selection signal input pin. H:Parallel. L:Serial                                    |
| 12      | CE    | I   | CPU interface chip enable signal input pin   |
| 13      | CL    | I   | CPU interface data transfer clock input pin  |
| 14      | DI    | I   | CPU interface data input pin   |
| 15      | DO7   | O   | CPU interface input data serial/parallel conversion output pin                                   |
| 16      | DO6   | O   |  |
| 17      | DO5   | O   |  |
| 18      | DGND  | -   | Ground pin   |
| 19      | DVDD  | -   | +5V power supply pin   |
| 20      | DO4   | O   | CPU interface input data serial/parallel conversion output pin                                   |
| 21      | DO3   | O   |  |
| 22      | DO2   | O   |  |
| 23      | DO1   | O   |  |
| 24      | DO0   | O   |  |
| 25      | DATAO | O   | Audio data output pin  |
| 26      | LRCKO | O   | LR clock output pin  |
| 27      | WCKO  | O   | Word clock output pin  |
| 28      | BCKO  | O   | Bit clock output pin   |
| 29      | DGND  | -   | Ground pin   |
| 30      | N. C. | -   | Not connected  |
| 31      | AGND  | -   | Analog ground pin  |
| 32      | VCO   | O   | PLL low pass filter pin  |
| 33      | VIN   | I   | VCO freerunning oscillation setting input pin  |
| 34      | R     | I   | VCO oscillation band adjustment input pin  |
| 35      | STOP  | I   | VCO oscillation stop signal input pin. H : Oscillation. L : Oscillation stops                    |
| 36      | UNLK  | O   | Lock state monitor signal output pin. H : Unlock. L : Lock                                       |
| 37      | MCK2  | I/O | FS converter section master clock input/output pin   |
| 38      | IOSEL | I   | MCK2 I/O selection signal input pin. H : Output. L : Input                                       |
| 39      | AVDD  | -   | Analog power supply pin  |
| 40      | MUTE  | I   | Mute control signal input pin. H : Soft mute. L : Off  |

| Pin No. | Name  | I/O | Function   |
|---------|-------|-----|--|
| 41      | FSEL3 | I   | Output data fs selection signal input pin. H : 2 fs. L : fs                        |
| 42      | TEST  | I   | For test   |
| 43      | DVDD  | -   | Ground pin   |
| 44      | DLSEL | I   | Digital filter output bit number setting input pin. H : 20 bits. L : 18 bits       |
| 45      | FSEL2 | I   | Input fs selection input pin 2. H : 32 kHz. L : 48 kHz                             |
| 46      | FSEL1 | I   | Input fs selection input pin 1. H : 48 or 32 kHz. L : 44.1 khz                     |
| 47      | MSEL2 | I   | Operation mode selection input pin 2. H : Single FSC mode. L : Single DF mode      |
| 48      | MSEL1 | I   | Operation mode selection input pin 1. H : Single operations. L : Normal operations |

## ■ PDC019A (AUDIO DIGITAL BOARD ASSY, IC301)

### EFM ENCODER

#### ● Block Diagram



**● Pin Function**

| Pin No. | Name     | I/O | Function  |
|---------|----------|-----|---|
| 1       | DIN 1    | I   | Optical module responding data input pin                              |
| 2       | DIN 2    | I   | Optical module responding data input pin                              |
| 3       | DIN 3    | I   | Optical module responding data input pin                              |
| 4       | DIN 4    | I   | Optical module responding data input pin                              |
| 5       | DIRRC 1  | I   | RC oscillation input pin  |
| 6       | DIRRC 2  | O   | RC oscillation output pin   |
| 7       | AVDD     | -   | Analog power supply pin   |
| 8       | DIRRS    | I   | VCO oscillation band adjustment input pin                             |
| 9       | AGND     | -   | Analog ground pin   |
| 10      | DIRVCO   | I   | VCO freerunning oscillation setting input pin                         |
| 11      | DIRLPF   | O   | PLL low pass filter pin   |
| 12      | VSS      | -   | Ground pin  |
| 13      | VDD      | -   | +5V power supply pin  |
| 14      | DIRCK    | O   | DIR system clock output pin   |
| 15      | DIRBCK   | O   | DIR bit clock output pin  |
| 16      | DIRLRCK  | O   | DIR LR clock output pin   |
| 17      | DIRDATA  | O   | DIR demodulation data output pin                                      |
| 18      | DIRWDCK  | O   | DIR word clock output pin   |
| 19      | DIRU     | O   | User bit output pin   |
| 20      | DIRERR   | O   | Data error or lock state monitor output pin. H : Unlocked. L : Locked |
| 21      | DRAMSW   | O   | External DRAM capacity setting output pin. H : 4Mbit. L : 1Mbit       |
| 22      | CJSDATA  | I   | Clock jitter suppresser data input pin                                |
| 23      | CJSBCK   | I   | Clock jitter suppresser bit clock input pin                           |
| 24      | CJSLRCK  | I   | Clock jitter suppresser LR clock input pin                            |
| 25      | JITVCOIN | I   | VCO input pin   |
| 26      | JITLPFO  | O   | LPF output pin  |
| 27      | JITLPFI  | I   | LPF input pin   |
| 28      | JITPCO   | O   | Phase comparator output pin   |
| 29      | JITERR   | O   | Lock state monitor signal output pin. H : Unlocked. L : Locked        |
| 30      | DACDATA  | O   | DAC data output pin   |
| 31      | DACBCK   | O   | DAC bit clock output pin  |
| 32      | DACLRCK  | O   | DAC LR clock output pin   |
| 33      | ADCDATA  | I   | ADC recording data input pin  |
| 34      | ADCCLK   | O   | ADC clock output pin  |
| 35      | ADCBCK   | O   | ADC bit clock output pin  |
| 36      | ADCLRCK  | O   | ADC LR clock output pin   |
| 37      | ADCSTBY  | O   | ADC standby signal output pin. H:Operating. L:Standby                 |
| 38      | XTALIN   | I   | System clock input pin  |
| 39      | XTALOUT  | O   | System clock output pin   |
| 40      | VSS      | -   | Ground pin  |


| Pin No. | Name     | I/O | Function   |
|---------|----------|-----|--|
| 41      | VDD      | –   | +5V power supply pin   |
| 42      | DACCKOUT | O   | DAC system clock output pin                                    |
| 43      | ENCCKOUT | O   | CD decoder system clock output pin                             |
| 44      | CDDATA   | I   | CD decoder data input pin                                      |
| 45      | CDBCK    | I   | CD decoder bit clock input pin                                 |
| 46      | CDLRCK   | I   | CD decoder LR clock input pin                                  |
| 47      | CDTX     | I   | Pin for inputting signal from CD decoder output                |
| 48      | DITOUT   | O   | Bi-phase modulation output pin                                 |
| 49      | TP6      | I   | For tests  |
| 50      | XRESET   | I   | System reset input pin. L : Reset                              |
| 51      | TP7      | I   | For tests  |
| 52      | XCAS     | O   | DRAM row address strobe signal output pin                      |
| 53      | XOE      | O   | DRAM output enable signal output pin                           |
| 54      | A8       | O   | DRAM address output pin  |
| 55      | A7       | O   |  |
| 56      | A6       | O   |  |
| 57      | A5       | O   |  |
| 58      | A4       | O   |  |
| 59      | A3       | O   |  |
| 60      | A2       | O   |  |
| 61      | VDD      | –   | +5V power supply pin   |
| 62      | VSS      | –   | Ground pin   |
| 63      | A1       | O   | DRAM address output pin  |
| 64      | A0       | O   |  |
| 65      | A9       | O   |  |
| 66      | XRAS     | O   | DRAM column address strobe signal output pin                   |
| 67      | XWR      | O   | DRAM read/write signal output pin                              |
| 68      | DQ2      | I/O | DRAM data input/output pin                                     |
| 69      | DQ1      | I/O |  |
| 70      | DQ4      | I/O |  |
| 71      | DQ3      | I/O |  |
| 72      | TP0      | I   | For tests  |
| 73      | TP1      | I   |  |
| 74      | TP2      | I   |  |
| 75      | TP3      | O   |  |
| 76      | ENCVCoin | I   | Encode circuit clock input pin                                 |
| 77      | ENCLPFO  | O   | LPF output pin   |
| 78      | ENCLPFI  | I   | LPF input pin  |
| 79      | ENCPCO   | O   | Phase comparator output pin                                    |
| 80      | ENCERR   | O   | Lock state monitor signal output pin. H : Unlocked. L : Locked |

| Pin No. | Name     | I/O | Function   |
|---------|----------|-----|--|
| 81      | TP4      | O   | For tests  |
| 82      | TP5      | I   |  |
| 83      | XRFDET   | I   | RF detection signal input pin. H : No RF. L : RF   |
| 84      | RECEN    | I   | Recording enable signal input pin. H : Recordable. L : Not recordable                            |
| 85      | XSAMPLE  | O   | Sample pulse signal for sample servo output pin  |
| 86      | DET4T    | O   | 4T detection signal output pin   |
| 87      | DET3T    | O   | 3T detection signal output pin   |
| 88      | EFM      | O   | EFM signal output pin  |
| 89      | VDD      | -   | +5V power supply pin   |
| 90      | VSS      | -   | Ground pin   |
| 91      | ENCCK    | O   | Encode clock output pin  |
| 92      | XEXTACK  | O   | ATIP synchronization notification signal output pin  |
| 93      | XEXTSYNC | I   | ATIP synchronization enable signal input pin   |
| 94      | ATIPSYNC | I   | ATIP sync signal input pin   |
| 95      | SUBSYNC  | O   | Subcode sync signal output pin   |
| 96      | CCB      | I   | CPU interface method selection signal input pin. H : Sanyo CCB format. L : General serial format |
| 97      | CE       | I   | CPU interface chip enable signal input pin   |
| 98      | CL       | I   | CPU interface data transfer clock input pin  |
| 99      | DI       | I   | CPU interface data input pin   |
| 100     | DO       | O   | CPU interface data output pin  |

■ PA4022A (HEAD BOARD ASSY, IC101)

RF Amplifier

● Block Diagram




## ● Pin Function

| Pin No. | Name  | I/O | Function  |
|---------|-------|-----|---|
| 1       | RF-   | I   | RF amplifier inversion input pin  |
| 2       | RFSUM | O   | RF summing amplifier output pin   |
| 3       | HDMON | O   | Sample hold signal monitor output pin   |
| 4       | VEE   | -   | -5V power supply pin  |
| 5       | IVMON | O   | I-V amplifier output monitor pin  |
| 6       | SA    | O   | Sample hold capacitor connection pin  |
| 7       | SB    | O   |   |
| 8       | SC    | O   |   |
| 9       | SD    | O   |   |
| 10      | SF1   | O   |   |
| 11      | SF2   | O   |   |
| 12      | SE1   | O   |   |
| 13      | SE2   | O   |   |
| 14      | A     | I   | Detector current input pin  |
| 15      | F2    | I   |   |
| 16      | F1    | I   |   |
| 17      | D     | I   |   |
| 18      | VC    | I   | Middle point voltage (GND) connection pin                                       |
| 19      | C     | I   | Detector current input pin  |
| 20      | E1    | I   |   |
| 21      | E2    | I   |   |
| 22      | B     | I   |   |
| 23      | MD    | I   | Monitor diode current input pin   |
| 24      | CMD   | I   | Playback laser APC I-V amplifier non-inversion input pin                        |
| 25      | MDMON | O   | Playback laser APC I-V amplifier output pin                                     |
| 26      | SMD   | O   | Playback laser APC hold output  |
| 27      | PBL+  | I   | Playback laser APC loop gain setting amplifier non-inversion input pin          |
| 28      | N. C. | -   | Not used  |
| 29      | VCC   | -   | +5V power supply pin  |
| 30      | PBL-  | I   | Playback laser APC loop gain setting amplifier inversion input pin              |
| 31      | PBLO  | O   | Playback laser APC loop gain setting amplifier output pin                       |
| 32      | PBI+  | I   | Playback laser APC voltage current conversion amplifier non-inversion input pin |
| 33      | PBI-  | I   | Playback laser APC voltage current conversion amplifier inversion input pin     |
| 34      | PBO   | O   | Playback laser APC voltage current conversion output pin                        |
| 35      | REI+  | I   | Recording laser power current setting amplifier non-inversion input pin         |
| 36      | REI-  | I   | Recording laser power current setting amplifier inversion input pin             |
| 37      | REO   | O   | Recording laser power current setting amplifier output amplifier                |
| 38      | XSPL  | I   | Sample pulse input pin. H : Hold. L : Sampling                                  |
| 39      | XLDON | I   | Laser diode ON/OFF control signal input pin. H : OFF. L : ON                    |
| 40      | F2-F1 | O   | Subbeam F push-pull signal monitor output pin                                   |

| Pin No. | Name  | I/O | Function  |
|---------|-------|-----|---|
| 41      | E1-E2 | O   | Subbeam E push-pull signal monitor output pin                 |
| 42      | RSUB  | I   | Subbeam gain difference adjustment control connection pin     |
| 43      | STE   | O   | Subbeam differential amplifier output pin                     |
| 44      | RMAIN | I   | Main beam tracking balance adjustment control connection pin  |
| 45      | VEE   | -   | -5V connection pin  |
| 46      | R10K  | -   | Internal 10 k $\Omega$ resistor                               |
| 47      | MTE   | O   | Main beam differential amplifier output pin                   |
| 48      | RTE   | O   | Main/sub gain differential adjustment control connection pin  |
| 49      | MSTE  | O   | DPP signal output pin   |
| 50      | TE-   | I   | Tracking error level adjustment amplifier inversion input pin |
| 51      | TE    | O   | Tracking error level adjustment amplifier output pin          |
| 52      | CF1   | I   | Focus error band limitation capacity connection pin           |
| 53      | CF2   | I   | Focus error band limitation capacity connection pin           |
| 54      | CF3   | O   | Focus error band limitation capacity connection pin           |
| 55      | FE    | O   | Focus error level adjustment amplifier output pin             |
| 56      | FE-   | I   | Focus error level adjustment amplifier inversion input pin    |
| 57      | VR    | O   | Middle point potential generation circuit output pin          |
| 58      | V1    | O   | Internal power supply monitor output pin                      |
| 59      | DWBL  | O   | WOBBLE balance circuit LPF amplifier output pin               |
| 60      | DWBL- | I   | WOBBLE balance circuit LPF amplifier inversion input pin      |
| 61      | WBL   | O   | WOBBLE signal generation amplifier output pin                 |
| 62      | WBL-  | I   | WOBBLE signal generation amplifier inversion input pin        |
| 63      | VCC   | -   | +5V input pin   |
| 64      | WMON  | O   | WOBBLE push-pull signal monitor output pin                    |
| 65      | RWBL  | I   | WOBBLE balance circuit variable resistor connection pin       |
| 66      | HF    | O   | HF signal output pin  |
| 67      | HF-   | I   | HF amplifier inversion input pin                              |
| 68      | RF    | O   | RF signal output pin  |

## 10. FL INFORMATION

### ■ PEL1086 (V701: FUNCTION BOARD ASSY)



#### Pin Connection


| Pin No.    | 1  | 2  | 3  | 4              | 5              | 6              | 7              | 8              | 9              | 10             | 11             | 12             | 13             | 14             | 15  | 16  | 17 |
|------------|----|----|----|----------------|----------------|----------------|----------------|----------------|----------------|----------------|----------------|----------------|----------------|----------------|-----|-----|----|
| Connection | F1 | F1 | NP | P <sub>a</sub> | P <sub>b</sub> | P <sub>c</sub> | P <sub>d</sub> | P <sub>e</sub> | P <sub>f</sub> | P <sub>g</sub> | P <sub>h</sub> | P <sub>i</sub> | P <sub>j</sub> | P <sub>k</sub> | 11G | 10G | 9G |

| Pin No.    | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 |
|------------|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| Connection | 8G | 7G | 6G | 5G | 4G | 3G | 2G | 1G | NP | NP | NP | NP | NP | NP | NP | NP | F2 | F2 |

Notes : 1) F: Filament 2) G: Grid 3) P: Anode 4) NP : No Pin

#### Grid Assignment



#### Anode Connection

|   | 11G        | 10G | 9G | 8G | 7G | 6G | 5G | 4G | 3G | 2G | 1G        |
|---|------------|-----|----|----|----|----|----|----|----|----|-----------|
| a | FADER      | a   | a  | a  | a  | a  | a  | a  | a  | a  |           |
| b |            | b   | b  | b  | b  | b  | b  | b  | b  | b  | OVER      |
| c |            | c   | c  | c  | c  | c  | c  | c  | c  | c  | DIGITAL 2 |
| d | REC        | d   | d  | d  | d  | d  | d  | d  | d  | d  | 32        |
| e | RND        | e   | e  | e  | e  | e  | e  | e  | e  | e  | 44        |
| f | PGM        | f   | f  | f  | f  | f  | f  | f  | f  | f  | ANALOG    |
| g | REP        | g   | g  | g  | g  | g  | g  | g  | g  | g  | DIGITAL 1 |
| h | -1         | h   | h  | h  | h  | h  | h  | h  | h  | h  | ON        |
| i | SYNC       | i   | i  | i  | i  | i  | i  | i  | i  | i  |           |
| j | CD-R       | j   | j  | j  | j  | j  | j  | j  | j  | j  | 48        |
| k | AUTO TRACK |     | k  | k  | k  | k  | k  | k  |    | k  | SKIP      |



## 11. CIRCUIT DESCRIPTION

### 11.1 CD-R DISC

As shown in Fig. 11-1, the CD-R disc is composed of first a recording layer, then a reflection layer, and then a protection layer (these are all color pigment layers) on top of a resin board. Guiding grooves called grooves are opened on the disc. By irradiating strong laser power on these grooves during recording, the color pigments change and pits are formed. The grooves have certain frequency undulations called wobble. The speed of the disc is controlled according to these wobbles. These wobbles are FM-modulated, enabling information on the absolute time, etc. of the disc to be obtained.




Fig. 11-1 CD-R disc structure

The light reflected on the disc again is passed through the objective lens and becomes parallel light again, is passed through the reflection prism and shaping beam splitter, and moves towards the convex lens. After non-point aberration is generated by the multi lens, it enters the 8-divided photo diode. The information signal and focus signal of the disc are formed by the 4 divided parts at the center of the photo diode, and the tracking signal is made by synthesizing all the parts described below.




Fig. 11-2 Structure of pickup

### 11.2 PICKUP

#### 11.2.1 Optical Path of Pickup

Fig. 11-2 shows the internal structure of the pickup. This pickup for recording differs from the normal CD pickup in that, to increase the power generated from the objective lens, the optical system is unlimited, and the laser diode is high output.

If the flow of light is explained based on the optical diagram, first the distributed light from the laser diode is converted to parallel light by the collimator lens, divided into three beams by grating, and directed towards the beam splitter. The light from the laser diode is oval-shaped, and it is made round by the refraction at the plane of incidence of the beam splitter. Some of the light at this time is reflected and induced by the monitor photo diode and used for controlling the power of the laser diode. The light output from the shaping beam splitter is passed through the reflection prism and wave length board, and converged at three spots on the disc by the objective lens.

#### 11.2.2 Servo Method

The focus servo adopts the non-point aberration method like normal CDs. The 3-beam method, like normal CDs, cannot be used for the tracking servo. This is because the 3-beam method senses the brightness/darkness of the disc and servo cannot be imposed in all bright states of the disc before recording. For this reason, the push-pull method is adopted, in which the diffraction light generated by the grooves on the disc are used. By obtaining the right and left difference of the light returning to the photo diode, the tracking signal is obtained. However, with one push-pull signal, offset is generated due to the changes caused by the objective lens following the disc, or the offset generated due to the distortion of the disc. Therefore, as shown in Fig. 11-3, this unit uses the differential push-pull method in which offset is canceled by synthesizing the push-pull signals of the three beams.




Fig. 11-3 Tracking system

## 11.3 Servo Section

### 11.3.1 APC

In this unit laser power control for playback and recording differs. During playback, APC (auto power control) similar to the CD player is basically performed, and during recording, control unique to the CD-R is performed.

During playback, the power output from the laser diode of the pickup is detected by the monitor diode and the detected signal is input from the MD (Pin 23) of the RF amplifier IC (IC101 : PA4022A). After current-voltage (I/V) conversion, it is amplified. Next, the output compared with the voltage of VR103 determining the playback power is input to the

voltage-current (V/I) conversion circuit composed of the internal op-amp of the IC and Q102 and applied to the laser diode. In this way, as the circuit operates so that the current detected by the monitor diode becomes constant, the laser power is always constant regardless of changes in temperature etc.

During recording, the APC for playback also functions. Only when pit is generated is the laser power required for recording generated. To ensure that no level changes occur in the servo signal during recording, the APC functions in the sample hold circuit of the RF amplifier IC using a signal generated by laser power not used for generating pits.

As the recording power changes according to the inconsistency of the disc, it is necessary to control the power to the optimum value each time (OPC adjustment). This value is converted to DC voltage value by the DA converter inside the CDR servo amplifier IC (IC205 : PA9004A) according to the data passing through the ATIP decoder IC (IC207 : PDJ006A) from the mechanism control microprocessor (IC356 : PD4584A, hereafter referred to as mechanism controller) of the servo microprocessor board assembly. It is then input to the op-amp in the RF amplifier IC and the V/I conversion circuit of Q101. This current is current-amplified by the mirror circuit composed of Q103 to Q106, and supplied to the laser diode by the Q107 collector. This current is turned on/off by IC103 and Q108 according to the recording signal from the EFM encoder IC (IC301 : PDC019A) to form the pit rows in the disc.




Fig. 11-4 APC peripheral circuit

### 11.3.2 Error Signal Generation Circuit

As the 3-beam differential push-pull method is used for the pickup of this unit, a pickup main beam 4-divided detector and two sub-beam 2-divided detector are provided. The current output is I-V converted respectively as shown in Fig. 11-5 for generating the HF, RF, wobble, focus error, and tracking error.

The outputs A, B, C, D, E1, E2, F1, and F2 of the detector are input to Pins 14, 22, 19, 17, 20, 21, 16, and 15 of the RF amplifier IC. After I-V conversion, it is led to the sample hold circuit. This sample hold circuit is provided so that each error signals for recording can be generated consistently. It is controlled so that it samples outputs when no pit is generated and holds outputs when pits are generated (when the laser generates recording power).

After the outputs of the sample hold circuit are amplified, the HF, RF, focus error are generated in a manner that the main beam output is calculated in the same way as the CD player, and then output to Pins 66, 68, and 55 respectively. As shown in Fig. 11-6, the focus error is offset-adjusted by VR105 connected to Pin 56, and offset variations caused by temperature changes are canceled by the R148 temperature compensation resistance. Furthermore, when ATIP signals are required for the CD-R disc, focus error is separately adjusted by the circuit composed of Q115 to 117, and VR115 for more reliable performance.

As shown in Fig. 11-7, the tracking error is created by generating the main beam push-pull signal and sub beam push-pull signal, and adding/subtracting these. The light amount balance of the main beam and subbeam is adjusted at VR110 connected to Pin 48 and then output to Pin 49. This output is further gain-adjusted by VR111, offset-adjusted by VR112, input to the RF amplifier IC from Pin 50, amplified and finally output to Pin 51 as the following signal.

$$[(A + D) - (B + C)] - K [(E2 - E1) + (F2 - F1)] / 2$$

(K = 0-1 stage light amount ratio)




Fig. 11-6 Focus error generation circuit

Fig. 11-8 shows the wobble generation circuit. The wobble signal is generated by the main beam so that the calculation  $[(A+D)-(B+C)]$  is performed and output from Pin 61. To prevent C/N deterioration due to the lost in balance of the left and right sides due to the deviation of the disc eccentricity and optical axis of the beam which disables the cancellation of RF components, etc., the auto balance circuit provides good wobble signals at all times.

This circuit passes the calculated output mentioned earlier through the inverting amplifier band-limited to the maximum frequency of eccentricity, and the output is fed back to the FET (Q110) connected to the calculation circuit of the first stage. The FET operates as a variable resistance element.




Fig. 11-5 I/V conversion circuit




Fig. 11-7 Tracking error generation circuit

### 11.3.3 Sample Hold Pulse Generation Circuit

During recording, only during pit generation is the laser power set to the recordable level. Consequently, the level of the light reflected from the disc differs during pit generation and playback level and thus disables normal servo errors from being obtained. This unit therefore uses a sample hold method for extracting signals only during playback. The sample pulse is a signal which remains level L about 500 nsec after the falling of the recording EFM signal to its rising. This pulse is output from the EFM encoder IC and input to Pin 38 of the RF amplifier IC as XSAMPL.




Fig. 11-9 Sample hold pulse timing




Fig. 11-8 Wobble generation circuit

### 11.3.4 Focus Servo

As shown in Fig. 11-10, the focus servo system of this unit is the same as the CD player. The error signal generated in the RF amplifier IC is led to the servo microprocessor board assembly via CN105, adjusted for its loop gain in VR201, and input to FE (Pin 47) and FZC (Pin 46) of the servo control IC for CD (IC201 : CXA1372Q). It is then passed through the defect countermeasure circuit and phase compensation circuit inside the IC and output from FEO (Pin 5). This output is led to the head board assembly and supplied to the focus actuator drive coil by the power ope-amplifier (IC202 : LA6517).





Fig. 11-10 Focus servo circuit

### 11.3.5 Tracking Sled Servo

Fig. 11-11 shows the tracking sled servo system of this unit. The error signals generated in this RF amplifier IC is led to the servo microprocessor board assembly via CN105 and input to TE (Pin 29) of the CD-R servo amplifier IC. This variable gain amplifier is provided to control gain inconsistency of the tracking error signal of each disc, and set the optimum loop characteristics. First, the tracking servo is set to open when TEG0 to TEG2, and TEGM are in a certain condition. The mechanism controller then measures the TEDET (Pin 36) level. From the results, the combination of TEG0 to 2 and TEGM are calculated to set the optimum level of the mechanism controller and reset. The TEDET is a result of detection of the P-P value of the signal passing through the variable gain amplifier and converted to DC. voltage by the external resistor and capacitor.

The output from TRKGR (Pin 32) is passed through the VR202 for loop gain adjustment and input to TE (Pin 43) of the servo control IC for CD. It is then passed through the defect countermeasure circuit and phase compensation circuit inside the IC and is output from TAO (Pin 11). This output is then led to the head board assembly after passing through the switch for selecting the actuator hold amplifier (IC5008 (1/2)) output and supplied to the tracking actuator drive coil by the power ope-amplifier (IC202 : LA6517). Immediately after jumping, the actuator hold is switched from the normal tracking servo loop by the mechanism controller during especially long distance jumps to reduce the time taken for adjusting the actuator and preventing the closing of the tracking servo loop in the incorrect state. This prevents unwanted operations of the actuator and enables accurate address information to be obtained in a short time after jumps.



In order to read wobble signals of CD-R disc more accurately, this unit adopts the optical axis servo. This servo only functions during the playback of CD-R discs and prevents the degradation of read signal due to the incorrect position of optical axis of the pickup during playing back. The output of the optical axis servo amplifier (IC5008 (2/2)) is added to the control signal of the tracking actuator, including the normal tracking servo loop, and operates as double loop.

The signal used for actuator hold and optical axis servo is extracted from the main beam push-pull signal output from MTE (Pin 47) of the RF amplifier IC and subbeam push-pull signal output from STE (Pin 43). In this case a method is oppositely used in which, for normal tracking error signals, the cancellation of the DC offset components is executed by the differential push-pull method.

The TAO output, on the other hand, is passed through the low pass filter (LPF) and input to SL+ (Pin 13) of the servo control IC for CDs. So, this is also a input of the sled servo system, like CD players. The slider control signal output from SLO (Pin 14) is led to the head board assembly via CN106 and supplied to the slider motor by the driver IC (IC203 (1/3)).

### 11.3.6 Spindle Servo

Fig. 11-12 shows the block diagram, of the spindle servo. Different types of spindle control is performed in this unit during playback of recorded parts, playback and recording of unrecorded parts, and change of number of rotations.

First, the playback of recorded parts is the same as CD players. RF signals generated in the RF amplifier IC is passed through CN105, is led to the servo microprocessor board assembly, and input to the RFI (Pin 39) of the servo control IC for CDs. The RF signal input is converted to a binary signal by the comparator, output to EFM (Pin 32), and input to the RF (Pin 24) of the CD decoder IC (IC206 : CXD2500BQ). MDP errors are generated from the sync signal in the EFM signal and the internal reference signal. In this IC, processes hereafter are performed digitally, and finally, ternary PWM signals are output to MDP (Pin 4), input as PWM 3 to the CDR servo amplifier IC, and becomes the spindle control signal whose carrier components have been eliminated by the filter.

As the above mentioned sync signal does not exist during the playback and recording of unrecorded parts, the rotation control signal of the disc called wobbles are read from the grooves on the disc beforehand. Information on the absolute time called ATIP are also obtained from these signals.

In the normal operations of this unit, the rotation of the spindle motor is brought near the rotation speed at the targeted location of the disc by CAV control (angular velocity is constant) which uses the PWM output of the mechanism controller, and then spindle servo using wobbles is selected. In this wobble servo, first the wobble signal generated in the RF amplifier IC is passed through the band pass filter (BPF) of IC104 (2/2), passed through CN105, is led to the servo microprocessor board assembly, eliminated for unnecessary components by the 22.05 kHz BPF composed of Pins 38 to 43 of the CDR servo amplifier IC, binarized by the comparator, and output to WBLO (Pin 45). This signal is then input to WBL (Pin 1) of the ATIP decoder IC. In this IC, the 4.3218 MHz supplied from the EFM encoder IC serves as the master clock. By comparing the phase with the earlier mentioned wobble signal based on the frequency division of this master clock (22.05 kHz), the binary PWM signal is output. This output is input as PWM2 to the CDR servo amplifier IC. At the same time carrier components are eliminated by the filter, phase compensation and gain compensation are performed so that it becomes the spindle control signal.

Apart from the wobble servo, this ATIP decoder also demodulates information such as ATIP sync, absolute time, recommended recording power, lead-in area starting time, read-out area starting time, and disc application from the wobble signal, and sends them to the mechanism controller. When the rotation speed of the spindle motor is changed rapidly during start, stop, search, etc., it is switched to CAV by the mechanism controller. As the current rotation speed information can be obtained because the mechanism controller counts the FG signal obtained from the servo mechanism, it can be changed to the desired rotation speed in a short time. The PWM output from the mechanism controller is input to the CDR servo amplifier IC as PWM1. The above three spindle control signals are switched inside the CDR servo amplifier IC according to the operation mode, output from SPDLO (Pin 9), and the rotation of the spindle motor is controlled by the spindle driver IC (IC203 : LA6520) of the head board assembly.




Fig. 11-12 Spindle servo block diagram

### 11.3.7 Defect Circuit

In the defect circuit, first the RFI signal is inverted and then bottom-held using the long and short time constants. The short time constant bottom hold responds to mirror defects of the disc above 0.1 msec, while the long time constant bottom hold holds the mirror level prior to the defect. These signals are differentiated and level-shifted by AC coupling and compared to generate the mirror defect signal. Using this signal, when the DEFECT signal is H, the tracking error is muted, and by holding the the focus error and spindle error at the value before the defect, player ability is improved.

A schematic diagram is shown in Fig. 11-13, and waveform of sections are in Fig. 11-14.




Fig. 11-13 DEFECT circuit




Fig. 11-14 Waveform of DEFECT circuit

### 11.3.8 EFM-PLL

To demodulate the played back EFM signal, for between 3T to 11T which are multiplied by T's integers to be modulated when T is taken as the channel clock period, the channel clock is required. Because inconsistencies of the spindle rotation actually change the pulse width of the EFM signal, PLL is required for playing back the channel clock.

As shown in Fig. 11-15, one of the EFM signals input to RF (Pin 24) of the CD decoder IC is passed through the internal buffer, output to ASYO (Pin 27), passed through the low pass filter composed of R266, C289, R267, and C288, and input to ASY (Pin 31) as the reference voltage of the EFM comparator of the servo control IC for CDs to compensate the asymmetry of the disc.

The other is led to the PLL inside the CD decoder IC. In this IC, as shown in Fig. 11-16, there are three stages of PLL. The first PLL is not used because it is for variable pitch playback. The second PLL generates the high frequency clock required in the third PLL, and the third PLL is a digital PLL which plays back the actual channel clocks. It is equipped with capture range of above  $\pm 150$  kHz (normal state).




Fig. 11-15 EFM comparator circuit




Fig. 11-16 EFM-PLL block diagram

### 11.3.9 RF Detection

In the CD-R, to differentiate recorded parts from unrecorded ones, the existence of the RF signal is detected. Fig. 11-17 shows the schematic diagram of the RF detection. The mirror circuit of 11.3.10 is also shown in this figure.

First, the HF signal generated in the RF amplifier IC is passed through CN105, is led to the servo microprocessor board assembly, and is input to the HF (Pin 52) of the CDR servo amplifier IC. The outputs of the short time constant peak hold circuit (PS) and bottom hold circuit (BS) is passed through the differential amplifier, and compared with the reference voltage set externally by the comparator. When the RF signal is present, it becomes L, and absent, it becomes H, the XRFDET (Pin 61) is output, and sent to the mechanism controller.

During setup, this signal is used in the TOC area to determine if the disc has been TOC-recorded (including CDs) or not. During recording, it is used for searching for linking position and preventing double writing.

For the RF peak hold signal (RFT) used for OPC operations (optimum recording power calibration) and the RF bottom hold signal (RFB), different circuits with time constants suitable for these operations are incorporated. HF signals are also input and output to RFT (Pin 49) and RFB (Pin 47) respectively and led to the mechanism controller.

The OPC operations of this unit use the higher 4 bits of the 5-bit DA converter described in 11.3.1. After the 15-step recording, while the recorded part is played back, the

difference between the RFT and RFB is calculated, and a DA converter output level is determined so that an ideal recording characteristics is obtained. The step which will produce the most ideal output voltage is selected by 5-bit accuracy (31 steps) and output, enabling recording using the ideal power.

### 11.3.10 Mirror Circuit

Fig. 11-17 shows the schematic diagram of the mirror circuit. The mirror circuit of this unit uses the same generation circuit as CD players for recorded parts. In unrecorded parts, a circuit unique to CD-R is utilized in which RC (radial contrast) generated by intersecting grooves is used. These circuits are switched by the RF detection signal mentioned earlier.

For unrecorded parts, the HF signal input is extracted for its RC components by the peak hold circuit (PS) with short time-constant, AC-coupled, amplified. The resultant signal is compared with integrated RC components as the reference voltage in the comparator and used as the CD-R mirror signal.

For recorded parts, the bottom hold circuit (BS) with short time constant is compared with the divided voltage of the outputs of the peak hold circuit (PL) with a long time constant and bottom hold circuit (BL) to obtain the same mirror signal as CDs.




Fig. 11-17 RF detection, mirror circuit diagram



## 11.4 Audio Section

### 11.4.1 Analog Input Circuit/Recording Control

The analog signal of the Lch is input from the pin jack JA801 (1/2), input to the VR board assembly via CN801, passed through the recording balance control (VR802) and recording level control (VR801), and after balance and level are adjusted, is input to the audio digital board assembly via CN801 again. It is amplified by about 11 dB in IC803 (1/2) and led to the AD converter IC. The same is performed for the Rch analog input signal.

### 11.4.2 AD Converter

Fig. 11-18 shows the schematic diagram of the AD converter IC (IC801:AK5340-VS).

Only the Lch is explained here. One of the signal amplified by IC803 (1/2) is then input to AINL + (Pin 1) via R823 and the other is inverted for its phase by IC803 (2/2) and input to AINL - (Pin 2) via R819. After the differential voltage (due to inverted phase, the signal is double and the noise is half) of these signals have been adjusted, they are AD converted.

As AD converter IC control signals, the 384 fs (fs=sampling frequency) master clock is input to CLK (Pin 20) via the clock buffer (IC308), the 32 fs serial clock is input to SCLK (Pin 15), and the LR clock is input to L/R (Pin 14) from the EFM encoder IC. The fs here is 44.1 kHz, and the master clock frequency divided by 6 (64 fs) is input to CLK as an AD conversion sampling rate.

The AD converted data is output from SDATA (Pin 16) and input to the ADCDATA (Pin 33) of EFM encoder IC. Fig. 11-19 shows the relation between each clock and data.

During operation modes other than analog recording, PD (Pin 10) is made H by signals from the EFM encoder IC ADCSTBY (Pin 37) to set the power down mode. By setting this pin to L during analog recording, the AD converter IC is calibrated.




Fig. 11-18 AD converter schematic diagram




Fig. 11-19 AD converter data output timing

### 11.4.3 Digital Filter

The DATA, BCK, and LRCK from the EFM encoder IC are input respectively to Pins 1, 2, and 28 of the digital filter IC (IC401 : PD7009A).

The 384 fs clock is input to XIN (Pin 6) from the clock buffer (IC308) as the master clock.  $\times 8$  oversampling 20-bit Lch and Rch data are output from DOL (Pin 24) and DOR (Pin 23) of the digital filter IC. Fig. 11-20 shows the output timing.

These digital filter ICs differ as shown in Table 11-1 according to the destination and model. Therefore use the R490, R492, R493, and R502 jumpers accordingly.

| Digital Filter No.         | Destination, Model      | Jumper to be Used |
|----------------------------|-------------------------|-------------------|
| PD7009A<br>(Legato Link S) | PDR-05/ME8<br>PDR-99/KU | R490, R502        |
| PD0116A<br>(Legato Link)   | PDR-05/J                | None              |
| SM5813AP (Normal)          | PDR-05/KU               | R492, R493        |

Table 11-1 Digital filter IC types




Fig. 11-20 Digital Filter Output Timing

### 11.4.4 DA Converter

Fig. 11-21 shows the schematic diagrams of the Lch DA converter IC (IC402 : PD2028B) and differential amplifier. WCKO, BCKL, and LDITA are input from the digital filter to Pins WCK (pin 19), BCK (Pin 20), DLI (Pin 21), and DRI (Pin 22) of the DA converter IC. The 384 fs master clock is input as DACL from IC309 to XI (Pin 8).

The 8 fs data input from DLI (Pin 21) and DRI (Pin 22) is passed through the input interface and oversampled to 32 fs by the compensation filter. In the dither circuit, to prevent noise caused by idling patterns unique to the  $\Sigma\Delta$  conversion DA converter, DC offset and dither are added to the data. The data is then oversampled to 384 fs in the sample hold circuit. By incorporating four secondary  $\Sigma\Delta$  conversion DA converter circuits, a 4  $\Sigma\Delta$  conversion circuit/ch high performance DA converter is realized.

The output circuit performs the resistance-adding of the positive phase outputs and that of the negative phase outputs from 2  $\Sigma\Delta$  conversion circuits and outputs them respectively from LO + and LO -. Furthermore, by operating a total of four signals (positive phase output RO + and negative phase output RO - of another channel) using an external op-amp (IC404), a low distortion rate high S/N DA conversion output is obtained. This amplifier also serves as the primary low pass filter.

Likewise, the Rch is also output from the differential amplifier (IC405).




Fig. 11-21 DA converter schematic diagram

### 11.4.5 Analog Output Circuit

Fig. 11-22 shows the schematic diagram of the Lch output buffer. The output of IC404 (1/2) mentioned earlier is input to the IC404 (2/2) inverted input pin via R437, R483, and R447. C447, C449, R483, R447, and R445 make up the secondary low pass filter here. This section has the following three functions.

First, it serves as a deemphasis circuit. When a preemphasized software is run, the control signal DEEMP is set to H and the transistor Q411 turns on. At this time, deemphasis is imposed by R437, R477, and C465.

Secondly, it serves as a muting circuit. When the POWER switch is turned on/off, and when the input selector is switched, the control signal MUTE is set to H, and the muting transistor Q407 is turned on to mute the audio output. Thirdly, it serves as a zero detection attenuate circuit. It improves the S/N when the data input to the DA converter IC is all zero (when no signals). When the DA converter detects the no-signal state, the control signal LZ is set to H and the attenuate transistor Q409 is turned on to attenuate the noise level of the audio output.

The outputs of this circuit are fed to the rear panel pin jack (JA401) and amplified by headphone amplifier IC (IC406) and fed to the headphone board assembly.




Fig. 11-22 Deemphasis, muting, zero detection attenuate schematic diagram

## 11.5 Digital Audio Section

### 11.5.1 Digital Audio Interface Demodulation (DIR) Block

This unit has two digital inputs-coaxial (COAX) and optical (OPT). The COAX input is waveform-shaped by the two inverters of IC307 and Schmidt inverter of IC312, and input to Pin 4 of the EFM encoder IC. The OPT input is photoelectric converted by the optical reception module (JA301) and input to Pin 1 of the EFM encoder IC. To prevent the effects of noises during COAX input, the power of the optical reception module is turned off.

Fig. 11-23 shows the schematic diagram of the DIR (digital audio interface receiver) in the EFM encoder IC. The inputs from Pins 1 and 4 are selected by the input selection circuit and bi-phase-demodulated. To create the reference clock for extracting data, the edge of the input data is detected and sent to the phase comparator of the PLL. Next, preamble detection and parity error check are performed, and the results are used to determine lock. When locked, L is output from DIRERR (Pin 20) and input to of the servo microprocessor board assembly (the mode controller (IC351 : PD4591A).) When unlock, H is output. For lockup to be performed smoothly, the temporary reference time (frequency close to fs) is created by the RC oscillator composed of DIRRC1 (Pin 5) and DIRRC2 (Pin 6).

Next, clocks are generated by the clock generator and the audio data, C bit, and U bit are extracted. The audio data, bit clock, and LR clock are each output from DIRDATA (Pin 17), DIRBCK (Pin 15), and DIRLRCK (Pin 16) respectively, and input to the FS converter IC as well as to the data selector in the EFM encoder IC. Fig. 11-24 shows the audio data output timing. The C bit and U bit data are sent to the mode controller via the microprocessor I/F. This IC is equipped with a function which sends U bit to the microprocessor I/F in the optimum form according to the category code detected from C bit. However, these data are not output when unlocked.

The PLL is composed of the phase comparator, LPF, VCO, and frequency divider. The phase comparator perform phase comparison at 64 fs using the reference clock made from the input signal and the clock obtained by frequency-dividing the VCO. The output is then smoothed by the DIRLPF (Pin 11) LPF and input to VCO as the control voltage. The VCO is generated at 384 fs by the DIRVCO (Pin 10) free-running setting resistor and DIRRS (Pin 8) oscillation band adjustment resistor.

On the other hand, the selected signal is sent to the digital audio interface modulation block as the through output.




Fig. 11-23 DIR block schematic diagram




Fig. 11-24 DIR section audio data output timing

### 11.5.2 FS Converter

Fig. 11-25 shows a schematic diagram of the FS converter IC (IC306 : PDC020A)

The digital input audio data demodulated by the EFM encoder IC is input to LRCKI (Pin 8), BCKI (Pin 4), and DATAI (Pin 9). For digital inputs with sampling frequency of 48 kHz or 32 kHz, audio data is converted into 44.1 kHz, and for 44.1 kHz, the internal circuits are all passed before output.

As for the conversion method, the 48 kHz or 32 kHz data is first  $\times 8$  oversampled by the digital filter. The process is carried out by the 384 fs clock input to MCK1 (Pin3). Data required for the 44.1 kHz output timing is then extracted from this data, and the output data is calculated by compensation calculation using the data from the internal coefficient ROM. The internal PLL clock is used here. The PLL VCO is oscillated at 14.112 MHz. In the phase comparator, the clock frequency-divided by 294 (when the fs is 48 kHz) and the clock frequency-divided by 441 (when fs is 32 kHz) are compared with the LR clock input to control the VCO.

The converted data is output to LRCKO (Pin 26), BCLKO (Pin 28), and DATAO (Pin 25), and input to the EFM encoder IC again. The timing of the output data is as shown in Fig. 11-24 except that the sampling frequency is 44.1 kHz. The internal operating mode is set by the 8-bit data by serial communication from the mode controller. This data is output as DO0 to DO7 to the external terminal. DO0 to DO4 are used for internal settings and DO5 to DO7 as general resistors. Table 11-2 shows the details.




Fig. 11-25 FS converter schematic diagram

| Register Output Pin | Signal Name | Details  |
|---------------------|-------------|--|
| DO0                 | MKSEL       | Internal digital filter clock selection L: 384 fs, H: 512 fs                                   |
| DO1                 | FSEL1       | Sampling frequency selection. L: 44.1 kHz, H: Other than 44.1 kHz                              |
| DO2                 | FSEL2       | Sampling frequency selection. L: 48 kHz, H: 32 kHz   |
| DO3                 | MUTE        | Output data mute. L: OFF, H: Soft mute   |
| DO4                 | STOP        | FS converter VCO and jitter absorption buffer VCO oscillation control. L: Stop, H: Oscillation |
| DO5                 | XOPT        | Optical module JA301 power supply control. L: ON, H: OFF                                       |
| DO6                 | XEVCO       | EFM encoder VCO generation control. L: Oscillation, H: Stop                                    |
| DO7                 | X'TAL       | Master clock selection. L: VCO, H: Crystal   |

Table 11-2 FS converter IC register details

11.5.3 Clock Jitter Suppressor (CJS) Block

To input the data and clock from the FS converter IC to the DA converter IC, it is necessary to reduce the jitter as much as possible. In this block, by imposing another trigger using a jitter-less clock made by a VCO (lithium tantalate) with highly stable frequency compared to normal VCOs, clean clocks and data are supplied to the following circuits. Operations are explained according to the schematic diagram of Fig. 11-26. The FS converter output is input to CJSLRCK (Pin 24), CJSBCK (Pin 23), and CJSDATA (Pin 22). The 16.934 MHz output from VOUT (Pin 8) of the VCO PCX1021 (IC303) is input to JITVCOIN (Pin 25) of the EFM encoder IC, and using CJSLRCK and the LRCK created by frequency-dividing this, phase comparison is performed. When the difference in phase between these two LRCKs is above 90 degrees, it is determined as unlocked and mute is imposed. The phase comparison output is output to JITPCO (Pin 28), passes through the JITLPFI (Pin 27) and JITLPFO (Pin 26) filters and input to VIN (Pin 1) of the VCO to control the oscillation frequency.

The inputs from the FS converter IC imposed with re-trigger by the VCO clock are fed to the data selector in the EFM encoder IC.




Fig. 11-26 Clock jitter suppressor circuit

#### 11.5.4 Data Selector, Digital Fader, Level Meter, Mute Block

The outputs from the DIR block, AD converter IC, CD decoder

IC, and CJS block are selected by the data selector block by the commands from the mode controller, and input to the digital fader and level meter.

In the digital fader block, fade in and fade out operations are performed during recording and playback by the attenuation data from the mode controller.

In the level meter block, absolute value conversion and logarithmic conversion are performed for the data input, the peak-held 8-bit data is read by the mode controller from the microprocessor I/F to light up the front panel level meter. Furthermore, absolute zero level detection is performed and used for detection no-sound states during the recording of the digital input.

The digital fader outputs are passed through the mute block, and one is output to DACDATA (Pin 30), DACBCK (Pin 31), and DACLRCK (Pin 32) as the output to the DA converter IC, and the other is led to the memory controller block in the EFM encoder IC.

#### 11.5.5 Memory Controller Block

The memory controller is equipped with a function which delays the audio data for recording. The 16-bit data is serial/parallel-converted every 4 bits and is delayed by about 700 ms by the external 1Mbit DRAM. The DRAM used here (IC304 : MB81C4256A) corresponds to the fast page mode and is refreshed every 11.6 ms. This block is used for preventing the head of data from dropping immediately after recording starts according to the copy prohibition bit determination time and disc rotation standby time during digital input recording.

For the writing clock of this block, the same clock output to the DA converter IC is used. The reading clock is created by the clock created at the external VCO (IC302 : CD74HC4046AM).

The data output from this block is fed to the CD encode block in the EFM encoder IC.

#### 11.5.6 EFM Encoder Block

Fig. 11-27 shows the schematic diagram of the EFM encoder block and its peripherals. The audio data output from the memory controller block is interleaved by the CIRC (Cross Interleave Reed-Solomon Code) encoder, added with the C1 and C2 error correction codes, EFM-modulated (Eight to Fourteen Modulations), and added with subcodes, sync, and merge bits. It is then NRZI-converted to become the CD format EFM signal. This IC incorporates a CIRC encoder RAM.

3T to 11T ( $T = 231 \text{ nsec}$ ) signals are created here, which are the signals on the disc. To obtain the ideal length when the bit length is played back after recording, the LD power On time is slightly reduced by the strategy block. Specifically, the 3T to 11T pulse is made  $(N-1)T$ , taken as 2T to 10T, and 2T is converted to a longer pulse of 60 nsec and 3T to 10 nsec. This output is finally output from Pin 3 of IC310, passes through the servo microprocessor board assembly, passes through CN105, converted to the recording pulse by the LD driver circuit of the head board assembly, and recorded on the disc by driving the pickup LD.

The CD-R recorders perform laser power calibration before recording. The test signal for this is also created in this block, switched with the audio data EFM signal during calibration, and output.

As this IC also controls the start of the output of the EFM signal using the RF detection signal input to XRFDET (Pin 83), it is able to additionally record at an accurate timing.

As EFM encoder processing requires EFM master clocks, PLL is composed of the internal phase comparator, LPF, external VCO (IC302). In the phase comparator, using the LR clock of the writing side of the memory controller block as reference, the clock (17.2872 MHz) divided by 392 input to ENCVCOIN (Pin 76) from the VCO is compared with the reference, and output from ENPCPO (Pin 79). The signal is then passed through the ENCLPFI (Pin 78) and ENCLPF0 (Pin 77) LPF, input to VCOIN (Pin 9) of the VCO to control the oscillation frequency.

To synchronize the subcode sync of the EFM signal to be recorded and the ATIP sync on the disc, the ATIP sync from the ATIP decoder IC is input to the ATIPSYNC (Pin 94). This is valid when XEXTSYNC (Pin 93) is L and is synchronized while standing by for recording. Subcode sync of the EFM signal for confirmation is output from the SUBSYNC (Pin 95) and taken into the mechanism controller.

The microprocessor I/F connected to the mode controller and mechanism controller via four lines-CE (Pin 97), CL (Pin 98), DI (Pin 99), and DO (Pin 100). Via this I/F, EFM encoder IC internal operation mode settings, digital out C bit setting, digital fader attenuate data input, subcode P and Q input, bits C and U read from digital input signal output, PLL lock conditions output, and level meter data output.




Fig. 11-27 EFM Encoder block and peripherals schematic diagram

### 11.5.7 Digital Audio Interface Modulation (DIT)

#### Block

There are three digital audio interface outputs—through signal from the digital audio interface input, playback signal from a disc encoded at the CD decoder IC, and analog input AD-converted and encoded. These are selected inside the EFM encoder IC according to each mode, passed through JA302 as the coaxial output and JA303 as the optical output from DITOUT (Pin 48), and sent to outside.

In this block, DATA from the AD converter are especially converted to the digital audio interface format. At this time, C bit is set via the microprocessor I/F and output as category: CD, sampling frequency:44.1 kHz, emphasis:none, copy prohibit, clock accuracy as  $\pm 1000$  ppm.

### 11.5.8 Master Clock

During recording of digital inputs with 48 or 32 kHz fs, a clock 384 times the fs created at the DIR block VCO is output from DIRCK (Pin 14). This clock is input to MCK1 (Pin 3) as the master clock of the digital filter of the FS converter IC. The clock frequency-divided inside serves as the reference for the FS converter PLL. A 14.112 MHz, which is 294 times the fs (441 times when 32 kHz) is created and is used as the master clock of the FS converter.


The LR clock output from the LRCKO (Pin 26) of the FS converter IC is input from CJS LRCK (Pin 24) as the reference clock of the CJS section. PLL is further composed by the lithium tantalate VCO. When the digital input fs is 44.1 kHz, the output from DIR serves as the reference clock as it is. The lithium tantalate is oscillated at 16.934 MHz, which is 384 times the 44.1 kHz clock, and is used as the master clock during digital inputs in blocks hereafter.

During recording of the analog input and disc playback, the 16.934 MHz of the IC308 crystal oscillator serves as the master clock of the system. The oscillation of the VCO of the DIR section and VCO of the CJS section stops.

The above two 16.9344 MHz master clocks are selected by IC309 according to the operation mode of this unit. The master clock selected here is supplied to the EFM encoder IC, CD decoder IC, AD converter IC, digital filter IC, and DA converter IC.


## 12. BLOCK DIAGRAMS

### 12.1 SERVO SYSTEM






12.2 AUDIO SYSTEM



## 13. PANEL FACILITIES

### • FRONT PANEL (For PDR-99)

The operations available using buttons marked ★ are also available using the buttons with the same names or inscriptions on the remote control unit.




### • DISPLAY

Lights when automatic digital-source synchro recording is activated.

Lights in the program mode.

Displays messages.



Blinks during disc identification and lights steadily if the loaded disc is a CD-R disc before finalization.

## 14. SPECIFICATIONS

- The following dimensions are for PDR-99/KU.

### 1. GENERAL

|                                |  |
|--------------------------------|--|
| Model .....                    | Compact disc audio system  |
| Applicable discs .....         | CDs and CD-Rs  |
| Power supply .....             | AC 120 V, 60 Hz  |
| Power consumption .....        | 19 W   |
| Operating temperature .....    | +5 °C to +35 °C<br>(+41 °F to +95 °F)                                  |
| Weight (without package) ..... | 6 kg (13 lb 1 oz)  |
| Max. dimensions .....          | 457 (W) x 287 (D) x 132 (H) mm<br>18 (W) x 11-5/16 (D) x 5-7/32 (H) in |

### 2. AUDIO UNIT

|   |  |
|---|--|
| Frequency characteristics .....               | 2 Hz to 20 kHz   |
| Playback S/N .....                            | 112 dB (EIAJ)  |
| Playback dynamic range .....                  | 97 dB (EIAJ)   |
| Playback total harmonic distortion .....      | 0.0026 % (EIAJ)  |
| Playback channel separation .....             | 100 dB   |
| Recording S/N .....                           | 92 dB  |
| Recording dynamic range .....                 | 92 dB  |
| Recording total harmonic distortion .....     | 0.004 %  |
| Output voltage .....                          | 2 V  |
| Wow-flutter .....                             | Less than measurement limit<br>( $\pm 0.001$ % W.PEAK) (EIAJ)  |
| Number of channels .....                      | 2 channels (stereo)  |
| Digital output .....                          | Coaxial output: 0.5 V <sub>p-p</sub> $\pm 20$ % (75 $\Omega$ ) |
| Optical output: .....                         | -15 to -20 dBm (wavelength: 660 nm)                            |
| Frequency deflection: Level 2 (standard mode) |  |

- \* Recording specification values are for the LINE input (ANALOG).

### 3. INPUT JACKS

Optical digital input jacks  
Coaxial digital input jack  
Audio LINE input jack

### 4. OUTPUT JACKS

Optical digital output jack  
Coaxial digital output jack  
Audio LINE output jack

### 5. RECORDING FUNCTIONS

- Recording
- Automatic digital-source synchro recording (1-track recording)
- Automatic digital-source synchro recording (All-track recording)

- REC MUTE
- AUTO TRACK INCREMENT
- AUTO REC/PAUSE
- Remaining recording time display
- PREVIOUS
- MANUAL TRACK INCREMENT
- INPUT SELECTOR
- TOC Write
- Fade-in/fade-out
- SCMS (Serial Copy Management System)
- Sampling monitor

### 6. PLAYBACK FUNCTIONS

- PLAY
- PAUSE
- STOP
- MANUAL search
- TRACK search
- Direct song selection
- 1-Track repeat
- All-track repeat
- Programmed repeat
- Programmed playback (max. 24 tracks)
- Program check
- Program correction
- Program clear
- Pause programming
- Program reservation
- SKIP playback
- DISPLAY OFF
- TIME display switching
- Random playback
- Fade in/Fade out

### 7. ACCESSORIES

- Remote control unit (CU-PD075) ..... 1
- Size AAA/R03 dry cell batteries ..... 2
- Audio cable ..... 2
- Control cable ..... 1
- Operating Instructions ..... 1

#### NOTE:

*The specifications and design of this product are subject to change without notice, due to improvements.*